INSTRUCTIONS ON HOW TO USE THE INDEX

BELOW ARE THE DIFFERENT SECTIONS THAT WILL APPEAR IN THE INDEX:

- A) SORTED BY PRODUCT NAME (CURRENT AND ARCHIVABLE ITEMS):
 THIS INDEX IS FOR THE USER WHO IS
 RUNNING ARCHIVABLE SOFTWARE. IT WILL
 LIST, IN THE ORDER IN WHICH THEY SHOULD
 AFFEAR IN THE LIBRARY, ALL CURRENT AND
 ARCHIVABLE PRODUCTS.
- B) SORTED BY PRODUCT NAME (CURRENT ITEMS ONLY): THIS INDEX IS FOR THE USER WHO IS RUNNING ALL CURRENT SOFTWARE ANY ITEMS NO LONGER LISTED WOULD BE OPSOLETE.
- C) SORTED BY PART NUMBER:
 THIS WILL GIVE YOU THE ABILITY
 TO LOOK UP A INDIVIDUAL PART NUMBER
 AND FIND THE LOCATION (OR LOCATIONS)
 OF IT IN THE LIBRARY
- D) SORTED BY TITLE OF MANUAL:
 THIS WILL SIVE YOU THE ABILITY
 TO LOOK UP A MANUAL BY THE TITLE
 AND FIND THE LOCATION (OR LOCATIONS)
 OF IT THE LIBRARY.

WHEN YOU RECEIVE NEW UPDATES TO BE PLACED INTO YOUR LIBRARY REFER TO THE INDEX WHICH WOULD APPLY TO YOU (EITHER ARCHIVABLE OR CURRENT SOFTWARE) AND PLACE THEM IN THE ORDER THEY AFFEAR ON THE INDEX. TO FIND NEW ITEMS EASILY REFER TO THE 'DATE' COLUMN AND ALL ITEMS WHICH HAVE THE SAME DATE THAT IS ON THE HEADER OF THE TITLE STRIP ARE THE ONES THAT YOU WOULD BE RECEIVING.

EXAMPLE: YOU RECEIVE 'INDEX 83-JUN'

YOU WOULD REFER TO ANY ITEMS THAT HAVE "JUN 83" IN THE DATE COLUMN, THESE ARE THE ITEMS YOU WILL BE PLACING INTO YOU LIBRARY.

ALSO, INCLUDED ON THE INDEX WILL BE THE NEW ITEMS FOR THE UFCONING MONTH. THE 'NUMBER OF THE FICHE' COLUMN WILL BE BLANK AND THE 'DATE' COLUMN WILL REFLECT THE MONTH YOU SHOULD BE RECEIVING THE FICHE.

IF YOU HAVE ANY PROBLEMS, QUESTIONS, OR SUGGESTIONS PLEASE WRITE TO:

DIGITAL EDUIPHENT CORP. CONTINENTAL BOULEVARD HERRIHACK, NH 03054

ATTN: DEB91E DUSLING MK1-2/N34

COLOR CODING FOR JULY 1984

RSX-11H/RSX-11H-PLUS/RSX-11S LIBRARY

	RSX-11H	V4.1	LT. BLUE	QJ628
	RSX-11H-FLUS	V2.1	PLAIN	QR500
	RSX-11S	V4.1	GRAY	03642
	BASIC+2 FOR RSX-11H/H+,FDP-11	V2.1,2.2	GREEN	QJ918
	BCP	V1.0	WHITE	0JS05
	CHR11/CHV11 SOFTWARE BRIVER	V1.0,3.0	GRAY	QJS28
	COBOL-81/RSX	V2.0	REIGE	QJ994
	CORR TOE-INE	V1.0	BROWN	QJ734CF
	COMM IOP-DZ	V1.0	PLAIN	QJ73301
	CORAL-66, FUP-11	V4.0	YELLOW	QP056
	DATATRIEVE-11	V3.0	URANGE	QF301
	DBMS-11	V2.0,2.1	PINK	QP376
	DECNET-11H	V3.1,4.0	RED	QJ764
	I/F/H	V4.1	BLUE	QJ651
***	DRU11-C RSX-11 DRIVER	V4.2	WHITE	QJS33XD
	DT07-11H	V1.1	LT.BLUE	0JS26
	BX/11H	V3.1	PURPLE	0J704CD
	FHS-11/RSX	V1.0	WHITE	QJ715
	FORTRAN IU/RSX	V2.6	GRAY	QF230
	FORTRAN-77 DEBUG, PDP-11	V1.0	BROWN	QP232
	FORTRAN-77/RSX, PDP-11	V5.0	REIGE	0.1668
	IEC-11H	V3.0	YELLOW	QJS02
***	IEX-PRX DRIVER	V2.0	ORANGE	QJ\$3?
	KHC-11 TOOLS	V1.0	REI	0163340
	KHV11-A HDLC FRAMING SOFTWARE	J1.0	PINK	@US32
	LSP-11	V1.2	PLAIN	RJ724AD
***	HICROPOWER/PASCAL-RSX	V1.5	WHITE	QP029
	MUX200/RSX-IAS	V2.1	DRANGE	0J070
	OBSERVER	V1.0,1.1	YELLOW	QSP40
	PASCAL/RSX, FDF-11	V1.0,1.1	GRAY	QJ128
	PDF-11 COBOL	V4.1.4.4	BROWN	QP012
	FLXY-11H	V1.1,1,3	GRAY	0J590
	PRO HOST CONHUNICATIONS	V1.5,1.7	GREEN	
	PRO HOST TOOL KIT	V1.0,2.0	LT. GREEN	QBA14
***	FRO REAL TIME INTERFACE LIBRARY		WHITE	QBA58A3
	FRO TOOL KIT BASIC-PLUS-2	V2.1,2.2	WHITE	9J073
	PRO TOOL KIT COBOL-81	V2.0,2.1	BLUE	QBA19
	PRO TOOL KIT DIBOL	V1.0,1.6	FEIGE	OBA16
	PRO TOOL KIT FORTRAN-77	V5.0	GRAY	QJ074
	PRO TOOL KIT FORTRAN-77/DBG	V1.0	LT. FLUE	QBA21
	PRO HOST TOOL KIT PASCAL	V1.1.1.2	ORANGE	QBA18
	RGL/11	V1.1	BROWN	QJ123
	RSX-11 2780/3780 EMULATOR	V4.1	PURPLE	07085
***	RSX-11H-PLUS DECTYPE	V3.0	WHITE	08038
***	RSX-11H-FLUS DIBOL	V1.0	LT. BLUE	QP540
	RSX-11 FSI/H	V2.0	BLUE	QJD91
	RSX-11/PROVUE	V2.0	GRAY	QJ333
	RSX-11H/3271 FR0TOCOL EMULATOR	V3.0	GREEN	
	RSX-11H/FORTAN ENHANC PKG HINC	V1.1.1.2	YELLO4	QJV43

RSX-11M/IAS RUE/HASF	V1.1	GREEN	QJ\$60
RSX-11H SNA PE	V1.1	GRAY	0JD69
RSX DLX-11	V1.0	WHITE	RJ689
RSX HDE/T11	V1.0	BLUE	QJA62
RTEH-11	V1,1,2.0	GREEN	QJ291
SORT-11	V2.0,3.0	FINK	0P602
SSF-11	V1.3	RED	QJ962AI
UN1004/RSX	V2.0	DRANGE	0J170
VSV11-M DRIVER	V2.0,2.1,2.2	YELLOW	QJ527
VTV31-K RSX-11H DRIVE & SUB	PKG V1.0	WHITE	QJS84

*** NEW PRODUCT

OPERATING SYSTEM	FRODUCT NAME	TITLE OF MANUAL	VERSION	PART NUMBER REV LEVEL	NUMBER OF FICHE	DATE
*RSX	RSX-11ri	RSX-11H/RSX-11S RELEASE NOTES	4.1	AA-2573H-TC-001	2	E3 VON
*RSX	RSX-11M	RSX-11H/11S INFORMATION DIRECTORY/INDEX	4.1	AA-2593G-TC-001	4	MON 92
*RSX	RSX-11H	RSX-11M GUIDE TO WRITING AN 1/O DRIVER	4.1	AA-2600E-TC-001	Ţ	H00 83
*RSX	RSX-11H	IAS/RSX-11 SYSTEM LIB ROUTINE REF MANUAL	4.1	AA-55808-TC-001	2	NOV 83
#RSX	RSX-11M	MSX 11 SYS GENERATION AND INSTALLATION GDE	4.1	AA-H6250-TC-001	5	40V 22
*RSX	RSX-11M	RHS-11 FROGRAMMERS MANUAL	4.1	AA-L658A-TC-001	5	E8 00M
*RSX	RSX-11H	RMS-11 USER'S GUIDE	4.1	AA-Löb9A-TC-001	2	HDV 83
#RSX	RSX-11H	RMS-11 UTILITIES MANUAL	4.1	AA-L570A-TC-001	3	NOV 83
#R5X	RSX-11H	RSX-11M/M-PLUS BATCH AND QUEUE OPERATIONS MAN	4.1	AA-L671A-TC-001	2	HOV 83
*RSX	RSX-11H	RSX-11H/H-PLUS COMMAND LANGUAGE MANUAL	4.1	AA-L672B-TC-001	Ġ	NOV 83
ARSX	RSX-11M o	RSX-11H/M+ CRASH DUMP AND REF HAHUAL	4.1	AA-L673R-TC-001	3	NOV 83
*RSX	RSX-11H	RSX-11H/M-PLUS ERROR LOGGING MANUAL	4.1	AA-L6748-TC-001	3	NO9 83
*RSX	RSX-11M	RSX-11H/H-PLUS EXECUTIVE REFERENCE HANUAL	4 1	AA-L675A-TC-001	4	HOV 83
*RSX	RSX-11H	RSX-11H/H-PLUS GUIDE TO PROGRAM DEVELOPMENT	4.1	AA-L676A-TE-001	2	NOV 83
*RSX	RSX-11H	RSX-11H/H+ I/O DRIVERS REF HAN (UPD#1)	4.1	AA-L677A-TC-001	ó	NOV 83
≱ RSX	RSX-11M	RSX-11M/H4 MCR OPERATIONS MANUAL (UPD#1)	4.1	AA-L678A-TC-001	5	NOV 83
*RSX	RSX-11n	RSX-11H/H} SYSTEM HANAGEHENT GDE (UFD#1)	4.1	AA-Lo79B-TC-001	ó	MON 83
#RSX	R5X-11H	RSX-11H/M-PLUS TASK BLDR HANUAL (UPD#1)	4.1	AA-16808-TC-001	5	NOV 63
₹RSX	RSX-11H	RSX-11M/H-PLUS UTILITIES MANUAL (UP[41)	4.1	44-L6614-TC-001	ð	NOV 83
#RSX	RSX-11H	RMS-11: AN INTRODUCTION	4.1	AA-L682A-TC-001	1	NOV 83
#RSX	RSX-11H	INTRODUCTION TO RSX-11m AND RSX-11m-FLUS	4.1	AA-L763A-T0-001	2	NOV 83
#RSX	RSX-11H	IAS/RSX-11 I/O OPERATIONS REFERENCE MANUAL	4.1	AA-H176A-TC-001	3	NOV 83
*RSX	RSX-11H	EDT EDITOR HANUAL	4.1	ён-1476A-TK-001	3	FEB 64
*RSX	RSX-11h	EDT OBJEK REFERENCE MANUAL	4.1	AA-H477A-TK-001	4	FEE 84
#RSX	RSX-11H	IAS/RSX-11 DDT REFERENCE HANUAL	4.1	44- h 5074-TC-001	1	NOV 83

OPERATING SYSTEM	FRODUCT NAME	TITLE OF HANUAL	VERSION	PART Number Rev Level	NUMBER OF FICHE	DATE
*RSX	RSX-11h	FDF-11 MACRO-11 LANGUAGE REF HANUAL	4.1	AA-9027A-TC-001	3	NOV 83
*RSX	RSX-11H	RSX-11M V4.1 SPD 14.32.21	4.1	AE-3407V-TC-001	1	mA/ 84
*RSX	RSX-11H	RSX-11H CROSS REFERENCE TABLE	4.1	AE-H778F-TC-001		OC1 64
*RSX	RSX-11M	RSX-11H HINI REFERENCE	4.1	AV-5570E-TC-001	3	NOV 65
*KSX	RSX-11H	PDF-11 PROGRAMMING CARD	4.1	EH-51045-78-001	1	K8 V0N
*RSX	RSX-11H-PLUS	IAS/RSX-11 SYSTEM LIB ROUTINE REF MANUAL	2.1	AA-55808-TC-001	2	NOV 63
*RSX	RSX-11H-PLUS	RSX-11H-PLUS GUIDE TO WRITING I/O DRIVER	2.1	AA-H267E-TC-001	4	MOV 83
*RSX	RSX-11H-PLUS	RSX-11H-FLUS INFORMATION DIRECTORY AND INDEX	2.1	AA-H426C-TC-001	4	HOV 93
#RSX	RSX-11H-PLUS	RSX-11M-PLUS V2.1 RELEASE NOTES	2.1	AA-H427C-TC-001	1	Fo VIIN
*R5X	RSX-11H-PLUS	RSX-11m-FLUS SYSTEM GEN/INSTALLATION GUIDE	2.1	AA-H431C-TC-001	3	NOV 63
*RSX	RSX-11H-PLUS	RMS-11 PROGRAMMERS HANUAL	2.1	4A-1668A-TE-001	5	NOV 83
#RSX	RSX-11H-PLUS	RMS-11 USER'S GUIDE	2.1	йй-Loó9й-TC-001	2	NOV 83
#RSX	RSX-11M-PLUS	RMS-11 UTILITIES	2.1	AA-L670A-TC-001	3	NOV 83
*RSX	RSX-11H-PLUS	RSX-11M/H+ BATCH AND QUEUE OPER MARUAL	2.1	AA-L671A-TC-001	2	NOV 83
*RSX	RSX-11M-PLUS	RSX-11M/H+ COMMAND LANGUAGE MANUAL	2.1	AA-L672B-TC-001	ć	NOV 83
≱ RSX	RSX-11H-PLUS	RSX-11H/H+ CRASH DUMP ANZ REF HANUAL	2.1	AA-L673B-TC-001	ï	NDV 83
*RSX	RSX-11M-PLUS	RSX-11H/H-PLUS ERROR LOGGING MANUAL	2.1	AA-L674B-TC-001	3	NOV 83
#RSX	RSX-11H-PLUS	RSX-11H/H-PLUS EXECUTIVE REFERENCE MANUAL	2.1	AA-L673A-TC-001	4	NOV 83
#R5X	RSX-11M-PLUS	RSX-11H/H+ GUIDE TO PROGRAM DEVELOPMENT	2.1	AA-L676A-TE-001	2	KOV 83
*RSX	RSX-11M-PLUS	RSX-11M-H-PLUS I/O DRIVERS REF dan (UPD#1)	2.1	AA-LUZ7A-TC-001	6	NDV 83
*RSX	RSX-11H-PLUS	RSX-11M-H-PLUS MCR OF MANUAL (UPD#1)	2.1	AA-L678A-TC-001	5	NOV 83
≭RSX	RSX-11H-FLUS	RSX-11M-M-PLUS SYSTEM MANAGEMENT GDE (UFD#1)	2.1	AA-L679B-TC-001	o	HOV 83
#RSX	RSX-11H-PLUS	RSX-11M-M-PLUS TASK BUILDER MANUAL	2.1	44-Lo808-TC-001	5	NOV 83
≱ RSX	RSX-11H-PLUS	RSX-11H/M-PLUS UTILITIES HANUAL (UPD#1)	2.1	AA-L681A-TC-001	6	NOV 33
*RSX	RSX-11h-PLUS	RMS-11: AN INTRODUCTION	2.1	AA-L682A-TC-001	1	NOV 83
#RSX	RSX-11h-PLUS	INTRODUCTION TO RSX-11H AND RSX-11H+	2.1	AA-L763A-TC-001	2	NOV 83

OPERATING SYSTEM	PRODUCT NAME	TITLE OF MANUAL	VERSION	PART HUMBER REV LEVEL	NUMBER OF FICHE	DATE
#RSX	RSX-11H-FLUS	IAS/RSX-11 I/O OPERATIONS REFERENCE MANUAL	2.1	AA-m176A-TC-001	3	NOV 83
≉ RSX	RSX-11M-FLUS	EDT EDITOR MANUAL	2.1	AA-M475A-TK-001	5	FEB 84
*RSX	RSX-11M-PLUS	EDT RUICK REFERENCE MANUAL	2.1	ан- в 477н-ТК-001	1	FEE 84
*RSX	RSX-11H-PLUS	IAS/RSX-11 ODT REFERENCE HANUAL	2.1	AA-H507A-TC-001	1	K6 V0N
*RSX	RSX-11M-PLUS	PDF-11 MACRO-11 LANGUAGE REFERENCE MANUAL	2.1	AA-V027A-TC-001	3	NOV 83
≉RSX	RSX-11H-FLUS	RSX-11M-FLUS V2.1 SFD 14.70.09	2.1	4E-H862J-TC-001	1	JUL 84
≭ RSλ	RSX-11H-PLUS	RSX-11M-PLUS V2.1 CROSS REFERENCE SPD	2.1	нЕ-M779I-TC-001	1	naY 84
#RSX	RSX-11h-FLUS	RSX-11M-PLUS HINI REFERENCE	2.1	AV-H435C-TC-001	3	NOV 83
*RSX	RSX-11M-PLUS	PDF-11 PROGRAMMING CARD	2.1	EH-S1046-78-001	1	NOV 83
≱ RSX	RSX-11S	RSX-11M/RSX-115 RELEASE NOTES	4.1	AA-2573H-TC-001	2	NOV 83
*RSX	RSX-11S	RSX-11h/RSX-11S INFORMATION DIRECTORY & INDEX	4.1	AA-2593G-TC-001	4	HOV 33
≭RSX	RSX-11S	RSX-11M GUIDE TO WRITING I/O DRIVER	4.1	AA-2600E-TC-001	3	KOV 83
*RSX	RSX-11S	RSX-118 SYS GEN/INSTL GDE (INCLUDES UFD#1)	4.1	AA-2874E-TC-001	2	NOV 83
#RSX	RSX-11S	IAS/RSX-11 SYS LIB ROUTINE REF HANUAL	4.1	AA-55808-TC-001	2	NOV 83
*RSX	RSX-11S	RSX-11H SYSTEM GENERATION/INSTALLATION GUIDE	4.1	AA-H3250-T0-001	5	NOV 83
≭ RSX	RSX-11S	RSX-11H/H+ CRASH DUMP ANZ REF MANUAL	4.1	AA-L6738-TC-001	3	NOV 83
*RSX	RSX-11S	RSX-11M/M-FLUS EXECUTIVE REFERENCE MANUAL	4.1	AA-L675A-TC-001	4	140V 83
*RSX	RSX-115	RSX-11H/H-FLUS GUIDE TO PROGRAM DEVELOPMENT	4.1	AA-L676A-TE-001	2	48V 83
*RSX	RSX-115	RSX-11M/N→ I/O DIRVERS REF HANUAL (UFD\$1)	4.1	6A-L677A-TE-001	.5	KBV 83
#RSX	RSX-11S	RSX-11H/H-PLUS HOR OPERATIONS MANUAL (UFD#1)	4.1	AA-L678A-TC-001	5	MBV 83
*RSX	RSX-11S	RSX-11H/H+ SYSTEM HANAGEMENT GUIDE (UPD#1)	4.1	AA-L679R-TC-001	0	NOV 83
*RSX	RSX-11S	RSX-11M/H-PLUS TASK BUILDER MANUAL	4.1	AA-L680B-TC-001	5	10V 83
*RSX	RSX-113	IAS/RSX-11 I/O OPERATIONS REFERENCE MANUAL	4.1	AA-M176A-TC-001	3	KOV 83
*RSX	RSX-11S	IAS/RSX-11 ODT REFERENCE MANUAL	4.1	##-#507#-TC-001	1	NOV 83
*RSX	RSX-11S	PDP-11 MACRO-11 LANGUAGE REFERENCE MANUAL	4.1	#A-V027#-10-001	3	HOV 93
*RSX	RSX-11S	RSX-11H/11S V4.1 UPDATE C INFORMATION	4.1	AA-W259C-TC-001	1	riAY 84

CONNERT SOFTWARE USEN

OPERATING SYSTEM	FRODUCT Name	TITLE OF MANUAL	VERSION	PART NUMBER REV LEVEL	NUMBER OF FICHE	DATE
*RSX	RSX-11S	RSX-11S V4.1 SPD 09.21.14	4.1	AE-34270-TC-001	1	MAY 84
≭RSX	RSX-11S	RSX-11H HINI REFERENCE	4.1	AV-5570E-TC-001	3	NOV 83
*RSX	RSX-11S	PDP-11 PROGRAMMING CARD	4.1	EH-S1046-78-001	1	NOV 83
#RSX	BASIC-FLUS-2 FOR RSX-11H/H-FLUS	BASIC+2 RSX-11H/M-PLUS INSTL GDE/REL NOTES	2.2	AA-0158F-TC-001	1	HAY 84
*RSX	BASIC-FLUS-2 FOR RSX-11M/M-FLUS	BASIC REFERENCE MANUAL (UFD\$1)	2.2	AA-L334A-TK-002	6	HAY 84
*RSX	RASIC-PLUS-2 FOR RSX-11H/H-PLUS	BASIC USER'S GUIDE (UPD#1)	2.2	AA-L335A-TK-002	3	nay 84
#RSX	BASIC-FLUS-2 FOR RCX-11H/H-PLUS	BASIC ON RSX-11h/h-PLUS SYSTEMS (UPD#1 & #2)	2.2	AA-L338A-TC-002	3	NAY 84
*RSX	BASIC-PLUS-2 FOR RSX-11M/M-PLUS	BASIC-PLUS-2 V2.2 SFD 14.11.11	2.2	AE-J197L-TC-001	1	JUL 84
*RSX	BASIC-PLUS-2 FOR RSX-11M/M-PLUS	BASIC FOCKET REFERENCE GUIDE	2.0-2.2	NV-L341A-TN-601	2	APR 83
≭RSX	BCF	BCP USER'S GUIDE	1.0	AA-H269B-TK-001	2	FEB 84
*RSX	BCF	BCF V1.0 SFD 14.72.0	1.0	AE-N202A-TC-001	1	FER 84
≭RSX	BCF	BCF V1.0 RELEASE NOTES	1.0	AV-N270B-TC-001	i	APR 83
*RSX	CHR11/CHV11 SOFTWARE DRIVER	CHR11/CHV11 SOFTWARE DRIVER USER'S GUIDE	3.0	AA-NO60B-TC-001	1	FER 84
*RSX	CHR11/CHV11 SOFTWARE DRIVER	CHR11/CHV11 SOFTWARE DRIVER REFERENCE MANUAL	3.0	AA-N061E-TC-001	1	FEE 84
*RSX	CMR11/CHV11 SOFTWARE DRIVER	CHR11/CHV11 V3.0 SPD 14.76.01	3.0	4E-N059E-TC-001	1	may 84
 ≰RSX	CHR11/CHV11 SOFTWARE DRIVER	CRM11/CHV11 SOFTWARE DRIVER RELEASE NOTES	3.0	AV-N058E-TC-001	1	FER 84
#RSX	COBOL-81/RSX	COBOL-81 LANGUAGE REFERENCE MANUAL	2.0	AA-J434B-TC-001	4	JAN 84
*RSX	COBOL-81/RSX	RSX-11h/m-PLUS USER'S GUIDE	2.0	AA-M179B-TE-001	5	JAN 24
#RSX	COBOL-81/RSX	RSX-11H/H-PLUS INSTALLATION/RELEASE NOTES	2.0	AA-M1818-TE-001	1	JAN 84
 #RSX	COBOL-81/RSX	COFOL-81 RSX V2.0 SPD 14.26.03	2.0	AE-F077E-TC-001	1	FEB 84
*RSX	COBOL-81/RSX	COROL-81 FOCKET GUIDE	2.0	AV-Ho30C-TC-001	2	JAN 84
*RSX	COMM TOP-DUP	CONN TOP-DUP PROGRAMMER'S MANUAL	1.0	AA-5670A-TE-001	1	SEP 82
*RSX	COMM IOP-DUP	COMM IOP-DUP RELEASE NOTES (INCLUDES UPINAL)	1.0	##-8367#-TC-001	1	SEP 82
#RSX	COMM IGP-INP	ADDENDUM TO SED	1.0	AE-BB27A-Th-001	1	may 84
*RSX	COMM IGF-DUF	COHH IOF-DUF V1.0 SFD 10.12.04	1.0	AE-D121E-TC-001	1	JUL 34
*RSX	COHM IOP-DZ	CONH IGF-DZ FROGRANMER'S MANUAL	1.0	AA-5127A-10-601	1	5EP 82

OPERATIN	G FRONUCT	TITLE OF		PART NUMBER REV	NUMBER OF	
SYSTEH	NAHE	HANUAL	VERSION		FICHE	DATE
*RSX	CONN IOP-IZ	COMM IOF-DZ RELEASE NOTES (INCLUDES UPI41)	1.0	AA-1308A-TC-001	1	3EF 82
*RSX	CONN IOP-DZ	ADDENDUM TO SPD	1.0	AE-BB27A-TN-001	1	hAY 64
*RSX	COMM IOF-DZ	COMM IDF-DZ V1.0 SFD 10.11.04	1.0	AE-D122E-TC-001	1	JUL 34
#RSX	CORAL-66	PDF-11 CORAL-66 V4.0 INSTL GDE/REL NOTES	4.û	AA-1744E-TC-001	1	APE 63
*R5X	CORAL-66	CORAL-66 LANGUAGE REFERENCE MANUAL	4.0	AA-01110-TN-001	2	AFR 83
*KSX	CORAL-66	RSX/VMS CORAL-66 USER'S GUDE	4.0	AA-B112C-TK-001	4	APR 83
*RSX	CORAL-66	CORAL-66 V4.0 SFD 14.56.10	4.0	AE-3450I-TC-001	1	MAY 84
#RSX	DATATRIEVE-11	DATATRIEVE-11 REFERENCE MANUAL	3.0	AA-U049A-TK-001	4	FEB 84
*RSX	DATATRIEVE-11	DATATRIEVE-11 CALL INTERFACE MANUAL	3.0	AA-U050A-TC-001	2	JAN 84
*RSX	DATATRIEVE-11	DATATRIEVE-11 GUIDE TO WRITING REPORTS	3.0	AA-U051A-TK-001	1	FEB 84
*RS	DATATRIEVE-11	DATATRIEVE-11 SUMMARY DESCRIPTION	3.0	AA-U052A-TC-001	1	JAN 84
*RSX	DATATRIEVE-11	DATATRIEVE-11 INSTALLATION ODE/REL NOTES	3.0	AA-X022A-TE-001	1	JAN 84
*R5X	DATATRIEVE-11	DATATRIEVE-11 USER'S GUIDE	3.0	AA-X023A-TN-001	3	FEB 84
≭RSX	DATATRIEVE-11	INTRODUCTION TO DATATRIEVE-11	3.0	AA-X025A-TN-001	1	FEB 34
≭ RSX	DATATRIEVE-11	DATATRIEVE-11 POCKET GUIDE	3.0	AA-X103A-TK-001	1	FEE S4
≭RSX	DATATRIEVE-11	DATATRIEVE-11 V3.0 SPD 12.48.12	3.0	AE-E777h-10-00.	1	JUL 84
*RSX	DATATRIEVE-11	DTR-11 COVER LETTER/BEFORE YOU INSTALL	3.0	AV-X024A-TE-001	1	JUL 34
#RSX	DBMS-11	DBMS-11/M+ DDL/DEVICE MEDIA CON LANG REF MAN	2.0-2.1	AA-H804B-IC-001	3	EEF 82
*RSX	NBMS-11	DBMS-11 DATA BASE ADMINISTRATOR'S (DBA) GUIDE	2.0-1.1	AA-H305F-T(-001	4	BEF 81
*RSX	DBMS-11	DBMS11 FORTRAN DATA MANIPULATION LANG REF MAN	2,0-2,1	AA-N8838-TC-001	2	SEP 82
*RSA	BBHS-11	DBhS11 COBOL DATA MANIFULATION LANG REF MAN	2.0-2.1	HA-N884E-TC-001	2	SEP 82
#RSX	DFMC-11	DBMS-11 INSTALLATION GUIDE	2.0-2.1	AA-K8858-TC-001	2	SEP 82
*RSX	DBhS-11	DEMS-11 V2.0 RELEASE NOTES	2.0-2.1	##-#889F-TC-001	1	SEP 82
*RSX	DBMS-11	USING THE DATATRIEVE-11/DBMS-11 INTERFACE	2.0-2.1	##-N867E-TC-001	1	SEP 82
*RSX	DBMS-11	DEMS-11 V2.1 SFD 12.66.2	2.1	RE-M130D-TC-001	1	FER S4
*RSX	DBMS-11	BEFORE YOU INSTALL DAMS-11 V2.1	7.1	4V-F666A-TC-001	1	AF'R 83

OPERATING	PRODUCT	TITLE OF		PART NUMBER REV	NUMBER. OF		
SYSTEM	NAME	narual	VERSION	LEVEL	FICHE	Į1)	ATE
≭R5 X	DECNE' 1.4	RSX DECNET GUIDE TO USER UTILITIES	4.0	AA-HIT30-TC-001	2	nåY	84
*RSX	DECNET-11H	FRX DECNET SYSTEM MANAGER'S GUIDE	4.0	AA-H224C-TC-001	5	hA!	84
*R5.(DECNET-11m	RSX DECHET NETWORK GEN AND INSTALLATION GUIDE	4.0	AA-H2250-T0-001	5	äĥī	54
≰ RSX	DECNET-11M	INTRODUCTION TO DECNET	4.0	AA-J055D-TK-001	3	náY	84
₽ R5λ	DECNET-11M	RSX DECNET POST-INSTL CHECKOUT PROCEDURES	4.0	AA-J3190-TN-001	1	7 *.	64
≱RSX	DECNET-11h	RSX DECNET RELEASE NOTES	4.0	AA-J517C-TC-601	1	äèï	84
#RGX	DECNET-11M	OVERVIEW OF REX DECNET	4.0	##-M0008-TC-001	3	nêr	84
*RSX	DECNET-11m	RSX DECNET PROGRAMMER'S REFERENCE MANUAL	4.0	AA-1 0988-TC-001	4	mai	84
*R5X	DECNET-11m	OVERVIEW TO DIGITAL HETWORK PROCEDURES	4.0	AA-X105H-TN-001	2	héĭ	94
#RSX	DECNET-11M	USERS/FROGRAMMERS MINI REFERENCE GUIDE	4.0	AA-X933A-TC-001	1	JUL	84
*RSX	DECNET-11m	DECNET RSX SYSTEM MANGER S MINI REF GUIDE	4.0	AA-X714A-TC-001	1	ПĤТ	63
#RSX	DECNET-11m	DECNET-11m V4.0 SFD 10.75.11	4.0	HE-3431L-TC-001	1	JUL	64
*RSX	DECNET-11m	DECNET-118 V4.0 SPD 10.74.10	4,1,	AE-3432m-18-001		0C T	64
#RSX	DECNET-11m	DECNET-11m+ V2.0 of D 10.00.05	4.0	4E-U513F-TC-001		OCT	84
*RSX	DECNET-11M	DECHET-RSX VOL 1 SPNST GENERAL INFORMATION	4.Û	AU-15024-16-001		130	64
#RSX	DECNET-11m	DECNET-RSX VOLUME II USER S INFORMATION	4.0	AU-1553A-TC-001		0CT	64
#RSX	DECNET-11m	* DECNET-RSX VOL 11 SEMST GENERAL INFORMATION	4.0	AV-15544-TC-061		OC Y	84
∦RSX	DECNET-11h	DECNET-RSX VOL IV SENST GENERAL INFORMATION	4.0	AV-1555A-TE-001		130	84
#RSX	DFM	DEN/DENT DECDATA INTELL SUBS USES GOE (UFD#1)	4.1	##-J5265-10-0u1	3	SEF	62
#RSX	DPH	DFM/DFM+ TERMIANL USER'S GUIDE (UPD#1)	4.1	AA-J530F-T0-001	2	SEF	82
≰RSX	DFM	DEN/DEM+ SYSTEM GENERATION/MANAGEMENT GOT	4.1	AH-J5316-16-001	4.	SEF	0_
#RSX	DFm	DFM/DFM FLUS RELEASE NOTES	4.1	##-:4150A-10-001	1	_EF	e2
≱R€X	DFM.	DFM V4.1 SFD 15.0.0	4.1	#E-373.H-To-6.1	i.	. []	34
*RSX	Df n	OFM/DFM FLUS REFERENCE GUIDE	4.1	AV-m195A-IC Jul	1	SEF	0.2
ARSX	DRU11-C RSX-11 DRIVER	DRU11-C RSX11m/ht SOFTWARE MANUAL	4.7	AA-W152A-11-001	1	JUL	84
*RSX	DRU11-C RSX-11 DRIVER	DRU11-E RSX SPD 13.35.00	4.2	AE-BP37A-TC-001	1	JUL	84

OPERATING SYSTEM	PRODUCT HAME	TITLE OF MANUAL	VERSION	FART NUMBER REV LEVEL	NUMBER OF FICHE	DATE
*RSA	UT07-11n	DT07-11h V1.1 USER'S GUIDE	1.1	AA-K566A-TC-001	1	SEP 82
#RSX	DT07-11ri	DT07-11H V1.1 SFD 14.36.1	1.1	AE-N534B-TC-001	1	FEB 84
#RSX	IX/11h	DX PRODUCTS PROGRAMMER'S REFERENCE MANUAL	3.1	AA-5469C-TC-001	1	APR 83
≭ RSX	DX/11#	DX PRODUCTS USER'S GUIDE	3.1	AA-5476B-TC-001	1	AFR 83
#RSX	DX/11H	DX/11m INSTALLATION GUIDE	3.1	AA-B997A-TC-001	1	AFR 83
#RSX	DX/11H	DX/11H VERSION 3.1 RELEASE NOTES	3.1	AA-H2888-TC-001	1	APR 63
*RSX	DX/11n	DX/11m V3.1 SFD 10.7c.4	3.1	AE-5274F-TC-001	1	FEB 84
#RSX	DX/11h	ADDENDUM TO SPU	3.1	HE-BE27H-TN-001	1	maY 84
#RSX	FMS-11/RSX	FDF11 KEYFAD EDITOR USER'S GDE (UFD\$1)	1.0	AA-H853A-10-001	2	SEP 82
4F:SX	FHS-11/RSX	FMS-11/RSX11M SOFTWARE REF MANUAL (UPD#1)	1.0	AA-H555A-T6-001	3	SEP 82
*RSX	F#S-11/RSX	FMS-11/RSX-11M RELEASE MOTES	1.0	AA-H857A-TC-001	1 h	SEP 82
#RSX	FHS-11/RSX	FDF11 KEYPAD EDITOR RELEASE NOTES	1.0	AA-USTTA-TC-001	1	SEP 82
*RSX	FriS-11/RSX	FMS-11/RSx V1.0 SPD 12.27.5	1.0	6E-J405F-TC-001	1	FEB 84
#RSX	FMS-11/RSX	PDF11 KEYFAD EDITOR REFERENCE CARD	1.0	AV-H854A-TC-001	1	3EF 82
*RSX	FHS-11/RSX	FMS-11/RSX-11M HINI REFERENCE GUIDE	1.0	AV-H850A-TC-001	1	SEP S2
#R5X	FORTRAN 1V/RSX	PDF-11 FORTRAN LANGUAGE REFERENCE MANUAL	2.ć	AA-R953A-TK-001	2	JAN 84
¥RSX	FORTRAN IV/RSX	RSX/VAS FORTRAN IV INSTALLATION/REL NTS	2.6	AA-R954A-TN-001	3	JAN 84
#RSX	FORTRAN IV/RSX	RSX/VAX/VHS FORTRAN IV USER'S GUIDE	2.6	AA-R955A-TK-001	2	JAN 84
*RSX	FORTRAN IV/RSX	FORTRAN IV/RSX V2.6 SFD 14.63.10	2.6	AE-3443N-TC-001	1	mAY 84
*RSX	FORTRAN-77 DEBUG, FDF-11	FDF-11 FORTRAN-77/DERUG USER'S GUIDE	1.0	AA-V197A-TK-001	2	JAK 84
*RSX	FORTRAN-77 DEBUG, FDF-11	FORTRAN-77/DEBUG INSTAL GUIDE/REL NOTES	1.Û	AA-X650A-TK-001	1	JAN 84
≱ RSX	FORTRAN-77 DEBUG, FDP-11	FDF-11 FORTEAN-77 DEBUG V1.0 SFD 30.33.00	1.0	AE-Y3988-TK-001	1	FEB 84
*RSX	FORTRAN-77/RSA, PDF-11	PDF-11 FORTRAN-77 LANGUAGE REFERENCE MANUAL	5.0	AA-V193A-TK-001	3	FEB 84
#RSX	FORTRAN-77/RSX, PDF-11	FOF-11 FORTRAN-77 USER'S GUIDE	5.0	AA-V194A-FK-001	3	FEE 84
*RSX	FORTRAN-77/RSX, PDP-11	PDP-11 ' IRTRAN-77 OTS REFERENCE HANUAL	5.0	AA-V195A-1K-001	2	FER 84
#RSX	FORTRAN-77/ESY, PDP-11	PDF-11 FORTRAN-77 INSTL GUIDE/REL NOTES	5.0	AA-V196A-TN-001	1	JAN 84

FART TITLE NUMBER MUNBER OPERATING PRODUCT OF SEU OF SYSTEM NAME HANUAL VERSION LEVEL FICHE DATE *RSX FORTRAN-77/RSX, PDF-11 FDF-11 FORTRAN-77/RSX V5.0 SFD 14.31.07 5.0 4E-J139H-TC-001 may 54 **#RSX** IEC-11H IEC-11M RSX SOFTWARE MANUAL AA-M275A-18-001 SEP 82 3.0 #RSX IEC-11m IEC-11M V3.0 SFB 14.64.0 3.0 AE-N029A-TC-001 1 FEB 34 #RSX IEC-11n 1EC-11M RELEASE NOTES AV-V507A-10-001 FER 84 3.0 185) IEX-RSX USERS & INSTALLATION GUIDE AA-S472A-FC-001 **OCT 84** IEX-RSX DRIVER 2.0 #RSX IEX-RSX DRIVER IEX-RSX DRIVER V2.0 SPD 12.66.01 2.0 AE-X682R-TC-001 JUL 84 #RSX KHE-11 TOOLS AME 11 FROGRAMMER'S MANUAL SEP 82 1.0 AA-5244E-TC-001 #F.SX KMC-11 TOOLS MHC-11 TOOLS VI.O SPD 12,49,04 1.0 AE-C776E-10-001 MAY 84 *RSX KMVII-A HOLD FRAMING SOFTWARE KMV11-A HOLE FRAMING SETWARE FOR RSX REF MAN AFR 83 1.0 AA-N5a5A-IC-001 1 #RSX KMV11-A HDLC FRAMING SOFTWARE FEB 84 KHV11A-HBLC FRAMING SOFTWARE V1.0 SFD 14.22.0 1.0 AE-R298A-16-001 1 #RSX LABORATORY SUBROUTINE PACKAGE LABORATORY SUB PROGRAMMER 5 REF MAN (UFD#1) AA-0994E-T0-001 1 SEF 82 #RSX LABORATORY SUBROUTINE PACKAGE AE-E627A-TK-001 1 ADDENDUM TO SPIN 1.2 MA1 84 **#RSX** LABORATORY SUBROUTINE PACHAGE LSP V1.2 SPD 15.44.06 1.2 AE-1007G-TC-001 MAY 34 #RSY HICROFOWER/FASCAL-RSX MP/P RSx-11m/m+ INSTALLATION GUIDE 1.5 AA-AK10A-10-001 JUL 84 #RSX hICROPOWER/FASCAL-RSX MF/P RSx-11m.m+ RELEASE NOTES 1.5 AA-AKIIA-IC-001 JUL 84 #RSX HICROPON' > FASCAL-RSX MF/F-RSX/VMS SYSTEM USER'S GUIDE 1.5 AA-AN13A-TN-001 JUL 84 #ESX MICROPOWER/PASCAL-RSX MF/F-RSX/VMS MESSAGES MANUAL 1.5 AA-AKI4A-IK-001 JUL 84 *RSX HICROFOWER/PASCAL-RSX INTRODUCTION TO MICROPOWER/FASCAL 1.5 4A-#3884-TC-001 JUL 64 #F:SX MICROFOWER/FASCAL-RSX mF/F LANGUAGE GUIDE (UFIL 11) 1.5 4A-M3690-T0-001 JUL 34 #R'SX HICROFOWER/FASCAL-RSX MF/F-RT RUNTIME SERVICE MANUAL (UPD 11) 1.5 44-M3918-TE-001 JUL 84 #RSX MICROPOWER/FASCAL-RSX MF/F DERUGGER USER S GUIDE (UFD41) 1.5 4A-M393E-18-00: JUL 84 #RSY HICROPOWER/FASCAL-RSX PDF-11 MACRO-11 LANGUAGE REFERENCE MANUAL 1.5 AA-V0274-10-001 JUL 84 *RSX MICROPOWER/FASCAL-SSX KXT11-C SOFTWARE USER 5 GUIDE 1.5 AA-10154-18-001 JUL 84 #RSX MICROFOWER/FASCAL-RSX MF/F RSX SFT 14.83.00 1.9 AE - Et 294-10-001 JUL 84 #REX HICROPOWER/PASCAL-RSX 1.5 JUL 34 MEZE REFERENCE CAFD AV-H395A-10-001 #ESX HICROPOWER/FASCAL-RSX PDF-11 FROGRAMMING CARD 1.5 LH-S1045-78-001 1 JUL S4

OPERATING SYSTEM	PRODUCT NAME	TITLE OF MANUAL	VERSION	FART MUMBER REV LEVEL	NUMBER OF FICHE	DATE
*RSX	MUX200/RSX-IAS	MUX200/RSX-IAS V2.1 RELEASE NOTES	2.1	A4-13430-TC-001		JAN 84
≉ RSX	HUX200/RSX-1A5	HUX200/RSX-IAS SYSTEM MANAGER GUIDE	2.1	AA-1344C-TC-001		JAN 84
#RSX	HUX200/RSX-IAS	MUX200/RSX-IAS USER'S GUIDE	2.1	AA-13450-TC-001	1	JAN 84
*RSX	HUX200/RSX-IAS	MUX200/RSX-IAS V2.1 SFT 10.77.07	2.1	AE-34531-TC-001	1	FER 84
*RSX	OBSERVER	OBSERVER INSTL GUIDE AND GEN GUIDE	1.1	AA-N759B-TC-001		FEE 84
#RSX	ORSERVER	OFSERVER USER'S GUIDE	1.1	AA-N960E-TE-001		FEB 84
*RSX	OBSERVER:	OBSERVER RELEASE NOTES	1.1	AA-N9626-TE-001	1	FEB 84
#RSX	OBSERVER	OBSERVER EVENT MESSAGE REFERENCE MANUAL	1.1	AA-X074A-TE-001	2	JUL 84
#RSX	OBSERVER	OBSERVER V1.1 SFD 13.18.02	1.1	AE-P335C-TC-001	1	may 84
#RSX	OBSERVER	OBSERVER REFERENCE CARD	1.1	AV-X073A-TC-001	1	FER 84
*RSX	PASCAL/RSX, PDF-11	FDF-11 PASCAL LANGUAGE REF MANUAL (UFF#1)	1.1	#A-#875A-T0-002	2	FEB 84
#RSX	FASCAL/RSX, FDF-11	FUF-11 PASCAL USER'S GUIDE (UPD#1)	1.1	AA~M876A-TC-002	2	FEE 84
#RSX	FASCAL/RSX, PDF-11	PDF-11 FASCAL INSTALLATION GDE/REL NOTES	1.1	A4-M877B-TC-001	1	MAY 34
*RSX	FASCAL/RSX+ FIF-11	FDF-11 PASCAL/RSX V1.1 SFD 14.18.03	1.1	At-N9171-TC-00.	1	may 84
*RSX	FDF-11 COBOL	FIF-11 COROL INSTALLTION GUIDE	4.4	AA-1745F-TC-061	1	SEP 32
#RSX	FDF-11 COBOL	PIPI1 COEGL LANS REF MANUAL (UFI#1 % #2)	4.4	AA-1749E-TC-001	3	SEF 82
*RSX	FUF-11 COBOL	PDF-11 COROL USER'S GUIDE (INCLUDES UFD#1)	4.4	AA-1757E-TC-001	6	SEP 82
*RSX	FDF-11 COROL	FDF-11 COROL V4.4 SFD 12.40.18	4.4	AE-3417S-TC-001	1	FER 84
‡ ŘSX	PLXY-11M	FLXY-11 USER'S GUIDE	1.3	AA-JS35F-TK-001	1	nAY 84
*RSX	FLXY-11H	PLXY-11 V1.3 SFD 14.39.01	1.3	AE-8797F-TC-001	1	may 84
*RSX	PROFESSIONAL HOST COMMUNICATIONS	PROFESSIONAL HOST COMM INSIL PROCEDURES	1.7	RA-F412E-TK-001	1	haY 84
*RSX	PROFESSIONAL HOST TOOL KIT	THS FROGRAMMER'S MANUAL	2.0	AA-AD34A-TH-001		081 84
#RSX	PROFESSIONAL HOST TOOL NIT	PRO/DECNET IN PROGRAMMER'S REFERENCE MANUAL	2.0	##-#V69#-TN-001	3	JUL 84
*RSX	PROFESSIONAL HOST TOOL KIT	PRO/DECNET TOOL KIT INSTALLATION GUIDE	2.0	AA-AV70A-TK-001	1	JUL 54
*RSX	PROFESSIONAL HOST TOOL NIT	GUIDE TO WEITING F/OS I/O DRIVER	2.0	AA-ET73A-TH-001		OCT 84
*RSX	PROFESSIONAL HOST TOOL KIT	PRO TOOL NIT REFERENCE MANUAL	2.0	AA-BT74A-TH-001		001 84

Fase 10

OPERATING SYSTEM	PROI NAM		TITLE OF HANUAL	VERSION	PART Number Rev Level	NUMBER OF FICHE	PATE
*RSX	PROFESSIONAL HOST	TOOL KIT	FMS-11/RSX SOFTWARE REFERENCE MANUAL	1.0-2.0	AA-H355A-T0-001	3	APR 83
∔RSX	FROFESSIONAL HOST	TOOL KIT	FHS-11/RSX RELEASE NOTES	1.0-2.0	AA-H8574-TC-001	1	APR 83
#RSX	FROFESSIONAL HOST	TOOL KIT	INTRO TO DECNET PHASE IV	2.0	AA-J0550-IN-001		DCT 84
*RSX	FROFESSIONAL HOST	TOOL KIT	RSX/RMS USER'S GUIDE	1.0-2.0	AA-L669A-TC-001	2	MAY 84
*RSX	PROFESSIONAL HOST	TOOL NIT	RSX-11M/M-PLUS RMS-11 UTILITIES MANUAL	1.0-2.0	AA-L670A-TC-001	3	may 84
*RSX	FROFESSIONAL HOST	TOOL KIT	RSX-11M/M-FLUS TASK BUILDER MANUAL	1.0-2.0	AA-L680B-TC-001	5	JAN 84
*RSX	FROFESSIONAL HOST	TOOL NIT	IAS/RSX-11 OUT REFERENCE MANUAL	1.0-2.0	AA-m507A-TC-001	1	AFR 83
#RSX	PROFESSIONAL HOST	TOOL KIT	F/DS SYSTEM REFERENCE MANUAL (UFD\$2)	1.0-2.0	AA-N620A-TK-002	4	JUL 84
*RSX	PROFESSIONAL HOST	TOOL KIT	DOCUMENTATION GUIDE LINES	1.0-2.0	AA-N621A-TK-001	1	APR 83
*RSX	PROFESSIONAL HGST	TOOL KIT	TERMINAL SUBSYSTEM MANUAL	1.0-1.0	AA-N623E-IN-001	2	JAN 84
*RSX	PROFESSIONAL HOST	TOOL KIT	PRG/RHS-11: AN INTRODUCTION	1.0-2.0	#A-P098A-TN-001	1	APR 83
*RSX	FROFESSIONAL HOST	TOOL KIT	FRO/RMS-11 MACRO FROGRAMMER'S GUIDE	1.0-2.0	AA-F099A-TN-001	5	AFR 93
*RSX	PROFESSIONAL HOST	TOOL KIT	PRO/FMS-11 DOCUMENTATION SUPPLEMENT	1.0-2.0	4A-F103B-TK-001	i.	JAN 84
#RSX	PROFESSIONAL HOST	TOOL KIT	IAS/RSX OUT REFERENCE MANUAL SUFFLEHENT	1.0-2.0	AA-F1938-TN-001	1	JAN 84
#RSX	PROFESSIONAL HOST	TOOL KIT	FDP-11 MACRO-11 LANGUAGE REFERENCE MANUAL	1.0-2.0	44-V0274-TC-001	3	JAN 34
#RSX	PROFESSIONAL HOST	TOOL KIT	FRO/TOOL KIT INSTALLATION GUIDE/RELEASE NOTES	2.0	AA-X911B-TH-001	1	JUL 84
*RSX	FROFESSIONAL HOST	TOOL KIT	PRO/TOOL NIT COMMAND LANG/UTILITIES MANUAL	1.0-2.0	AA-X912A-TH-001	5	mAY 34
4RSX	PROFESSIONAL HOST	TOOL KIT	FRO GIDIS MANUAL (UFD#1)	2.0	AA-Y630A-TH-001		OCT 84
#RSX	PROFESSIONAL HOST	TOOL NIT	PRO/TOOL KIT V2.0 SFD 40.19.01	2.0	BH-1771F-TH-001		OCT 84
#RSX	FROFESSIONAL REAL	TIME INTERFACE LI	PRTIL RELEASE NOTES	1.1	AA-AI40C-TH-001		OCI 84
#RSX	PROFESSIONAL REAL	TIME INTERFACE LI	PRIIL PROMES REFERENCE MANUAL	1.1	AA-F411A-TN-001	3	JUL 84
*RSX	PROFESSIONAL REAL	TIME INTERFACE LI	ADDENDUM TO SPD	1.1	AE-BE27A-TK-001	1	JUL 84
*RSX	PROFESSIONAL REAL	TIME INTERFACE LI	FRO/TN FFTIL V1.1 SFD 40.35.01	1.1	AE-BLESF-TH-001		061 84
#RSX	PROFESSIONAL TOOL	KIT BASIC-PLUS-2	BASIC REFERENCE MANUAL (UFD \$1)	2.2	AA-L334A-TK-002	ć	mA/ 84
*RSX	FROFESSIONAL TOOL	KIT BASIC-PLUS-2	BASIC USER S GUIDE (UPD41)	2.2	AA-L335A-TN-002	3	m4Y 84
*RSY	PROFESSIONAL TOOL	KIT BASIC-FLUS-2	BASIC ON RSX-11m/h-FLUS SYSTEMS (UPD#1 % #2)	2.2	AA-L338A-10-002	3	MAY 84

OPERATING SYSTEM		PRODUCT		TITLE OF MANUAL	VERSION	PART NUMBER REV LEV E L	NUMBER OF FICHE	OATE
	050550010000	_	T. 10 TO 10 O					
*RSX	FROFESSIONAL	100F KII	BASIC-PLUS-2	BASIC-PLUS-2 DOCUMENTATION SUPPLEMENT	2.2	AA-F102C-TK-001	1	nAY 84
*RSX	PROFESSIONAL	TOOL KIT	BASIC-FLUS-2	PRO TOOL AIT BASIC-FLUS-2 V2.2 SFD 30.27.03	2.2	AE-F650D-TK-001	1	JUL 84
*RSX	PROFESSIONAL	TOOL KIT	BASIC-FLUS-2	BASIC POCKET REFERENCE GUIDE	2.0-2.2	AV-L341A-TN-001	2	AFR 83
#RSX	PROFESSIONAL	TOOL KIT	COBOL-81	COBOL-81 LANGUAGE REFERENCE MANUAL	2.1	AA-J4345-TC-001	4	MAY 84
*RSX	PROFESSIONAL	TOOL KIT	COBOL-81	RSX-11m/m-PLUS USER'S GUIDE	2.1	AA-m179B-TC-001	5	mAY 84
*RSX	FROFESSIONAL	TOOL KIT	COBOL-81	FRO TOOL KIT COROL-81 INSTL GRE/DOC SUPL	2.1	AA-Y285A-TH-001	1	JUL 94
*RSX	PROFESSIONAL	TOOL KIT	C090L-81	FRO TOOL KIT COROL-81 V2.1 SFD 40.24.00	2.1	AE-Z764A-TH-001		OCT 84
#RSX	PROFESSIONAL	TOOL KIT	COROL-81	COBOL-81 POCNET GUIDE	2.1	AV-H630C-TC-001	2	MAY 84
*RSX	PROFESSIONAL	TOOL KIT	DIFOL	DIBOL FOR BEGINNERS	1.0	AA-B177A-TK-001	1	JUL 84
#RSX	PROFESSIONAL	TOOL KIT	DIROL	INTRODUCTION TO DIFFOL	1.6	AA-FG42B-TN-G01	1	JUL 84
*RSX	FROFESSIONAL	TOOL KIT	PIPOL	PROFESSIONAL TOOL NIT DIFFOL USER'S GUIDE	1.6	AA-P043C-TK-001	2	hay 84
*RSX	FROFESSIONAL	TOOL KIT	DIROL	FROFESSIONAL TOOL KIT DIROL REL HTS/INSTE GDE	1.6	AA-F045C-TN-001	1	MAY 84
#RSX	PROFESSIONAL	TOOL KIT	DIBOL	DIBOL-83 LANGUAGE REFERENCE MANUAL (UPD#1)	1.0	AA-U066A-Th-001	2	FEF 84
#RSX	PROFESSIONAL	TOOL KIT	DIBOL	DIBOL-83 COMPATIBILITY MANUAL	1.6	AA-V810R-TK-001	1	MAY 84
*RSX	PROFESSIONAL	100L KIT	DIPOL	PRO TOOL KIT MESSAGE MANUAL	1.6	AA-2515A-TK-001	1	FEE 84
*RSX	FROFESSIONAL	TOOL KIT	DIBOL	DIBOL-83 LANGUAGE REFERENCE CART	1.6	AV-U067A-TK-001	1	JUL '64
*RSX	FROFESSIONAL	100L KIT	FORTRAN-77	FRO HOST IN F-77 1G/DOC SUPL	5.0	AA-R387F-TX-001	1	JAN 84
*RSX	PROFESSIONAL	TOOL KIT	FORTKAN-77	FUP-11 F-77 LANGUAGE REFERENCE MANUAL	5.0	AA-V193A-TN-001	3	FEB 81
*RSX	PROFESSIONAL	TOOL KIT	FORTRAN-77	PDP-11 FORTRAN-77 USER'S GUIDE	5.0	AA-U194A-TK-001	3	FEB SA
*RSX	PROFESSIONAL	TOOL KIT	FORTRAN-77	PIP-11 FORTRAN-77 OTS REFERENCE MANUAL	5.0	AA-V195A-TK-001	2	FEE E4
*RSX	PROFESSIONAL	TOOL KIT	FORTRAN-77	FRO TOOL KIT FORTRAN-77 V5.0 SPD 30.36.02	5.0	4E-W5870-TK-001	1	JUL 84
*RSX	PROFESSIONAL	TOOL KIT	FORTRAN-77 DE	PRO TOOL KIT FORTRAN-77/DBG IG/DGC SUPL	1.0	AA-Z384A-TK-001	1	m41 84
#RSX	PROFESSIO all	100F K11	FORTRAN-77 DB	FRO TOOL NIT FORTRAN-77/DEG V1.0 SEB 40.25.00	1.0	AE-2847A-TH-001	1	JUL 34
*RSX	PROFESSIONAL	TOOL KIT	FASCAL	PRO TOOL KIT PASCAL INSTL GDE/RELEASE NOTES	1.2	AA-E759C-TN-001	1	JUL 84
*RSX	PROFESSIONAL	TOOL KIT	PASCAL	FRO TOOL KIT PASCAL USER'S GUIDE	1.1-1.2	AA-U045A-TN-001	2	JAN 84
#RSX	PROFESSIONAL	TOOL KIT	PASCAL	FRO TOOL NIT PASCAL LANGUAGE REFERENCE MANUAL	1.1-1.2	AA-U047A-IN-001	2	JAN 84

OPERATING SYSTEM	FRODUCT Name	TITLE OF MANUAL	VERSION	PART NUMBER REV LEVEL	NUMBER OF FICHE	DATE
*RSX	RGL-11	RGL-11 PROGRAMMER'S REFERENCE MANUAL	1.1	AA-M837A-TC-001	3	AFR 83
#RSX	RGL-11	RGL-11 INSTALLATION GUIDE	1.1	AA-M818A-TE-001	1	AFR 83
≉ RSX	RGL-11	RELEASE NOTES FOR RGL-11	1.1	AA-m8395-TC-001	1	FER 84
≭ RSX	RGL-11	RGL-11 V1.1 SPN 14.62.04	1.1	AE-M802E-TC-001	1	MAY 64
#RSX	RSX 11 2780/3780 EMULATOR	RSX-11 2780/3780 EMULATOR USER'S GUIDE	4.1	AA-J581A-TC-001	1	SEF 82
≭ RSX	RSX 11 2780/3780 EMULATOR	RSX11 2780/3780 EMUL V4.1 SPD 10.01.02	4.1	AE-K997C-TC-001		OST 84
#RSX	RSX 11 FSI/H	INTRODUCTION TO RSX-11 FS1	2.0	A4-H369A-T0-001	1	SEP 82
#RSX	RSX 11 FSI/M	RSX-11 FSI SYSTEM MANAGER'S GUIDE	2.0	AA-M370A-TE-001	3	SEP 82
#RSX	RSX 11 FSI/M	RSX-11 PSI USER'S GUIDS	2.0	AA-m371A-TC-001	2	SEP 82
#RSX	RSX 11 PSI/M	RSX-11 FSI GENERATION GUIDE	2.0	AA-M372A-TC-001	2	SEP 62
#R5X	RSX 11 FSI/h	RSX-11 PSI NETWORK SPECIFIC INFORMATION	2.0	AA-m373A-TE-001	1	SEP 82
*RSX	RSX 11 FSI/M	RSX-1: PSI RELEASE NOTES	2.0	AA-M374A-TC-001	1	SEP 82
*RSX	RSX 11 PSI/H	RSX-11 FSI/m V2.0 SFD 10.42.0	2.0	AE-N1418-TE-001	1	FEB 84
#R5X	RSX 11 FSI/M	RSX-11 PSI REFERENCE CARD	2.0	AV-n749A-TE-001	1	SEP 82
4RSX	RSX 11/FROVUE	PROVUE SYSTEM MANAGER S GUIDE	2.0	AA-M0218-TN-001	1	JAN 84
*RSX	RSX 11/FROVUE	PROVUE SYSTEM BUILD MANUAL	2.0	AA-M022E-Th-001	1	JAN 84
*RSX	RSX 11/FROVUE	PROVUE TERMINAL USER'S GUIDE	2.0	AA-m023B-TN-001	1	JAN 84
*RSX	RSX 11/FROVUE	PROVUE OFFLINE PICTURE SYSTEM MANUAL	2.0	AA~h024E-TK-001	1	JAN S4
*RSX	RSX 11/PROVUE	PROVUE ONLINE PICTURE SYSTEM MANUAL	2.0	AA-MO2SB-TN-001	1	JAN 84
#RSX	RSX 11/PROVUE	PROVUE PROGRAMMING GUIDE	2.0	AA-M026E-TH-001	1	JAN 84
#RSX	RSX 11/PROVUE	PROVUE UTILITY GUIDE	2.0	AA-M027B-TK-001	1	JAN S4
#RSX	RSX 11/PROVUE	PROVUE V2.0 RELEASE NOTES	2.0	AA-MQ898-TK-001	1	JAR 84
#RSX	RSX 11/PROVUE	PROVUE V2.0 SPD 14.33.1	2.0	AE-N271B-TC-001	1	FEB 84
≉ RSX	RSX 11H 3271 PROTOCOL EMULATOR	RSX-11/3271 FE PROGRAMMER'S GUIDE	3.0	AA-0739E-10-001	2	AFF. 83
*RSX	RSX 11H 3271 PROTOCOL EMULATOR	RGX-11/3271 PE SYSTEM MANAGER S GUIDE	3.0	AA-07390-70-001	**	AFR 83
#RSX	RSX 11M 3271 PROTOCOL EMULATOR	RSX-11/3271 FE RELEASE NOTES V3.0	3.0	AA-H0320-TC-001	1	APR 83

OPERATING SYSTEM	TOUDERA MAN	TITLE OF MANUAL	√ERS10N	PART NUMBER REV LEVEL	NUMBER OF FICHE	DAJE
*RSX	RSX 11m 3271 PROTOCOL EMULATOR	3270 TERMINAL EMULATOR NEYFOARD LAYOUT	3.0	AV-F07SA-TE-061		APR 83
#RSX	RSX 11H F ENHANC PNG FOR MINC	SCIENTIFIC SUBROUTINES PROG REF MAN (UPD#1)	1.1-1.2	AA-1101E-TE-001	2	AFR 83
*FSX	RSX 11M F ENHANC PKG FOR MINC	LAB SUBROUTINES PROG REF MAN (UFD#1)	1.1-1.2	AA-69846-16-001	3	APR 83
4RSX	RSX 11H F ENHANC PKG FOR MINC	REALIIM/MNC FORTTRAN PROG REF MAN (UF[041+2)	1.1-1.2	##-{#0310-TE-001	4	AFR 83
#RSX	RSX 11h F ENHANC PING FOR MINE	INTRODUCTION TO FEE AND FRE	1.1-1.2	AA-J3028-TC-001	1	49R 83
4RSX	RSX 11H F ENHANC PNG FOR HINC	RSX-116 FEF AND FRE INSTALLATION, USAS ODE	1.2	AA-J3030-TC-001	2	JAN 84
*RSX	RSX 11h F ENHANC PAG FOR MINC	RELEASE NOTES FOR REX-11m/FEF AMT FOR	1.7	AA-#055D-TE-001	1	JAN 34
#RSX	RSX 11H F ENHANC PNG FOR HINC	RGL/11 PROGRAMMER'S REFERENCE MANUAL	1.1-1.2	44-m8374-TC-001	3	AFF 63
*RSX	RSX 11m F ENHANC PNG FOR mINE	RSx-11M/FEF V1.2 SFI 14.44.4	1	AE-L702E-TL-001	1	FEB 84
#RSX	RSX 11m F ENHANC PRG FOR MINC	RGL/11 PROGRAMMERS REFERENCE MANUAL ERRATA	1.2	AU-V1854-TC-001	9	JAN E4
#RGX	RSX 11m F ENHANC PING FOR mINE	REAL-11 PROGFAMMERS REFERENCE MANUAL EFRATA	1.1	AV1974-TC-001	1	JUL 84
#RSX	RSX 11m F ENHANC PNG FOR mINC	SSP REFERENCE MANUAL ERRIATA SHEET	1.7	AV-91674-Tu-001	1	JAN E4
#RSX	RSx 11M F ENHANC FNG FOR minc	LSP REFERENCE MANUAL ERRATA SHEET	1.7	AV-V196A-TC-201	1	JAN 34
¢ RSX	RSX 11m F ENHANC FING FOR MINC	INTRO TO FER & FRE ERRATA SHEET	1.7	AV-V1914-10-001	1	JAN 64
4RSx	RSX 11H F ENHANC PAG FOR HINC	MICROCOMPUTERS AND MEMORIES HANDEROOK	1.1-1.2	E8-10917-20-001	3	APF 83
#RSX	RSX 11M F ENHANC FKG FOR MINE	PIP-11 HICROCOMPUTER INTERFACES HAMDBOOK	1.1-1.2	EF-23144-18-001	7	APR 83
#RSX	RSX 11h F ENHANC PNG FOR HINC	DECLAR-11, HINC USER S GUIDE	1.1-1.2	EN-MNC11-UG-001		APR 83
TRSX	RSX 11M F ENHANC FMG FOR HINC	MINC THERMOCOUPLE PREAMPLIFIER USER'S GUIDE	1.1-1.2	EN-MACTF-UE-UC1	1	AFR 83
1RSX	RSX 1 4 IAS RJE/HASF	RUE/HASP WORMSTATION INSTALLA: ION GUIDE	1.1	44-5405[-10-0]	1	JUL 34
#RSX	RSX 11m IAS RJE/HASP	RUE/HASE WORNSTATION OPERATOR S GUIDE	1.1	44-5417D-TC-101	1	JUL 84
*RSX	RSX 11m IAS RUE/HASE	RSX11m IAS RUE/HASP VI.1 SPE 10.51.5	1.1	AE-52466-FC-001	1	FEB 84
#RSX	RSA 11M FLUS DECTYPE	DECTIFE REFERENCE MANUAL	3.0	44-F124B Th-001		الله عالله
*RSX	RSX 11m SNA PE	RSX11m/SNA PE CONCEPTS AND FACILITIES (UPD41	1.1	AA-55014-TU-001	٨	SEF 82
#RSX	RSX 11H SNA FE	RSX11m/SNA PE S/STEM MANAGER'S GUILLE (UFL)#1+	1.1	AA-5502A-TC-001	2	SEP 82
*RSX	RSX 11m SNA PE	RSX11M/SNA PE APPLICATIONS PROGRAMMER S GUIDE	1.1	AA-5503B-TC-001	As .	5EF 8.
#RSX	RSX 11H SNA PE	RSX11M/SNA PE RELEASE NOTES (UFII4)	1.1	AA-US49A-TC-001	1	SEF 82

OPERATING SYSTEM	PRODUCT NAME	TITLE OF MANUAL	VERSION	PART NUMBER REV LEVEL	NUMBER OF FICHE	PATE
*RSX	RSX 11M SNA PE	RSX 11M SNA PE V1.1 SPD 14.04.1	1.1	AE-J512C-TE-001	1	FEB 84
*RSX	RSX DLX-11	RSX DLX-11 USER'S GUIDE	1.0	AA-K142A-TC-001	2	SEF 82
*RSX	RSX DLX-11	RSX DLX-11 RELEASE MOTES	1.0	AA-K143A-TC-001	1	SEP 32
#RSX	RSX DLX-11	RSX DLX-11 V1.0 SFD 10.6.0	1.0	AE-K4348-TC-001	1	FEE 84
*RSX	RSX MDE/T11	MDE/T-11 USER'S GDE/REF MANUAL	1.0	AA4845E-TN-001	3	AFR 83
#RSX	RSX HDE/T11	RSX11H/H+ HRE/T11 SETW INSTL GDE/REL NTS	1.0	AA-N998A-TC-001	1	APR 83
#RSX	RSX MDE/T11	RSX HDE/T-11 V1.0 SPD 14.23.0	1.0	AE-F081B-TC-001	ī	FEB 84
#R5X	RSX MDE/T11	MDE/T11 REFERENCE CARD	1.0	AV-M846F-TN-001	1	FEB 84
1RSX	RSX MBE/T11	MDE/T-11 V1.0 INSTE GDE/REE HTS	1.0	AV-F511A-TE-601	1	APR 83
#RSX	RTEH-11	RTEK-11 USER'S GUIDE	2.0	AA-N435E-TK-001	2	MAY 84
*RSX	RTEm-11	RTEM-11 INSTALLATION GUIDE	2.0	AA-N436B-TK-001	1	MAY 64
#RSX	RTEH-11	RTEM-11 RELEASE NOTES	2.0	AA-W325A-TK-001	1	HAY 84
#RSX	RTEM-11	RTEM-11 V2.0 SFD 30.21.04	2.0	AE-N5/1E-TN-001	1	HAY 84
*RSX	SORT-11	PRF-11 SORT/MERGE USER'S GUILLE	3.0	AA-0167A-10-001	2	JUL 64
#RSX	SORT-11	SORT-11 V3.0 SFD 12.07.07	3.0	AE-5429H-TC-001	1	JUL 84
#RSX	SSF-11	SCIENTIFIC SUB PROGRAMMER'S REF MAN (UFD#1)	1.3	AA-1101D-TC-001	2	SEF 82
*RSX	SSF-11	SSF-11 V1.3 SF0 15.45.10	1.3	AE-34131-TC-001	1	hAY 84
#RSX	3SF-11	ADDENDUM TO SED	1.3	AE-BE27A-TK-001	1	MAY 84
*RSX	UN1004	UN1004/RSX RELEASE NOTES	2.0	AA-13416-TC-001	1	SEP 82
*RSX	UN1004	UN1004/RSX USRS GDE/SYS GEN GDE (UFD#1)	2.0	AA-1342B-TE-001	1	SEP 82
*RSX	UN1004	UN1004 V2.0 SPD 10.79.06	2.0	AE-34546-TC-001	1	FEB 84
#RSX	VSV11-M DRIVER	VSV11-M SOFTWARE DRIVER GUIDE	2.2	AA-U287E-TK-001	1	JUL 84
*RSX	VSVII-M DRIVER	VSV11-H V2.2 SPD 14.53.34	2.2	AE-N851A-TC-001	1	JUL 84
*RSX	VTV31-K RSX11M DRIVE/SUB FKG	VIV31-K/RSX DEVICE DRV AND SUBROUTINE LIBRARY	1.0	AA-M809A-TC-001	1	APR 83
*RSX	VTV31-K RSX11M DRIVE/SUB FKG	VTV31-K/RSX V1.0 SPD 14.73.0	1.0	AE-F079A-TC-001	1	FER 84
RSX	RSX-11M	EBT EDITOR MANUAL	4.1	AA-J726A-TC-001	3	MON 82

RSX RSX-11H RSX-11H V4.1 SFD 14.35.20 4.1 AE-3407U-TC-001 1 RSX RSX-11H EDT EDITOR REFERENCE CARD 4.1 AV-J756A-TC-001 1 RSX RSX-11H-PLUS EDT EDITOR MANUAL 2.1 AA-J726A-TC-001 3 RSX RSX-11H-PLUS RSX-11H-PLUS V2.1 SFD 14.70.08 2.1 AE-H862I-TC-001 1 RSX RSX-11H-PLUS EDT EDITOR RYFERENCE CARD 2.1 AV-J756A-TC-001 1 RSX RSX-11S RSX-11H/11S V4.1 UPDATE B INFORMATION 4.1 AA-W259B-TC-001 1 HSX RSX-11S RSX-11S V4.1 SFD 9.21.13 4.1 AE-3427N-TC-001 1	FEB 84 NOV 83 NOV 83 FEB 84 NOV 83 FEB 84 FEB 84 JAN 84
RSX RSX-11M-PLUS EDT EDITOR MANUAL 2.1 AA-J726A-TC-001 3 RSX RSX-11M-PLUS RSX-11M-PLUS M2.1 SFD 14.70.08 2.1 AE-H862I-TC-001 1 RSX RSX-11M-PLUS EDT EDITOR REFERENCE CARD 2.1 AV-J756A-TC-001 1 RSX RSX-11M-PLUS RSX-11M/11S V4.1 UPDATE B INFORMATION 4.1 AA-W259B-TC-001 1	NOV 83 FEB 84 NOV 83 FEB 84 FEB 84
RSX RSX-11M-PLUS RSX-11M-PLUS M2.1 SFD 14.70.08 2.1 AE-H862I-TC-001 1 RSX RSX-11M-PLUS EDT EDITOR REFERENCE CARD 2.1 AV-J756A-TC-001 1 RSX RSX-11S RSX-11M/11S V4.1 UPDATE B INFORMATION 4.1 AA-W259B-TC-001 1	FEB 84 NOV 83 FEB 84 FEB 84
RSX RSX-11M-PLUS EDT EDITOR REFERENCE CARD 2.1 AV-J756A-TC-001 1 RSX RSX-11S RSX-11M/11S V4.1 UFDATE B INFORMATION 4.1 AA-W259B-TC-001 1	NOV 83 FEB 84 FEB 84
RSX RSX-115 RSX-11H/11S V4.1 UPDATE B INFORMATION 4.1 4A-W259B-TC-001 1	FEB 84
	FER 84
RSX-11S RSX-11S V4.1 SFD 9.21.13 4.1 AE-3427N-TC-001 1	
	JAN B4
RSX BASIC-PLUS-2 FOR RSX-11H/H-FLUS RESIC+2 RSX-11H/H-FLUS INSTL GDE/REL NOTES 2.1 AA-0158E-TC-001 1	
RSX BASIC-PLUS-2 FOR RSX-11H/H-PLUS BASIC REFERENCE MANUAL 2.0-2.1 AA-L334R-TK-601 6	APR 83
RSX BASIC-PLUS-2 FOR RSX-11H/H-PLUS BASIC USER S GUIDE 2.0-2.1 AA-L335A-TK-001 3	APR 83
RSX BASIC-PLUS-2 FOR RSX-11H/H-PLUS BASIC ON RSX-11H/H-PLUS SYS (5 (UPD#1) 2.1 AA-L338A-TC-001 3	JAN 84
RSX BASIC-PLUS-2 FOR RSX-11H/H-PLUS BASIC-PLUS-2 V2.1 SPI-14.11.8 2.1 AE-J197I-TC-001 1	FEB 84
RSX BASIC-PLUS-2 FOR RSA-11H/H-PLUS BASIC-PLUS-2 V2.2 SFD 14.11.10 2.2 AE-J197N-TC-001 1	nAY 84
RSX BCF RSX-11H RCF USER'S GUIDE 1.0 AA-N269A-TC-001 2	SEF 82
RSX CHR11/CHV11 SOFTWARE DRIVER CHR11/CHV11 SOFTWARE DRIVER USERS GUIDE 1.0 AA-NO60A-TC-001 1	APR 83
RSX CHRII/CHVII SOFTWARE DRIVER CHRII/CHVII SOFTWARE DRIVER REFERENCE MANUAL 1.0 AA-NG61A-1C-001 1	APR 83
RSX CHR11/CHV11 SOFTWARE DRIVER CHR11/CHV11 SOFTWARE DRIVER RELEASE NOTES 1.0 AV-NOSBA-TC-001 1	4FR 83
RSX DATATRIEVE-11 V3.0 SPD 12.48.11 3.0 AE-C777L-TC-001 1	MAY 84
RSX DECNET-11M RSX DECNET GUIDE TO USER UTILITIES 3.1 AA-H223B-TC-001 2	FEB 34
RSX DECNET-11M RSX DECNET SYSTEM MANAGER'S GUIDE 3.1 AA-H224B-1C-001 5	FEB 84
RSX DECNET-11M RSX DECNET NETWORK GEN AND INSTE GUIDE 3.1 AA-H225B-TC-001 3	FER 84
RSX DECNET-11M INTRODUCTION TO DECNET 3.1 AA-JOSSC-TN-001 2	FEB 84
RSX DECNET-11M RSX DECNET POST-INSTL CHECKOUT PROCEDURES 3.1 64-J3198-TN-001 C	FEB 84
RSX DECNET: 11M RSX DECNET RELEASE NOTES 3.1 AA-J517E-TC-001 1	FEB 84
RSX DECNET-11M OVERVIEW OF RSX DECNET 3.1 AA-MOSeA-TC-001 2	FEB 84
RSX DECNET-11H RSX-DECNET REFERENCE GUIDE 3.1 AA-M097A-FC-001 1	FEB 84

OPERATING SYSTEM	FRODUCT NAME	TITLE OF MANUAL	VERSION	PART NUMBER REV LEVEL	NUMBER OF FICHE	DATE
RSX	DECNET-11M	RSX DECNET PROGRAMMER'S REF MANUAL	3.1	AA-M098A-TC-001	5	FER 84
RSX	DECNET-11M	DECNET-11H V4.0 SFD 10.75.10	4.0	AE-3431N-TC-001	1	HA / 84
RSX	FMS-11/RSX	FMS-11/RSX V1.0 SFD 12.27.07	1.0	AE-J405H-TE-001	1	JUL 84
RSX	FORTRAN IV/RSX	FORTRAN IV/RSX V2.6 SPI 14.63.9	2.6	AE-3443J-TC-001	1	FEB 84
RSX	FORTRAN-77/RSX; FDF-11	FDF-11 FORTRAM-77/RSX VS.0 SPD 14.31.06	5.0	AE-J139G-TC-001	1	FEB 84
RSX	LABORATORY SUBROUTINE FACKAGE	LSP V1.2 SPD 15.44.5	1.2	AE-1607F-TC-001	1	FER 84
RSX	OBSERVER	OBSERVER INSTL GUIDE AND GEN GUIDE	1.0	AA-N959A-TC-001	1	AFR 83
RSX	OBSERVER	OBSERVER USEN'S GUIDE	1.0	AA-N960A-TE-001	3	AFR 83
RSX	OBSERVER	OBSERVER RELEASE NOTES	1.0	AA-N962A-TC-001	1	APR 83
RSX	FASCAL/RSX, FDF-11	PDF-11 PASCAL LANGUAGE REFERENCE MANUAL	1.0	AA-#875A-TC-001	2	JAN 64
RSX	FASCAL/RSX, FDP-11	FDF-11 FASCAL USER'S GUIDE	1.0	AA-M876A-TE-001	2	JAN 84
RSX	FASCAL/RSX+ FTF-11	FDP-11 PASCAL INSTALLATION GDE/REL NOTES	1.0	AA-M877A-TC-001	1	JAN 64
RSX	FASCAL/RSX, FDF-11	FDP-11 FASCAL/RSX V1.1 SFD 14.18.02	1.1	4E-NY17C-TC-001	1	FEB 84
RSX	FLXY-11H	FLXY-11 V1.1 USER'S GUIDE	1.1	AA-JS3SA-TK-001	1	SEP 82
RSX	PROFESSIONAL HOST COMMUNICATIONS	PROFESSIONAL HOST COMM INSTL PROCEDURES	1.5	AA-P4128-TK-001	1	JAN 84
RSX	PROFESSIONAL, HOST TOOL KIT	TOOL KIT DOCUMENTATION DIRECTORY	1.0	AA-N615E-TK-001	1	JAN 84
RSX	PROFESSIONAL HOST TOOL NIT	TOOL KIT DOCUMENATION DIRECTORY	1.0	AA-N615C-TK-001	1	MAY 94
RSX	PROFESSIONAL HOST TOOL KIT	FRO TOOL KIT INSTL GDE/REL HTS	1.0	AA-N6168-FK-001	1	JAN 84
RSX	PROFESSIONAL HOST TOOL KIT	TOOL KIT USER'S GUIDE	1.0	44-N5170-TK-001	3	MA1 84
RSX	PROFESSIONAL HOST TOOL KIT	CORE GRAPHICS LIBRARY MANUAL	1.0	AA-N619A-TN-001	2	APR 83
RSX	PROFESSIONAL HOST TOOL NIT	CORE GRAPHICS LIBRARY MANUAL	1.0	44-N619B-TK-001	2	hay 84
RSX	FROFESSIONAL HOST TOOL KIT	F/OS SYSTEM REFERENCE MANUAL	1:0	AA-No20A-TK-001	4	APP 83
RSX	FROFESSIONAL HOST TOOL KIT	PRO/TOOL KIT DOCUMENATION DIRECTOR:	1.0	44-λ°104-TH-001	1	MAY 84
RSX	PROFESSIONAL HOST TOOL KIT	PRO/TOOL KIT INSTALLATION GDE/FELEASE NOTES	1.0	AA~X911A~TH-001	1	MAY 84
RSX	PROFESSIONAL TOOL NIT BASIC-FLUS-2	BASIC REFERENCE MANUAL	2.0-2.1	AA-L334A-TN-001	6	APR 83
RSX	PROFESSIONAL TOOL NIT BASIC-FLUS-2	BASIC USER'S GUIDE	2.0-2.1	AA-L335A-TN-001	3	AFR 83

OPERATING SYSTEM	G PRODUCT NAME	TITLE OF MANUAL	VERSION	PART NUMBER REV LEVEL	NUMBER OF FICHE	DATE
RSX	PROFESSIONAL TOOL KIT BASIC-PLUS-2	BASIC ON RSX-11H/H-PLUS SYSTEMS (UPD#1)	2.1	AA-L33SA-TC-001	1	JAN 84
RSX	PROFESSIONAL TOOL KIT BASIC-FLUS-2	BASIC-PLUS-2 DOCUMENTATION SUPPLEMENT	2.1	AA-P102B-TK-001	1	JAN 84
RSX	PROFESSIONAL TOOL KIT BASIC-PLUS-2	PRO TOOL KIT BASIC + 2 INSTL GDE/REL HTS	2.1	AA-P104B-TK-601	1	JAN 84
RSX	PROFESSIONAL TOOL KIT BASIC-PLUS-2	FRO TOOL KIT BASIC-FLUS-2 V2.2 SFD 30,27.01	2.2	AE-P650B-TK-001	1	HAY 84
RSX	PROFESSIONAL TOOL KIT DIPOL	INTRODUCTION TO DIBOL	1.0-1.6	AA-F042A-TK-001	i	APR 83
RSX	PROFESSIONAL TOOL KIT DIBOL	PROFESSIONAL TOOL NIT DIBOL USER'S GUIDE	1.0	AA-F043A-TN-001	2	APR 83
RSX	PROFESSIONAL TOOL KIT DIBOL	PROFESSIONAL TOOL KIT DIBOL LANG REF MANUAL	1.0	AA-P044A-TK-001	3	AFR 83
RSX	PROFESSIONAL TOOL KIT DIBOL	PROFESSIONAL TOOL KIT DIBOL REL NIS/INSTL GDE	1.0	AA-P045A-TK-001	1	APR 83
RSX	PROFESSIONAL TOOL KIT DIBOL	DIBOL LANGUAGE REFERENCE CARD	1.6	AA-U067A-TK-001	i	MAY 84
RSX	PROFESSIONAL TOOL NIT FORTRAN-77	FRO TOOL KIT FORTRAN-77 V5.0 SFD 30.38.01	5.0	AE-W587P-TN-001	1	HAY 84
RSX	PROFESSIONAL TOOL KIT PASCAL	PRO TODE NIT PASCAL INSTERNET NOTES	1.1	AA-R/59E-IN-001	1	nAY 84
RSX	RGL-11	RELEASE NOTES FOR FGL-11	1.1	AA-#839A-TC-001	1	APR 83
RSX	RGL-11	RGL-11 V1.1 SFD 14.62.3	1.1	AE-M302D-TC-001	1	FEB 84
RSX	RSX 11 2780/3780 EMULATOR	RSX11 2780/3780 EMUL V4.1 SFD 10.01.01	4.1	AE-K997B-TC-001	1	may 84
RSX	RSX 11H IAS RUE/HASP	RUE/HASP WORKSTATION INSTALLATION GUIDE	1.1	AA-5426E-TC-001	1	SEP 32
RSX	RSX 11H IAS RJE/HASP	RUE/HASP WORKSTATION OPERATOR'S GUIDE	1.1	AA-54276-TE-001	1	SEP 82
RSX	RTEH-11	RTEM-11 USER'S MANUAL	1.1	AA-N435B-TN-001	2	JAN 84
RSX	RTEM-11	RTEM-11 INSTL GUIDE/RELEASE NOTES (UFD#1)	1.1	AA-N436A-TK-001	2	JAN 84
RSX	SORT-11	PDF11 SORT REFERENCE MANUAL (UPDATE \$1)	2.0	AA-33416-TE-001	2	SEP 82
RSX	SORT-11	SORT-11 V2.0 SFD 12.7.5	2.0	AE-5429G-TC-001	1	FER 84
RSX	SSF-11	SSF-11 V1.3 SFD 15.45.9	1.3	AE-3413H-TC-001	1	FEB 84
RSX	VSV11-M DRIVER	VSV11-M SOFTWARE DRIVER GUIDE	2.0	AA-J287E-TK-001	1	SEP 82
RSX	VSV11-M DRIVER	VSV11-M V2.0 RELEASE NOTES	2.0	AA-M615A-TC-001	1	JAN 84
RSX	VSV11-H DRIVER	USU11-# U2.1 SFR 14.53.03	2.1	AE-K851II-TC-001	i	FEB 84
RSX 11 PL	U RSX 11M PLUS DECTYPE	USING DECTYPE	3.0	AA-R125B-TK-001	3	JUL 84
RSX 11 PL	U RSX 11M PLUS DECTYPE	INSTALLING AND MANAGING DECTYPE	3.0	AA-Z960A-TC-001	1	JUL 84

OPERATING	FRODUCT	TITLE OF		PART NUMBER	NUMBER	
SYSTEM	NAME	MANUAL	VERSION	REV LEVEL	OF FICHE	DATE
RSX 11 PLU RSX 11M	PLUS DECTYPE	DECTYPE V3.0 SFD 14.82.00	3.0	AE-BG31A-TC-001	1	JUL 84
RSX 11 PLU RSX 11H	FLUS DECTYPE	DECTYPE KEYBOARD LAYOUT	3.0	AV-R127A-TK-001	1	JUL 84
RSX 11 PLU RSX 11M	PLUS DECTYPE	DETYPE QUICK REFERENCE GUIDE	3.0	AV-R1288-TK-001	1	JUL 84
RSX 11 PLU RSX 11M	PLUS DIROL	DIBOL FOR REGINNERS	1.0	AA-BI77A-TK-001	1	JUL 84
RSX 11 PLU RSX 11H	PLUS DIBOL	PRO TOOL KIT INTRODUCTION TO DIBOL-83	1.0	AA-F042B-TK-001	1	JUL 84
RSY 11 PLU RSX 11M	PLUS DIROL	DIBOL-83 LANGUAGE REFERENCE MANUAL (UPD#1)	1.0	AA-U066A-TK-001	2	JUL 84
RSX 11 PLU RSX 11H	PLUS DIBOL	DIBOL-83_COMPATIBILITY GUIDE	1.0	AA-V810B-TK-001	1	JUL 84
RSX 11 PLU RSX 11H	PLUS DIROL	H+/MICRO RSX DIBOL USER'S GUIDE	1.0	AA-2865A-TC-001	2	JUL 84
RSX 11 PLU RSX 11M	PLUS DIBOL	MH/MICRO RSX DIBOL RELEASE NOTES/INSTL GDE	1.0	AA-Z88&A-TC-001	1	JUL 84
RSX 11 FLU RSX 11M	PLUS BIBOL	HI/MICRO REX DB HESSAGE MANUAL	1.0	AA-Z887A-TC-001	1	JUL 84
RSX 11 PLU RSX 11H	PLUS DIBOL	DIBOL-83 LANGUAGE REFERENCE CARD	1.0	AV-U667A-IN-001	1	JUL 84

Fage 1

OPERATING SYSTEM	PRODUCT NAME	TITLE OF MANUAL	VERSIDA	PART NUMBER REV LEVEL	NUMBER OF FICHE	DATE
RSX	BASIC-FLUS-2 FOR RSX-11M/M-PLUS	BASIC+2 RSX-11H/H-PLUS INSTL GDE/REL NOTES	2.1	44-0158E-TC-001	1	JAN 64
#RSX	BASIC-FLUS-2 FOR RSX-11H/M-FLUS	BASIC+2 RSX-11H/H-FLUS INSTL GDE/REL HOTES	2.2	AA-0158F-TC-001	1	may 84
#RSX	RSX 11M F ENHANC PNG FOR HINE	SCIENTIFIC SUBROUTINES PROG REF MAN (UPD#1)	1.1-1.2	AA-11010-76-001	2	AFR 83
*RSX	SSF-11	SCIENTIFIC SUB PROGRAMMER'S REF MAN (UFD#1)	1.3	AA-1101II-TC-001	2	SCP 82
*RSX	UN1004	UN1004/RSX RELEASE NOTES	2.0	AA-13410-T0-001	1	SEP 82
*RSX	UN1004	UN1004/RSX USRS GDE/SYS GEN GDE (UFU#1)	2.0	AA-13428-TC-001	1	SEF 52
*RSX	HUX200/RSX-IAS	MUX200/RSX-IAS V2.1 RELEASE NOTES	2.1	#A-13430-T0-001	1	JAN 84
#RSX	HUX200/RSX-IAS	NUX200/RSX-IAS SYSTEM MANAGER GUIDE	2.1	AA-13440-TC-001	2	JAN 84
#RSX	MUX200/RSX-IAS	MUX200/RSX-IAS USER'S GUIDE	2.1	AA-13460-TC-001	1	JAN 64
4RSX	CORAL-66	PDF-11 CORAL-66 V4.0 INSTL GDE/REL NOTES	4.0	AA-1744E-TL-001	1	APR 83
#RSX	FDF-11 COPOL	FIR-11 CORCL INSTALLTION GUIDE	4,4	##-1745F-TC-001	1	SEF 82
*RSX	FIF-11 COSOL	FDF11 COBOL LANG FEF MANUAL (UPD#1 & #2)	4.4	AA-1749E-TC-001	3	SEF 82
*RSX	FDF-11 COPOL	PDF-11 COROL USER'S GUIDE (INCLUDES UPD#1)	4.4	44-1757E-TC-001	٥	SEF 8.2
#RSX	RSX-11m	RSX-11M/RSX-11S RELEASE NOTES	4.1	AA-2573H-TC-001	2	NOV 83
*RSX	RSX-115	RSX-11m/RSX-11S RELEASE NOTES	4.1	AA-2573H-TE-001	2	NOV 83
*RSX	RSX-11h	RSX-11H/11S INFORMATION DIRECTORY/INDEX	4.1	AA-25938-TC-001	4	HOV 83
#RSX	RSX-119	RGX-11m/HSX-11S INFORMATION DIRECTORY & INDEX	4.1	AA-2593G-TC-001	4	NOV 93
#RSX	RSX-11m	RS4-11M GUINE TO WEITING AN 1/0 INTIVER	4.1	AA-2600E-TE-001	3	40V 83
FRSX	R3x-115	RSX-11M GUIDE TO WRITING I/O OFFICER	4.1	44-2500E-TC-001	6+4	18 VON
#RSX	RSX-115	RSX-119 SYS GEN/INSTE GDE (INCLUDES UF141	4.1	AA-2074E-TC-001	2	NO! 83
RSX	SORT-11	FDF11 SORT REFERENCE MANUAL (UPDATE #1)	2.0	AA-33210-T0-001	2	SEP 87
#RSX	FOMM IOF-12	COMM TOF-DZ PROGRAMMER'S MANUAL	1.0	4A-5127A-TC-001	1	SEF E2
#RSX	KMC-11 TGOLS	NHC11 PROGRAMMER S MANUAL	1.0	AA-5244B-TC-001	n.	3EF 80
FS.	RSX 11H IAS RUE/HASF	RUE/HASP WORKSTATION INSTALLATION GUIDE	1.1	AA-51260-TC-001	1	3EF 62
*RSX	RSX 11M TAS RUE/HASF	RUE/HASP WORNSIATION INSTALLATION GUILE	1.1	AA-5426D-TC-001	1	JUL 84

OFERATING	FRODUCT	TITLE OF		PART NUMBER REV	NUMBER OF	
SYSTEM	NAME	hanual	VERSION		FICHE	DATE
RSX	RSX 11m IAS RJE/HASP	RJE/HASP WORKSTATION OPERATOR'S GUIDE	1.1	AA-5427C-TC-001	1	SEP 82
*RSX	RSX 11M TAS RUE/HASF	RJE/HASE WORKSTATION OFERATOR'S GUIDE	1.1	AA-5427D-TC-001	1	JUL 84
*RSX	PX/11H	UX PRODUCTS PROGRAMMER'S REFERENCE MANUAL	3.1	AA-5469E-TC-001	1	APR 83
*RSX	DX/11H	DX PRODUCTS USER'S GUIDE	3.1	AA-5476R-TC-001	1	APR 83
*R5X	RSX 11M SNA FE	RSX11h/SNA PE CONCEPTS AND FACILITIES (UFD#1)	1.1	AA-5501A-TC-001	2	SEF 82
#RSX	RSX 11H SNA PE	RSX11H/SNA PE SYSTEM MANAGER'S GUIDE (UPD#1)	1.1	AA-5502A-TC-001	2	SEP 82
*RSX	RSX 11M SNA PE	RSX11H/SNA PE APPLICATIONS PROGRAMMER S GUIDE	1.1	AA-55038-TC-001	2	SEF 82
#RSX	RSX-11h	IAS/RSX-11 SYSTEM LIB ROUTINE REF MARUAL	4.1	AA-55808-TC-001	2	NOV 63
*RSX	RSX-11H-FLUS	IAS/RSX-11 SYSTEM LIB ROUTINE REF MARUAL	2.1	AA-5530E-TC-001	2	NOV 83
#RSX	RSX-11S	IAS/RSX-11 SYS LIB ROUTINE REF MANUAL	4.1	AA-55808-TC-001	2	NOV 83
₽RSX	CONH TOF-INF	COMM TOF-DUF PROGRAMMER'S MANUAL	1.0	44-5070A-TC-001	1	SEF 8.7
#RSX	PROFESSIONAL HOST TOOL KIT	THS PROGRAMMER 19 MANUAL	2.0	AA-AB34A-TH-001		DCT 84
#RGX	FROFESSIONAL REAL TIME INTERFACE LI	PRTIL RELEASE NOTES	1.1	AA-AI40C-TH-001		OCT 84
*RSX	MICROPONER/FASCAL-RSX	HP/P RSX-11H/H+ INSTALLATION GUIDE	1.5	AA-AK10A-T8-001	i	JUL 84
*RSX	MICRUPOWER/FASCAL-RSX	MP/P RSX-11M/M+ RELEASE NOTES	1.5	AA-AN11A-TC-001	1	JUL 84
#RSX	HICROPOWER/FASCAL-RSX	HF/F-RSX/VMS SYSTEM USER'S GUILLE	1.5	AA~AN13A-TK-001	3	JUL 84
*RSX	HICROPOWER/FASCAL-RSX	MF/F-RSX/VMS MESSAGES MANUAL	1.5	AA-AN14A-TN-001	1	JUL 84
#R'SX	PROFESSIONAL HOST TOOL KIT	PRO/BECNET IN PROGRAMMER'S REFERENCE MANUAL	2.0	AA-AV69A-TK-001	3	JUL 64
*RSX	PROFESSIONAL HOST TOOL KIT	FRO/BECHET TOOL KIT INSTALLATION GUIDE	2.0	64-40706-TK-001	1	JUL 94
#RSX	PROFESSIONAL TOOL NIT DIEGL	DIBOL FOR BEGINNERS	1.6	AA-B177A-Th-001	1	JUL 84
RSX 11 PLU	J RSX 11M FLUS DIBOL	DIBOL FOR BEGINNERS	1.0	##-BI/7#-TK-001	1	JUL 84
#RSX	FROFESSIONAL HOST TOOL KIT	GUIDE TO WRITING P/OS I/O DRIVER	2.0	AA-BT73A-TH-001		OCT 94
*RSX	PROFESSIONAL HOST TOOL KIT	PRO TOOL KIT REFERENCE MANUAL	2.0	AA-BT74A-TH-001		001 94
*RSX	RSX 11M 3271 PROTOCOL EMULATOR	RSX-11/3271 PE PROGRAMMER'S GUIDE	3.0	AA-C739&-TC-001	2	APR 83
#RSX	RSX 11M 3271 PROTOCOL EMULATOR	RSX-11/3271 FE SYSTEM MANAGER'S GUIDE	3.0	AA-87398-TC-001	3	APR 83
#RSX	LABORATORY SUBROUTINE PACKAGE	LABORATORY SUB PROGRAMMER'S REF MAN (UFI#1)	1.2	AA-09840-10-001	1	SEF 82

OPERATING SYSTEM	FRODUCT NAME	TITLE OF HANUAL	VERSION	FART NUMBER REV LEVEL	NUMBER OF FICHE	DATE
*RSX	RSX 11M F ENHANC FKG FOR HINC	LAB SUBROUTINES PROG REF MAN (UPD#1)	1.1-1.2	AA-09840-T0-001	3	APR 83
*RSX	SORT-11	PDF-11 SORT/MERGE USER'S GUIDE	3.0	AA-CI67A-TC-001	2	JUL 84
*RSX	C04HL-66	CORAL-66 LANGUAGE REFERENCE MANUAL	4.0	AA-B111C-TK-001	2	AFR 83
*RSX	CORAL-66	RSX/VMS CORAL-66 USER'S GUDE	4.0	AA-B112C-TK-001	4	APR 83
*RSX	COMM TOP-DUP	COMM TOP-DUP RELEASE NOTES (INCLUDES UPD#1)	1.0	AA-0367A-TC-001	1	SEP 82
#RSX	COMM 10F-DZ	COMM TOP-THE RELEASE NOTES (INCLUDES UPD#1)	1.0	AA-D368A-TC-001	1	SEP 82
*RSX	RSX 11M F ENHANC PKG FOR MINC	REALIIM/MNC FORTTRAN PROG REF MAN (UFD#1+2)	1.1-1.2	AA-B6310-T0-001	4	AFR 83
*RSX	DX/11H	DX/11M INSTALLATION GUIDE	3.1	AA-B997A-TC-001	1	APR 83
#RSX	RSX 11H 3271 PROTOCOL EMULATOR	RSX-11/3271 FE RELEASE NOTES V3.0	3.0	AA-H032E-TC-001	1	APR 83
RSX	DECNET-11H	RSX DECNET GUIDE TO USER UTILITIES	3.1	AA-H223R-TC-001	2	FEB 84
*RSX	DECNET-11H	RSX DECNET GUIDE TO USER UTILITIES	4.0	AA-H223C-TC-001	2	MAY 84
RSX	DECNET-11H	RSX DECNET SYSTEM MANAGER'S GUIDE	3.1	AA-H224B-TC-001	5	FEB 84
*RSX	DECNET-11H	RSX DECNET SYSTEM MANAGER'S GUIDE	4.0	AA-H224C-T€-001	5	MAY 84
RSX	DECNET-11M	RSX DECNET HETWORK GEN AND INSTL GUIDE	3.1	AA-H225E-TC-001	3	FEB 84
*RSX	DECNET-11h	RSX DECNET NETWORK GEN AND INSTALLATION GUIDE	4.0	AA-H_25C-TC-001	5	hay 84
#RSX	RSX-11H-FLUS	RSX-11M-PLUS GUIDE TO WRITING I/O DRIVER	2.1	AA-H267B-TC-001	4	NOV 83
*RSX	DX/11H	DX/11M VERSION 3.1 RELEASE NOTES	3.1	#A-H288E-TC-001	1 ,	AFR 83
#RSX	RSX-11H-FLUS	RSX-11H-FLUS INFORMATION DIRECTORY AND INDEX	2.1	AA-H426C-TC-001	4	40V 83
*RSX	RSX-11h-FLUS	RSX-11M-PLUS V2.1 RELEASE NOTES	2.1	AA-H427C-TC-001	1	NOV 83
#RSX	RSX-11H-FLUS	RSX-11M-PLUS SYSTEM GEN/INSTALLATION GUIDE	2.1	AA-H431C-TC-001	3	NOV 83
*RSX	RSX-11h	RSX-11 SYS GENERATION AND INSTALLATION GDE	4.1	AA-H625C-TC-001	5	NOV 83
#RSX	RSX-11S	RSX-11H SYSTEM GENERATION/INSTALLATION GUIDE	4.1	AA-H62SC-TC-001	5	NOV 83
*RSX	DBMS-11	DBMS-11/M+ DDL/DEVICE MEDIA CON LANG REF MAN	2.0-2.1	AA-H804E-TC-001	3	SEP 82
*RSX	DBMS-11	DBMS-11 DATA BASE ADMINISTRATOR'S (DBA) GUIDE	2.0-2.1	AA-H805E-TC-001	4	SEP 82
*RSX	Fhu-11/RSX	PDF11 KEYPAD EDITOR USER'S GDE (UFD\$1)	1.0	AA-H953A-TC-001	2	SEP 82
*RSX	FHS-11/RSX	FMS-11/RSX11M SOFTWARE REF MANUAL (UFD41)	1.0	AA-H355A-T0-001	3	SEP 82

OPERATING		TITLE OF	UPDETAN	PART NUMBER REV	NUMBER OF	
SYSTEM	NAME	HANUAL SECTION DESCRIPTION VANIAN	VERSION		FICHE	DATE
\$RSX	PROFESSIONAL HOST TOOL NIT	FMS-11/RSX SOFTWARE REFERENCE MANUAL	1,0-2,0	AA-H855A-TC-001		AFR 83
*RSX	FMS-11/RSX	FMS-11/RSX-11H RELEASE NOTES	1.0	AA-H857A-TE-001	1	SEP 82
*RSX	PROFESSIONAL HOST TOOL KIT	FMS-11/RSX RELEASE NOTES	1.0-2.0	AA-H857A-TC-001	1	APR 83
RSX	DECNET-11M	INTRODUCTION TO DECNET	3.1	AA-J0556-TK-001	2	FEB 84
*RSX	DECNET-11M	INTRODUCTION TO DECNET	4.0	AA-J05511-TK-001	3	MAY 84
*RSX	PROFESSIONAL HOST TOOL KIT	INTRO TO DECNET PHASE IV	2.0	AA-J055D-TK-001		OCT 64
RSX	USV11-M DRIVER	VSV11-M SOFTWARE DRIVER GUIDE	2.0	AA-J2878-TK-001	1	SEP 82
*RSX	USU11-M DRIVER	VSV11-# SOFTWARE DRIVER GUIDE	2.2	AA-J287E-TK-001	1	JUL 84
#RSX	RSX 11M F ENHANC PKG FOR MINC	INTRODUCTION TO FEP AND FRE	1.1-1.2	AA-J3028-TC-001	1	APR 83
#RSX	RSX 11H F ENHANC PNG FOR MINC	RSX-11M FEP AND FRP INSTALLATION/USRS GDE	1.2	AA-J303N-TC-001	2	JAN 64
RSX	DECNET-11h	RSX DECNET POST-INSTL CHECKOUT PROCEDURES	3.1	44-J3198-TN-001	2	FER 84
#RSX	DECNET-11H	RSX DECNET POST-INSTL CHECKOUT PROCEDURES	4.6	AA-J3190-TN-001	1	MAY 84
*RSX	CGBOL-81/RSX	COBOL-81 LANGUAGE REFERENCE MANUAL	2.0	AA-J434H-TC-001	4	JAN 84
#RSX	PROFESSIONAL TOOL KIT COROL-61	COROL-81 LANGUAGE REFERENCE MANUAL	2.1	AA-J434B-TC-001	4	MAY 84
RSX	DECNET-11H	RSX DECNET RELEASE NOTES	3.1	AA-J517k-TC-001	1	FEB 84
#RSX	DECNET-11M	RSX DECNET RELEASE NOTES	4.0	AA-J517C-TC-001	1	MAY 84
*RSX	DFM	DPM/DPM+ DECDATA INTELL SUBS USFS GDE (UPD41)	4.1	AA-JS298-TC-001	3	SEP 82
#RSX	DF:N	DEH/DEH+ TERMIANL USER'S GUIDE (UFD#1)	4.1	AA-J530E-TC-001	2	SEP 82
#RSX	DFM	DPH/DPM+ SYSTEM GENERATION/MANAGEMENT GDE	4.1	AA-J5310-T0-001	31 <u>4</u>	SEP 82
RSX	FLXY-11H	FLXY-11 VI.1 USER'S GUIDE	1.1	AA-J535A-Th-001	1	SEP 82
#RSX	FLXY-11M	PLXY-11 USER'S GUIDE	1.3	44-J535H-TN-001	1	nAY 84
4RSX	RSX 11H SNA FE	RSX11M/SNA PE RELEASE NOTES (UFD#1)	1.1	AA-J549A-TC-001	1	SEP 82
*RSX	RSX 11 2780/3780 EMULATOR	RSX-11 2780/3780 EMULATOR USER'S GUIDE	4.1	AA-J581A-TL-001	1	SEP 82
*RSX	FMS-11/RSX	PDP11 KEYPAD EDITOR RELEASE NOTES	1.0	AA-J692A-TC-001	1	SEP 82
RSX	RSX-11M	EDT EDITOR MANUAL	4.1	AA-J726A-TC-001	3	110V 83
RSX	RSX-11H-FLUS	EDT EDITOR MANUAL	2.1	AA-J726A-TC-001	3	NOV 83

OPERATING SYSTEM	FRODUCT Name	TITLE OF MANUAL	VERSION	PART NUMBER REV LEVEL	NUMBER OF FICHE	DATE
	RSX DLX-11	RSX DLX-11 USER'S GUIDE	1.0	AA-K142A-TC-061		SEP 82
#RSX						
≭ RSX	RSX DLX-11	RSX DLX-11 RELEASE NOTES	1.0	AA-K143A-TE-001		5EP 62
*RSX	DT07-11	DT07-11K V1.1 USER'S GUIDE	1.1	AA-N568A-TC-001	1	SEF 82
≭R5X	DBMS-11	DBMS11 FORTRAN DATA MANIPULATION LANG REF MAN	2.0-2.1	AA-K883B-TC-001	2	5EF 82
*RSX	DBMS-11	DBMS11 COBOL DATA MANIPULATION LANG REF MAN	2.0-2.1	AA-N884B-TC-001	2	SEP 82
*RSX	DBMS-11	DBMS-11 INSTALLATION GUIDE	2.0-2.1	AA-1685E-TC-001	2	SEF 82
*RSX	DBhS-11	IBMS-11 V2.0 RELEASE NOTES	2.0-2.1	AA-N386B-TE-001	1	SEP 82
*RSX	DBMS-11	USING THE DATATRIEVE-11/DBMS-11 INTERFACE	2.0-2.1	AA-K887B-TC-001		SEP 62
RSX	BASIC-PLUS-2 FOR RSX-11h/H-PLUS	BASIC REFERENCE MANUAL	2.0-2.1	AA-L334A-TN-001	ó	AFR 83
RSX	PROFESSIONAL TOOL KIT BASIC-PLUS-2	BASIC REFERENCE MANUAL	2.0-2.1	AA-L334A-TK-001	ó	AFR 83
*RSX	BASIC-PLUS-2 FOR RSX-11M/M-PLUS	BASIC REFERENCE MANUAL (UFD)1)	2.2	AA-1334A-TK-002	6	may 84
*RSX	PROFESSIONAL TOOL KIT BASIC-FLUS-2	EASIC REFERENCE MANUAL (UPI \$1)	2.2	AA-L334A-TN-002	ó	MAY 84
RSX	BASIC-PLUS-2 FOR RSX-11m/m-PLUS	BASIC USER'S GUIDE	2.0-2.1	AA-L335A-TN-001	3	APR 83
RSX	PROFESSIONAL TOOL KIT BASIC-PLUS-2	BASIC USER'S GUINE	2.0-2.1	AA-L335A-TK-001	3	APR 83
*RSX	BASIC-PLUS-2 FOR RSX-11M/M-PLUS	BASIC USER'S GUIDE (UPD#1)	2.2	AA-L335A-TK-002	3	may 84
*RSX	PROFESSIONAL TOOL KIT BASIC-FLUS-2	BASIC USER'S GUIDE (UPD#1)	2.2	AA-L335A-TK-002	3	MAY 84
RSX	BASIC-PLUS-2 FOR RSX-11H/H-PLUS	BASIC ON RSX-11H/H-PLUS SYSTEMS (UPD41)	2.1	AA-L338A-TC-001	3	JAN 84
RSX	PROFESSIONAL TOOL NIT BASIC-PLUS-2	BASIC ON RSX-11m/H-FLUS SISTEMS (UPIA1)	2.1	• AA-L338A-TC-001	1	JAN 84
#RSX	BASIC-PLUS-2 FOR RSX-11h/M-PLUS	BASIC ON RSX-11m/m-PLUS SYSTEMS (UPD#1 % #2)	2.2	AA-L338A-TC-002	3	may 84
#FSX	PROFFSSIONAL TOOL KIT BASIC-PLUS-2	BASIC ON RSX-11m/m-FLUS SYSTEMS (UFILE1 & #2)	2.2	AA-L338A-TC-002	3	naY 84
*RSX	RSX-11m	RHS-11 PROGRAMMERS MANUAL	4.1	6A-1.0866-TC-001	5	NOV 83
#RSX	RSX-11H-FLUS	RMS-11 PROGRAMMERS MANUAL	2.1	AA-L668A-TC-001	5	NOV 93
ARSX	RSX-lin	RMS-11 USER'S GUIDE	4.1	AA-Loo9A-76-001	2	NOV 83
#RSX	RSX-11m-FLUS	RMS-11 USER'S GUIDE	2.1	AA-L669A-TC-001	2	NBV 83
4RSX	PROFESSIONAL HOST TOOL KIT	RSX/RMS USER'S GUIDE	1.0-2.0	AA-L567A-TC-001		nat 84
#RSX	RSX-11H	RMS-11 UTILITIES MANUAL	4.1	AA-Lo70A-TC-001	3	HOV 83

OPERATING SYSTEM	FRODUCT NAME	TITLE OF MANUAL	VERSION	PART NUMBER REV LEVEL	NUMBER OF FICHE	DATE
*RSX	RSX-11h-PLUS	Am6-11 UTILITIES	2.1	AA-L370A-TC-001	3	HOV 83
#RSX	PROFESSIONAL HOST TOOL KIT	RSX-11M/h-PLUS RMS-11 UTILITIES MANUAL	1.0-2.0	AA-Lo70A-TC-001	3	MAY B4
#RSX	R5X-11H	RSX-11h/h-PLUS BATCH AND QUEUE OPERATIONS MAN	4.1	AA-L671A-TC-001	2	NOV 83
#RSX	RSX-11M-FLUS	RSX-11m/mt BATCH AND QUEUE OFER MANUAL	2.1	AA-L671A-TC-001	2	E8 VON
#RSX	RSX-11H	RSX-11h/M-PLUS COMMAND LANGUAGE MANUAL	1.4	AA-L6728-TC-001	ó	HOV 83
#RSX	RSX-11h-PLUS	RSX-11m/H+ COMMAND LANGUAGE MANUAL	2.1	AA-L672E-TC-001	6	NOV 83
*RSX	RSX-11h	RSX-11m/m+ CRASH DUMP AND REF MAMUAL	4.1	AA-Lo738-TC-001	3	E6 VON
4RSX	RSX-11M-FLUS	RSX-11M/m+ CRASH DUMF ANZ REF HANUAL	2.1	AA-Lo735-TC-001	3	NOV B3
#RSX	F:5X-115	RSA-11M/m+ CRASH DUMP ANZ REF HANUAL	4.1	4A L573F-18-001	3	NOV 83
*RSX	RSX-11n	RSX-11m/H-PLUS EFROR LOGGING MANUAL	4.1	AA-L674E-TC-001	3	MOD 83
*RSX	RSx-11m-FLUS	RSX-11M/M-PLUS ERFOR LOGGING MANUAL	2.1	AA-L:746-10-001	3	401 83
♦F (SX	RSX-11M	RSX-11H/H-PLUS EXECUTIVE REFERENCE MANUAL	4.1	AA-L579A-T2-001	4	HOV 83
*RSX	RSX-11m-FLUS	RSX-11M/N-PLUS EXECUTIVE REFERENCE MANUAL	2.1	AA-Le75A-TC-001	4	MOV 83
#RSX	RSX-11S	RSX-11M/M-PLUS EXECUTIVE REFERENCE MANUAL	4.1	4A-L675A-TE-001	4	NOV 83
*RSX	RSX-11m	RGX-11m/n-FLUS GUIDE TO PROGRAM DEVELOPMENT	4.1	AA-L676A-TC-001	2	NOV 63
#RSX	RSX-11M-FLUS	RSX-11H/N+ GUIDE TO PROGRAM DEVELOPMENT	2.1	AA-L676A-TC-001	2	NOV 83
#R6X	R5X-11S	RSX-11m/m-PLUS GUIDE TO PROGRAM DEVELOPMENT	4.1	AA-Lo7oA-TC-001	i	NOV 83
#RSX	RSX-11M	RSX-11M/H+ I/O DRIVERS REF MAN (UPD41)	4.1	AA-L6774-10-001	6	NOV 33
#RSX	RSX-11h-PLUS	RSX-11M-h-FLUS I/O DRIVERS REF MAN (UFD#1)	2.1	AA-Lo77A-TE-001	٥	NOV 83
*RSX	RSX-115	RSX-11M/M+ I/O DIRVERS REF MANUAL (UFD+1)	4.1	AA-L677A-TC-001	0	MOV 83
*RSX	RSX-11m	RSX-11m/m+ mCR OPERATIONS MANUAL (UFD41)	4.1	AA-Lo78A-TC-001	5	NOV 83
*RSX	RSX-11M-FLUS	RSX-11M-M-FLUS MER OF MANUAL (UFD41)	2.1	AA-L673A-TE-001	5	NOV 83
#RSX	RSX-115	RSX-11m/m-FLUS min OPERATIONS MANUAL (UPD41)	4.1	A4-Lo78A-TE-001	٤	E3 404
#RSX	RSX-11M	RSX-11M/M+ SYSTEM MANAGEMENT GDE (UPD41)	4.1	AA-Lo79B-TC-001	o	NOV 83
#RSX	RSX-11M-FLUS	RSX-11M-m-PLUS SYSTEM MANAGEMENT GRE (UFD#1)	2.1	##-L5778-TC-001	C	NOV 93
#RGX	RSX-11S	RSX-11H/H+ SYSTEM MANAGEMENT GUIDE (UFD41)	4.1	AA-L679B-10-001	ć	NOV 83

OPERATING SYSTEM	PRODUCT NAME	TITLE OF MANUAL	VERSION	PART NUMBER REV LEVEL	NUMBER OF FICHE	DATE
#RSX	RSX-11H	RSX-11M/N-PLUS TASK BLDR MANUAL (UPD#1)	4.1	AA-L680B-TC-001	5	10V 83
*RSX	RSX-11H-FLUS	RSX-11M-M-FLUS TASK BUILDER MANUAL	2.1	AA-L680B-TC-001	5	NOV 83
#RSX	RSX-115	RSX-11m/N-FLUS TASK BUILDER MANUAL	4.1	AA-L680E-TC-001	5	NOV 83
#RSX	FROFESSIONAL HOST TOOL KIT	RSX-11m/M-PLUS TASK BUILDER MANUAL	1.0-2.0	AA-L680E-TC-001	5	JAN 64
#RSX	RSX-11M	RSX-11m/h-PLUS UTILITIES MANUAL (UPR#1)	4.1	AA-Lo81A-TC-001	5	NOV 83
*RSX	RSX-11M-FLUS	RSX-11H/H-PLUS UTILITIES MANUAL (UPD#1)	2.1	AA-L681A-TC-001	6	NOV 53
#RSX	RSX-11H	RMS-11: AM INTRODUCTION	4.1	##-L682#-TE-001	1	HOV 83
#RSX	RSX-11m-PLUS	RMS-11: AN INTRODUCTION	2.1	AA-L682A-TC-001	1	MOV 83
#RSX	RSX-11M	INTRODUCTION TO RSX-11H AND RSX-11H-FLUS	4.1	AA-L753A-TC-001	2	HOV 83
#RSX	RSX-11M-FLUS	INTRODUCTION TO RSX-11h AND RSX-11h+	2.1	AA-L753A-TC-001	2	NOV 83
#RSX	RSX 11/PROVUE	PROVUE SYSTEM MANAGER'S GUIDE	2.0	AA-m0218-TK-001	1	JAN 84
4RSX	RSX 11/PROVUE	PROVUE SYSTEM BUILD MANUAL	2.0	AA-MU22B-Tr001	1	JAN 84
#RSX	RSX 11/PROVUE	PROVUE TERMINAL USER'S GUIDE	2.0	AA-#023B-**-001	1	JAN 84
#RSX	RSX 11/FROVUE	PROVUE OFFLINE FICTURE SYSTEM MANUAL	2.0	AA-M024E-TN-001	1	JAN 84
#RSA	RSx 11/FROVUE	PROVUE ONLINE FICTURE SYSTEM MANUAL	2.0	AA-N025B-TN-001	1	JAN 84
#RSX	RSX 11/FROVUE	FROVUE FROGRAMMING GUIDE	2.0	AA-m026B-TK-001	1	JAN 84
*RSX	RSX 11/FROVUE	PROVUE UTILITY GUIDE	2.0	AA-M027B-TN-001	1	JAN 84
#RSX	RSX 11M F ENHANC FKG FOR KINC	RELEASE NOTES FOR RSX-11M/FEF AND FRF	1.2	AA-#055P-TC-001	1	JAM 84
#RSX	RSX 11/PROVUE	PROVUE V2.0 FELEASE NOTES	2.0	AA-m0898-TK-001	1	JAN 84
RSX	DECNET-11M	OVERVIEW OF RSX DECNET	3.1	AA-M096A-TC-001	2	FEB 84
*RSX	DECNET-11m	OVERVIEW OF RSX DECMET	4.0	4A-n076H-TC-001	2	MHY 84
RSX	DECNET-11M	RSX-DECNET REFERENCE GUIDE	3.1	AA-H097A-TC-001	1	FEB 84
RSX	DECNET-11M	RSX DECNET PROGRAMMER'S REF MANUAL	3.1	44-H093A-TC-001	5	FER 84
#RSX	DECNET-11H	RSX DECNET PROGRAMMER'S REFERENCE MANUAL	4.0	AA-M0988-TC-001	4	MAY 84
*RSX	RSX-11M	IAS/RSX-11 I/O OPERATIONS REFFRENCE MANUAL	4.1	4A-M17oA-TC-001	3	KOV 83
*RSX	RSX-11H-PLUS	IAS/RSX-11 I/O OPERATIONS REFERENCE MANUAL	2.1	AA-H176A-TC-001	3	NOV 83

PART TITLE NUMBER NUMBER OPERATING PRODUCT OF REV OF SYSTEH NAME VERSION HANUAL LEVEL FICHE DATE **#RSX** RSX-11S IAS/RSX-11 I/O OPERATIONS REFERENCE MANUAL **NOV 83** 4.1 AA-M176A-TC-001 3 **#RSX** COROL-S1/RSX RSX-11M/N-FLUS USER'S GUIDE 2.0 AA-#1798-TC-001 5 JAN 84 **#RSX** FROFESSIONAL TOOL KIT COROL-81 RSX-11M/M-PLUS USER'S GUIDE 2.1 AA-M1798-TC-001 5 MAY 84 #R'SX COBOL-S1/RSX RSX-11M/M-FLUS INSTALLATION/RELEASE NOTES 2.0 AA-N181C-TC-001 i JAN 84 *RSX IEC-11H IEC-11M RSX SOFTWARE MANUAL AA-d275A-YC-001 1 SEP 82 3.0 #RSX RSX 11 PSI/H INTRODUCTION TO RSX-11 FSI 2.0 AA-M369A-T0-001 1 SEF 82 #RSX RSX 11 FSI/M RSX-11 PSI CYSTEM MANAGER'S GUIDE SEP 82 2.0 AA-M370A-TE-001 3 **#RSX** RSX 11 FSI/H RSX-11 PSI USER'S GUIDE 2.0 SEF 82 AA-M371A-TC-001 2 #RSX RSX 11 PSI/H RSX-11 PSI GENERATION GUIDE **SEP 82** 2.0 AA-H372A-T0-001 2 #R'SX RSX 11 PSI/M RSX-11 PSI METWORK SPECIFIC INFORMATION SEF 82 2.0 AA-M373A-IE-001 1 #RSX SEP 82 RSX 11 PSI/H RSX-11 FS1 RELEASE NOTES 2.0 AA-M374A-TC-001 1 *RSX MICROPOWER/PASCAL-RSX INTRODUCTION TO MICROPOWER/PASCAL 1.5 AA-M388A-TC-001 1 JUL 84 #RSX MICROFOWER/PASCAL-RSX MF/F LANGUAGE GUIDE (UFD 11) 1.5 4A-H3890-TC-001 5 JUL 34 *RSX HICROPOWER/PASCAL-RSX MF/F-RT RUNTIME SERVICE MANUAL (UFD \$1) 1.5 AA-K3918-TC-001 6 JUL 84 **#RSX** MICROPOWER/FASCAL-RSX MP/F DEBUGGER USER'S GUIDE (UPD41) 1.5 AA-6393B-TC-001 2 **JUL 84** #RSX RSX-11H EDT EDITOR MANUAL 4.1 AA-m476A-TK-0u1 8 FEB 84 #RSX RSX-11m-PLUS EBT EDITOR MANUAL 3.1 66-84766-TK-001 8 FEB 84 #RSA RSX-11H EDT QUICK REFERENCE MANUAL 4.1 AA-M477A-Th-001 1 FER 84 #RSX RSX-11M-PLUS ELT QUICK REFERENCE MANUAL 2.1 AA-M477A-IN-001 1 FEB 84 #RSX RSX-11H IAS/RSX-11 ODT REFERENCE HANUAL 4.1 AA-H507A-TC-001 1 HOV 83 #RSX RSx-IIM-FLUS IAS/RSX-11 ODT REFERENCE MANUAL 2.1 AA-M507A-TC-001 1 HOV 83 4RSX RSX-11S IA5/R3X-11 ODT REFERENCE MANUAL AA-M507A-15-001 1 MGV 83 4.1 #RSX PROFESSIONAL HOST TOOL NIT IAS/RSX-11 ODT REFERENCE MANUAL #A-#5074-TC-001 1 APR 83 1.0-2.0 F:SX VSVII-H DRIVER VSV11-M V2.0 RELEASE NOTES 2.0 AA-M5:5A-TE-001 1 JAN 34 #R'SX VTV31-K RSX11M DRIVE/SUB PKG VTV31-K/RSX DEVICE DRV AND SUBROUTINE LIBRARY 1.0 AFR 83 4A-13094-TC-001 1 #RSX RGL-11 RGL-11 PROGRAMMER'S REFERENCE MANUAL AA-MS37A-TC-001 3 AFR 83 1.1

OPERATING SYSTEM	FRODUCT NAME	TITLE OF MANUAL	VERSION	PART NUMBER REV LEVEL	NUMBER OF FICKE	DATE
*RSX	RSX 11H F ENHANC PKG FOR HINC	RGL/11 FROGRAMMER'S REFERENCE MANUAL	1.1-1.2	AA-M837A-TC-001	3	APR 83
*RSX	RGL-11	RGL-11 INSTALLATION GUIDE	1.1	AA-M838A-TC-001	1	AFR 83
RSX	RGL-11	RELEASE NOTES FOR RGL-11	1.1	AA-M839A-TC-001	1	APR 83
4RS\	RGL-11	RELEASE NOTES FOR RGL-11	1.1	AA-M839E-TC-001	1	FEB 84
#R5X	RSX MDE/T11	HDE/T-11 USER'S GDE/REF MANUAL	1.0	AA-M845B-TK-001	3	APR 83
RSX	FASCAL/RSX, FDF-11	PDF-11 FASCAL LANGUAGE REFERENCE MANUAL	1.0	AA-M875A-TC-001	2	JAN 84
#RSX	FASCAL/RSX, FDF-11	PDF-11 PASCAL LANGUAGE REF MANUAL (UPI#1)	1.1	AA-m875A-TC-002	2	FEB 84
RSX	FASCAL/RSX, FDF-11	FOF-11 FASCAL USER'S GUIDE	1.0	AA-HS76A-TC-001	2	JAN 84
*RSX	FASCAL/RSX, FDF-11	PDF-11 PASCAL USER'S GUIDE (UPD41)	1.1	4A-m876A-TC-002	2	FER 84
RSX	PASCAL/RSX, FUF-11	PEF-11 PASCAL INSTALLATION GDE/REL NOTES	1.0	AA-H8774-TC-001	1	JAN 84
#RSX	FASCAL/RSX, FDF-11	PDF-11 PASCAL INSTALLATION GDE/REL MOTES	1.1	AA-H8778-TC-001	1	MAY 84
RSX	CHF11/CHV11 SOFTWARE DRIVER	CHR11/CHV11 SOFTWARE DRIVER USERS GUIDE	1.0	AA-N060A-TC-001	1	APR 63
#RSX	CHR11/CHV11 SOFTWARE DRIVER	CHR11/CHV11 SOFTWARE DRIVER USER'S GUIDE	3.0	AA-N060B-TC-001	1	FEB 84
RSX	CMR11/CMVI1 SOFTWARE DRIVER	CHR11/CHV11 SOFTWARE DRIVER REFERENCE MANUAL	1.0	AA-N061A-TC-001	1	APR 83
*RSX	CHR11/CMV11 SOFTWARE DRIVER	CHR11/CHV11 SOFTWARE DRIVER REFERENCE MANUAL	3.0	AA-N061E-TC-001	1	FE8 84
*RSX	DE.W	DFM/DFM PLUS RELEASE NOTES	4.1	AA-N150A-TC-001	1	SEF 82
RSX	BCP	RSX-11M BCF USER'S GUIDE	1.0	AA-N269A-TC-001	2	SEP 82
*RSX	BCF	BCP USER'S GUIDE	1.0	AA-N267E-TK-001	2	FER 64
RSX	RTEM-11	RTEM-11 USER'S MANUAL	1.1	AA-N435B-TK-001	2	JAN 84
*RSX	RTEH-11	RTEH-11 USER'S GUIDE	2.0	AA-N435C-TN-001	2	MAY 84
RSX	RTEn-11	RTEM-11 INSTL GUIDE/RELEASE NOTES (UPD41)	1.1	AA-N436A-TK-001	2	JAN 84
#RSX	RTEM-11	RTEM-11 INSTALLATION GUIDE	2.0	AA-N436E-TK-001	1	mAY 84
*RSX	NMV11-A HDLC FRAMING SOFTWARE	KMV11-A HDLC FRAMING SETWARE FOR RSX REF MAN	1.0	AA-NS65A-TC-001	1	APR 83
RS.	PROFESSIONAL HOST TOOL KIT	TOOL NIT DOCUMENTATION DIRECTORY	1.0	AA-N615E-TK-001	1	JAN 84
οςχ	PROFESSIONAL HOST TOOL KIT	TOOL NIT DOCUMENATION DIRECTORY	1.0	AA-N6150-TK-001	1	nay 84
RSX	PROFESSIONAL HOST TGOL KIT	FRO TOOL KIT INSTE GUE/REL HTS	1.0	AA-N616R-TA-001	i	JAN 84

OPERATING SYSTEM	PRODUCT NAME	TITLE OF MANUAL	VERSION	PART NUMBER REV LEVEL	NUMBER OF FICHE	DATE
RSX	PROFESSIONAL HOST TOOL KIT	TOOL KIT USER'S GUIDE	1.0	AA-R617C-TK-001	3	HAY 84
RSX	PROFESSIONAL HOST TOOL KIT	CORE GRAPHICS LIBRARY MANUAL	1.0	AA-N619A-TK-001	2	AFR 83
RSX	PROFESSIONAL HOST TOOL KIT	CORE GRAPHICS LIBRARY HAMUAL	1.0	AA-N619B-TK-001	2	HAY 84
RSX	FROFESSIONAL HOST TOOL KIT	F/OS SYSTEM REFERENCE MANUAL	1.0	AA-N620A-TK-001	4	APR B3
*RSX	PROFESSIONAL HOST TOOL KIT	P/OS SYSTEM REFERENCE MANUAL (UPD#2)	1.0-2.0	AA-N620A-TK-002	4	JUL 84
*RSX	PROFESSIONAL HOST TOOL KIT	DOCUMENTATION GUIDE LINES	1.0-2.0	AA-N621A-TK-001	1	AFR 83
*RSX	PROFESSIONAL HOST TOOL KIT	TERHINAL SUBSYSTEM MANUAL	1.0-2.0	AA-N623B-TK-001	2	JAN 84
RSX	OFSERVER	OBSERVER INSTL GUIDE AND GEN GUIDE	1.0	AA-N959A-TC-001	1	APR 83
*RSX	OBSERVER	OBSERVER INSTL GUIDE AND GEN GUIDE	1.1	AA-N959E-TC-001	1	FEB 84
RSX	OBSERVER	OBSERVER USER'S GUIDE	1.0	AA-N960A-TC-001	3	APR 83
*RSX	ORSERVER	OBSERVER USER'S GUIDE	1.1	AA-N760B-TC-001	3	FEB 84
RSX	OBSERVER	OBSERVER RELEASE NOTES	1.0	AA-N962A-TC-001	1	APR 83
*RSX	OBSERVER	OBSERVER RELEASE NOTES	1.1	AA-N962B-TC-001	1	FEB 64
≭ RSX	RSX HDE/T11	RSX11H/H+ HDE/T11 SFTW INSTE GDE/REL NTS	1.0	AA-N978A-TC-001	1	AFR 83
RSX	PROFESSIONAL TOOL KIT DIBOL	INTRODUCTION TO DIFOL	1.0-1.6	AA-F042A-TK-001	1	APR 83
≭ RSX	PROFESSIONAL TOOL KIT DIFOL	INTRODUCTION TO DIBOL	1.6	AA-F0428-TK-001	1	JUL 84
RSX 11 PLU	RSX 11H FLUS DIBOL	PRO TOOL KIT INTRODUCTION TO DIBOL-83	1.0	AA-F042B-TK-001	1	JUL S4
RSX	PROFESSIONAL TOOL KIT DIROL	PROFESSIONAL TOOL KIT DIBOL USER'S GUIDE	1.0	AA-F043A-TK-001	2	APF: 83
*RSX	PROFESSIONAL TOOL NIT DIPOL	PROFESSIONAL TOOL KIT DIBOL USER'S GUIDE	1.6	AA-F043C-TK-001	2	MAY 84
RSX	PROFESSIONAL TOOL KIT DIBOL	PROFESSIONAL TOOL NIT DIBOL LANG REF MANUAL	1.0	AA-F044A-TK-001	3	AFR 83
RSX	PROFESSIONAL TOOL KIT DIFOL	PROFESSIONAL TOOL NIT DIBOL REL NTS/INSTL GDE	1.0	AA-F045A-TN-001	1	AFR 83
#RSX	PROFESSIONAL TOOL KIT DIFOL	PROFESSIONAL TOOL KIT PIROL REL NTS/INSTL GDE	1.6	AA-F045E-IK-001	1	MAY 84
*RSX	PROFESSIONAL HOST TOOL KIT	PRO/RHS-11: AN INTRODUCTION	1.0-2.0	AA-E09SA-TN-001	1	APR 83
#RSX	PROFESSIONAL HOS ' TOOL KIT	FRO/RMS-11 MACRO FROGRAMMER'S GUIDE	1.0-2.0	AA-P099A-TK-001	5	APR 83
RSX	PROFESSIONAL TOOL KIT BASIC-FLUS-2	BASIC-PLUS-2 DOCUMENTATION SUPPLEMENT	2.1	AA-P102E-TN-001	1	JAN 84
#RSX	PROFESSIONAL TOOL KIT BASIC-FLUS-2	BASIC-PLUS-2 DOCUMENTATION SUPPLEMENT	2.2	AA-P102C-Th-001	1	hAY 84

OPERATING SYSTEM	G PRODUCT NAME	TITLE OF MANUAL	VERSION	PART Number Rev Level	NUMBER OF FICHE	DATE
*RSX	PROFESSIONAL HOST TOOL KIT	PRO/FMS-11 DOCUMENTATION SUPPLEMENT	1.0-2.0	AA-F103E-TK-001	1	JAN 84
RSX	PROFESSIONAL TOOL KIT FASIC-PLUS-2	PRO TOOL KIT BASIC + 2 INSTL GDE/REL NTS	2.1	AA-F104F-TK-001	1	JAN 84
*RSX	PROFESSIONAL HOST TOOL KIT	TAS/RSX ODT REFERENCE MANUAL SUPPLEMENT	1.0-2.0	AA-F193B-TK-001	1	JAN 84
*RSX	PROFESSIONAL REAL TIME INTERFACE LI	PRTIL PRGHRS REFERENCE MANUAL	1.1	AA-P411A-TK-001	3	JUL 84
RSX	PROFESSIONAL HOST COMMUNICATIONS	PROFESSIONAL HOST COMM INSTL PROCEDURES	1.5	AA-P412B-TK-001	1	JAN 84
#RSX	PROFESSIONAL HOST COMMUNICATIONS	FROFESSIONAL HOST COMM INSTL FROCEDURES	1.7	AA-F'412C-TK-001	1	MAY 84
*RSX	RSX 11M FLUS DECTYFE	DECTYPE REFERENCE MANUAL	3.0	AA-R124B-TK-001	2	JUL 84
RSX 11 FLL	J RSX 11% PLUS DECTYPE	USING DECTYPE	3.0	AA-R125B-TK-001	3	JUL 64
*RSX	PROFESSIONAL TOOL KIT FORTRAN-77	PRO HOST TK F-77 1G/DOC SUPL	5.0	AA-R387B-TK-001	1	JAN 84
*RSX	IEX-RSX DRIVER	IEX-RSX USERS & INSTALLATION GUIDE	2.0	AA-R472A-TC-001		OCT 84
RSX	FROFESSIONAL TOOL KIT PASCAL	PRO TOOL NIT PASCAL INSTL/REL NOTES	1.1	AA-R759B-TK-001	1	MA1 84
*RSX	PROFESSIONAL TOOL KIT PASCAL	FRO TOOL KIT PASCAL INSTL GDE/RELEASE NOTES	1.2	AA-R7590-TK-001	1	JUL 84
*RSX	FORTRAN IV/RSX	FDF-11 FORTKAN LANGUAGE REFERENCE MANUAL	2.6	AA-R953A-TK-001	2	JAN 84
*RSX	FORTRAN IV/RSX	RSX/VMS FORTRAN IV INSTALLATION/REL NTS	2.6	AA-R954A-TK-001	1	JAN 84
*RSX	FORTRAN IV/RSX	RSX/VAX/VMS FORTRAN IV USER'S GUIDE	2.6	AA-R955A-TN-001	2	JAN 84
*RSX	PROFESSIONAL TOGE KIT FASCAL	PRO TOOL KIT PASCAL USER'S GUIDE	1.1-1.2	AA-U046A-YK-001	2	JAN 8ª
#RSX	PROFESSIONAL TOOL NIT FASCAL	FRO TOOL KIT FASCAL LANGUAGE REFERENCE MANUAL	1.1-1.2	AA-U047A-TN-001	2	JAN 84
#RSX	DATATRIEVE-11	DATATRIEVE-11 REFERENCE HANUAL	3.0	AA-U049A-TK-001	4	FEF 84
*RSX	DATATRIEVE-11	DATATRIEVE-11 CALL INTERFACE MANUAL	3.0	AA-U050A-TE-001	2	JAN 84
*RSX	DATATRIEVE-11	DATATRIEVE-11 GUIDE TO WRITING REFORTS	3.0	AA-U051A-Th-001	1	FEB 84
#RSX	DATATRIEVE-11	DATATRIEVE-11 SUMMARY DESCRIPTION	3.0	AA-U052A-T0-001	1	JAN 84
*RSX	PROFESSIONAL TOOL KIT DIROL	DIBOL-83 LANGUAGE REFERENCE MANUAL (UFD#1)	1.6	AA-UG66A-TK-001	2	FEB B4
RSX 11 FLU	J RSX 11M PLUS DIBOL	DIBOL-83 LANGUAGE REFERENCE MANUAL (UFD#1)	1.0	AA-U066A-TK-001	2	JUL 84
RSX	FROFESSIONAL TOOL KIT DIROL	DIBOL LANGUAGE REFERENCE CARD	1.6	44-U0674-TN-001	1	hay 84
*RSX	RSX-11M	FDF-11 MACRO-11 LANGUAGE REF MANUAL.	4.1	AA-V027A-1C-001	3	NOV 83
*RSX	RSX-11H-FLUS	PIP-11 MACRO-11 LANGUAGE REFERENCE MANUAL	2.1	AA-V027A-TC-001	3	NOV 83

OPERATING SYSTEM	PRODUCT NAME	TITLE OF MANUAL	VERSION	PART NUMBER REV LEVEL	NUMBER OF FICHE	DATE
*RSX	RSX-11S	FDF-11 MACRO-11 LANGUAGE REFERENCE MANUAL	4.1	AA-V027A-TC-001	3	NOV 83
#RSX	HICROPOWER/PASCAL-RSX	PDF-11 MACRO-11 LANGUAGE REFERENCE MANUAL	1.5	AA-V027A-TC-001	3	JUL 64
*RSX	PROFESSIONAL HOST TOOL KIT	PDP-11 MACRO-11 LANGUAGE REFERENCE MANUAL		AA-V027A-TC-001		JAN 34
*RSX	FORTRAN-77/RSX, PUP-11	FDF-11 FORTRAN-77 LANGUAGE REFERENCE HANUAL	5.0	AA-V193A-Th-001		FER 84
#RSX	FROFESSIONAL TOGL KIT FORTRAN-77	PDF-11 F-77 LANGUAGE REFERENCE HANUAL	5.0	AA-V193A-TK-001		FEB 84
₽RSX	FORTRAN-77/RSX+ PBF-11					
		PDF-11 FORTRAN-77 USER'S GUIDE	5.0	AA-V194A-TK-001		FER 84
*RSX	PROFESSIONAL TOOL NIT FORTRAN-77	PDP-11 FORTRAN-77 USER'S GUIDE	5.0	AA-V194A-TK-001	3	FER 84
#RSX	FORTRAN-77/RSX, FDF-11	FDF-11 FORTRAN-77 OTS REFERENCE MANUAL	5.0	AA-V195A-TK-001	2	FER 84
*RSX	PROFESSIONAL TOOL KIT FORTRAN-77	FIR-11 FORTEAN-77 CTS REFERENCE MANUAL	5.0	AA-V195A-TN-001	2	FEB 84
4RSX	FORTRAN-77/RSX, FDF-11	PDF-11 FORTRAN-77 INSTL GUIDE/REL NOTES	5.0	AA-V196A-TK-001	1	JAN 84
*RSX	FORTRAN-77 DEBUG, PDF-11	FDF-11 FORTRAN-77/DEBUG USER'S GUIDE	1.0	AA-V197A-TN-001	2	JAN 84
#R'SX	PROFESSIONAL TOOL KIT DIROL	DIROL-83 COMPATIBILITY MANUAL	1.6	AA-V810B-TK-001	1	MAY 34
RSX 11 PLU	J RSX 11M FLUS DIBOL	DIBOL-83 COMPATIBILITY GUIDE	1.0	AA-V810B-TK-001	1	JUL 84
*RSX	DKU11-C RSX-11 DRIVER	DRU11-C RSX11M/H+ SOFTWARE MANUAL	4.2	AA-W152A-Τζ-001	1	JUL 84
RSX	RSX-11S	RSX-11M/11S V4.1 UPDATE B INFORMATION	4.1	AA-W259B-TC-001	1	FE8 84
#RSX	RSX-11S	RSX-11M/11S V4.1 UPDATE C INFORMATION	4.1	AA-W2596-TC-001	1	MAY 84
*RSX	RTEM-11	RTEM-11 RELEASE NOTES	2.0	AA-W325A-TN-001	1	MAY 84
≉RSX	DATATRIEVE-11	DATATRIEVE-11 INSTALLATION GDE/REL NOTES	3.0	AA-X022A-TE-001	1	JAN 84
#RSX	DATATRIEVE-11	DATATRIEVE-11 USER'S GUIDE	3.0	AA-X023A-TN-001	3	FEB S4
#RSX	DATATRIEVE-11	INTRODUCTION TO DATATRIEVE-11	3.0	AA-X025A-TK-001	1	FEB 84
*RSX	OBSERVER	OBSERVER EVENT MESSAGE REFERENCE MANUAL	1.1	AA-X074A-TC-001	2	JUL 84
#RSX	DATATRIEVE-11	DATATRIEVE-11 FOCKET GUIDE	3.0	AA-X103A-TK-001	i	FEB 84
#RSX	DECNET-11M	OVERVIEW TO DIGITAL KETWORK PROCEDURES	4.0	AA-X105A-TN-001	2	MAY 84
*RSX	FORTRAN-77 DEBUG, FDF-11	FORTRAN-77/DEBUG INSTAL GUIDE/REL NOTES	1.0	AA-X650A-TN-001	1	JAN 84
RSX	PROFESSIONAL HOST TOOL KIT	PRO/TOOL KIT DOCUMENATION DIRECTORY	1.0	AA-X910A-TH-001	1	MAY 84
RSX	PROFESSIONAL HOST TOOL NIT	PRO/TOOL KIT INSTALLATION GDE/RELEASE HOTES	1.0	AA-x911A-TH-001	1	MAY 84

OPERATING SYSTEM	FRODUCT Name	TITLE OF MANUAL	VERSION	PART NUMBER REV LEVEL	NUMBER OF FICHE	DATE
*RSX	PROFESSIONAL HOST TOOL NIT	PRO/TOOL NIT INSTALLATION GUIDE/RELEASE NOTES	2.0	4A-X911B-TH-001	1	JUL 84
*RSX	PROFESSIONAL HOST TOOL KIT	PRO/TOOL KIT COMMAND LANG/UTILITIES MANUAL	1.0-2.0	AA-X912A-TH-001	5	hAY 84
#RSX	DECNET-11m	USERS/FROGRAMMERS MINI REFERENCE GUIDE	4.0	AA-X923A-FC-001	1	JUL 84
#RSX	DECNET-11H	DECNET RSX SYSTEM MANGER'S MINI REF GUIDE	4.0	AA-X924A-TC-001	1	HAY 64
*RSX	PROFESSIONAL TOOL NIT COROL-81	PRO TOOL KIT COBOL-81 INSTE GDE/DOC SUPL	2.1	AA-Y285A-TH-001	1	JUL 84
4RSX	HICROPOMER/PASCAL-RSX	KXT11-C SOFTWARE USER'S GUIDE	1.5	AA-Yc15A-TK-001	2	JUL 84
*RSX	PROFESSIONAL HOST TOOL KIT	FRO GIDIS MANUAL (UFD#1)	2.0	##-Y560#-TH-001		OCT 84
*RSX	PROFESSIONAL TOOL WIT FORTRAN-77 DE	PRO TOOL KIT FORTRAN-77/DBG IG/DOC SUPL	1.0	AA-Z384A-IK-001	1	may 84
*RSX	PROFESSIONAL TOOL KIT DIPOL	PRO 100L NII MESSAGE MANUAL	1.6	AA-Z515A-TN-001	1	FEB S4
RSX 11 FLU	RSX 11M FLUS DIFOL	me/hicro RSX Dirol USER'S GUIDE	1.0	4A-Z885A-TC-001	2	JUL 84
RSX 11 PLU	RSA 11M PLUS DIBOL	m+/micro RSX DIBOL RELEASE NOTES/INSTL GDE	1.0	A4-2886A-TC-001	1	JUL 84
RSX 11 FLU	RSX 11H PLUS DIBOL	HE/MICRO RSX DB MESSAGE MANUAL	1.0	AA-Z887A-TC-001	1	JUL 64
RSX 11 PLU	RSX 11M PLUS DECTYPE	INSTALLING AND MANAGING DECTYPE	3.0	AA-Z9a0A-TC-001	1	JUL 64
RSX	RSX-11M	RSX-11M V4.1 SFD 14.35.20	4.1	AE-3407U-TC-001	1	FER 84
*RSX	RSX-11n	RSX-11M V4.1 SFD 14.32.21	4.1	AE-3407V-TC-001	1	may 84
RSX	SSF-11	SSP-11 V1.3 SFD 15.45.9	1.3	AE-3413H-TC-001	1	FES 84
*RSX	SSF-11	SSF-11 V1.3 SPD 15.45.10	1.3	AE-3413I-TC-001	1	may 84
*RSX	FDF-11 COBOL	FDF-11 COROL V4.4 SFD 12.40.18	4.4	AE-34175-IC-001	1	FEE 84
RSX	RSX-11S	RSX-115 V4.1 SFD 9.21.13	4.1	AE-3427N-FC-001	1	FEB 34
#RSX	RSX-11S	RSX-115 V4.1 SFB 09.21.14	4.1	AE-34270-TC-001	1	hAY 84
RSX	DECNET-11M	DECNET-11h V4.0 SFD 10.75.10	4.0	AE-3431K-TE-001	1	hat 34
#R'SX	DECNET-11H	DECNET-11H V4.0 SPD 10.75.11	4.0	AE-3431L-TC-001	1	JUL 84
*RSX	DECNET-11H	DECNET-115 V4.0 SPD 10.74.12	4.0	AE-3432M-T0-001		007 84
RSX	FORTRAN IV/RSX	FORTRAN IV/RSX V2.6 SFD 14.63.9	2+6	AE-3443J-TC-001	1	FER 64
*RSX	FORTRAN IV/RSA	FORTRAN IV/RSX V2.6 SPD 14.63.10	2.6	AE-3443K-TC-001	1	mAY 84
#RSX	CORAL-66	CDRAL-66 V4.0 SPN 14.56.10	1.0	AE-3450I-FC-001	1	MAY 84

OPERATING SYSTEM	FRODUCT NAME	TITLE OF	UFFORON	PART NUMBER REV	NUMESE OF	
		MANUAL	VERSION		FICHE	IATE
*RSX	HUX200/RSX-IAS	HUX200/RSX-IAS V2.1 SFD 10.77.0	7 2.1	AE-3453I-TC-001	1	FER 84
*RSX	UN1004	UN1004 V2.0 SFD 10.79.06	2.0	AE-3454G-TC-001	1	FEB 84
*RSX	RSX 11M TAS RJE/HASP	RSX11M IAS RJE/HASP V1.1 SFD 10	.51.6 1.1	AE-5248G-TC-001	1	FEB 84
*RSX	DX/11H	DX/11M V3.1 SFD 10.96.4	3.1	AE-5274F-TC-001	1	FER 84
RSX	SORT-11	SDRT-11 V2.0 SPD 12.7.5	2.0	AE-5429G-TC-001	1	FER 84
#R'SX	SORT-11	SURY-11 V3.0 SFD 12.07.07	3.0	AE-5429H-TC-001	1	JUL 84
#RSX	DFM	DFM V4.1 SFD 15.6.6	4.1	AE-5730H-TC-001	1	FEB 84
*RSX	COMM TOP-DUP	ADDENDUM TO S. J	1.0	AE-FF27A-TN-001	1	MAY 34
*RSX	COMM IOF-I/Z	ADDENBUR TO SED	1.0	AE-BB27A-TK-001	1	MAY 84
*RSX	DX/11m	ADDENDUM TO SED	3.1	AE-RF27A-TK-001	1	MAY 84
*RSX	LABORATORY SUBROUTINE FACAGE	ADDENDUM TO SPD	1.2	AE-8827A-TN-001	1	hAY 84
#RSX	FROFESSIONAL REAL TIME INTERFACE LI	ADDENDUM TO SPD	1.1	AE-8827A-TK-001	1	JUL 64
*RSX	SSF-11	ADDENDUM TO SPD	1.3	AE-BB27A-TN-001	1	MAY 84
RSX 11 PLU	RSX 11M PLUS DECTYPE	BECTYPE V3.0 SFB 14.82.00	3.0	AE-RG31A-TC-001	1	JUL 84
*RSX	MICROPOWER/PASCAL-RSX	MP/F RSX SFD 14.83.00	1.5	AE-BK29A-TC-001	1	JUL 84
#RSX	PROFESSION, REAL TIME INTERFACE LI	PRO/TK PRTIL V1.1 SPD 40.35.01	1.1	AE-BLS2B-TH-001		OCT 84
*RSX	DRU11-C RSX-11 DRIVER	DRU11-C RSX SFD 13.35.00	4.2	AE-BF37A-TC-001	1	JUL 84
*RSX	kMC-11 TOOLS	KMC-11 TOOLS V1.0 SPD 12.49.04	1.0	AE-C776E-TC-001	1	MAY 84
RSX	DATATRIEVE-11	DATATRIEVE-11 V3.0 SFD 12.48.11	3.0	AE-C777L-TC-001	1	HAY 84
1SX	DATATRIEVE-11	DATATRIEVE-11 V3.0 SFI 12.48.12	3.0	AE-0777M-T0-001	1	JUL 84
#RSX	COMM TOP-DUP	COMM 10F-DUF V1.0 SFD 10.12.04	1.0	AE-B121E-TC-001	1	JUL 84
*RSX	CONH IOP-IZ	COMM 16F-DZ V1.0 SFD 10.11.04	1.0	AE-I/122E-TC-001	1	JUL 84
RSX	LABORATORY SUBROUTINE FACKAGE	LSF V1.2 SFI: 15.44.5	1.2	AE-D607F-T0-001	1	FEB 84
*RSX	LABORATORY SUBROUTINE PACKAGE	LSF V1.2 SPD 15.44.06	1.2	4E-D607G-TE-001	1	MAY 84
RSX	RSX-11H-FLUS	RSX~11M~PLUS V2.1 SFD 14.70.08	2.1	AE-H862I-TC-001	1	FEB 84
*RSX	RSX-11M-FLUS	RSX-11M-FLUS V2.1 SFT 14.70.09	2.1	AE-H862J-TC-001	í	JUL 84

OFERATING SYSTEM	PRODUCT NAME	TITLE OF MANUAL	VERSION	FART NUMBER REV LEVEL	NUMBER OF F1CHE	DATE
RSX	FORTRAN-77/RSX, PDF-11	PDF-11 FORTRAN-77/RSX V5.0 SFD 14.31.06	5.0	AE-J1396-TC-001	1	FER 84
#RSX	FORTRAM-77/RSX. PDF-11	PDP-11 FORTRAN-77/RSX V5.0 SPD 14.31.07	5.0	AE~J139H-TC-001	1	HAY S4
RSX	BASIC-PLUS-2 FOR RSX-11H/H-FLUS	BASIC-PLUS-2 V2.1 SP% 14.11.8	2.1	AE-J1971-TC-001	1	FE8 84
RSX	BASIC-FLUS-2 FOR RSX-11M/M-FLUS	RASIC-PLUS-2 V2.2 SPD 14.11.10	2.2	AE-J197K-T0-001	1	MAY 84
#RS\	BASIC-PLUS-2 FOR RSX-11N/H-PLUS	BASIC-PLUS-2 V2.2 SPD 14.11.11	2.2	AE-J197L-TC-001	1	JUL 34
#RSX	FMS-11/RSX	FMS-11/RSX V1.0 SFD 12.27.5	1.0	AE-J405F-TC-001	1	FEB 84
RSX	FHS-11/RSX	FMS-11/R5X V1.0 SFD 12.27.07	1.0	4E-J405H-TC-001	1	JUL 84
*RSX	RSX 11H SNA PE	RSX 11m SNA PE V1.1 SPU 14.04.1	1.1	AE-J5120-T0-001	1	FEB 84
#RSX	DECNET-11H	DECNET-11n+ 12.0 SFD 10.66.05	4,0	AE-J513F-TC-601		OCT 84
+RSX	RSX DLX-11	RSX DLX-11 V1.0 SFD 10.6.0	1.0	AE-14348-10-001	1	FEE 64
*RSX	DT07-11n	DT07-11m V1.1 SFD 14.36.1	1.1	AE-A5348-TC-001	1	FEB 84
1 P3X	FLXY-11H	FLXY-11 V1.3 SFD 14.39.61	1.3	#E-N797E-TC-001	1	hay 84
*RSX	VSV11-A DRIVER	VSV11-m V2.2 SFT 14.53.04	2.2	AE-K851A-TE-601	1	JUL 34
RSX	VSV11-M DRIVER	VSV11-# V2.1 SPD 14.53.03	2.1	AE-K851D-TC-001	1	FEB 84
RSX	RSX 11 2780/3780 EMULATOR	RSX11 2780/3780 EMUL V4.1 SFD 10.01.01	4.1	AE-K9978-TC-001	1	may 84
#RSX	RSX 11 2789/3780 EMULATOR	RSX11 2780/3780 EMUL V4.1 SFD 10.01.02	4.1	AE-K9970-TC-001		001 84
*RSX	ESX 11M F ENHANC PNG FOR MINC	RSX-11M/FEF V1.2 SFD 14.44.4	1.2	AE-L762E-TC-001	1	FEB 84
#RSX	DBHS-11	DBMS-11 V2.1 SPD 12.66.2	2.1	AE-H130B-TC-001	1	FER 84
*RSX	RSX-11H	RSX-11M CROSS REFERENCE TABLE	4.1	AE-H778F-TC-001		QCT 84
4RSX	RSX-11M-FLUS	RSX-11H-PLUS V2.1 CROSS REFERENCE SP1	7.1	AE-H779I-TC-001	1	MAY 84
RSX	RGL-11	RGL-11 V1.1 SPU 14.62.3	1.1	AE-M802[1-TC-001	1	FER 84
*RSX	RGL-11	RGL-11 V1.1 SFD 14.62.04	1.1	AF -M802E-TC-001	1	hAY 84
#RSX ►	IEC-11M	IEC-11m V3.0 SPD 14.54.0	3.0	AE-M029A-16-001	1	FEE 94
*RSX	CHR11/CHV11 SOFTWARE DRIVER	CHR11/CHV11 V3.0 SFD 14.76.01	3.0	AE-N059B-TC-001	1	пнҮ 84
*RSX	RSX 11 FSI/H	RSX-11 PSI/H V2.0 SPD 10.42.0	2.0	AE-N1418-TC-001	1	FEB 84
#RSX	HCF	BCF V1.0 SFD 14.72.0	1.0	AE-N202A-TC-001	1	FER 84

INDEX BY PAFT NUMBER

OPERATING		TITL OF		FART NUMBER REV	NUMBER OF	
SYSTEM	NAME	HANUAL	VERSION	LEVEL	FICHE	DATE
#R5X	RSX 11/FROVUE	PROVUE V2.0 SPD 14.33.1	2.0	AE-N2716-TC-001	1	FEB 84
*RSX	RTEM-11	RTEM-11 V2.0 SFD 30.21.04	2.0	AE-N571E-TK-001	1	MAY 84
RSX	PASCAL/RSX, FDF-11	FDF-11 PASCAL/RSX V1.1 SFD 14.18.02	1.1	AE-N917C-TC-001	1	FEB 84
#RSX	PASCAL/RSX, FUF-11	PDP-11 PASCYL/RSX V1.1 SPD 14.18.03	1.1	AE-N917D-TC-001	1	KAY 84
*RSX	COBOL-81/RSX	COBOL-81 RSX V2.0 SFD 14.26.03	2.0	AE-P077E-TE-001	1	FEB 84
#RSX	UTU31-K RSX11M DRIVE/SUB FKG	VTV31-K/RSX VO SPD 14.73.0	1.0	AE-P079A-TC-001	1	FEB 84
*RSX	RSX MDE/T11	RSX MDE/T-11 V1.0 SFD 14.23.0	1.0	AE-F0818-T0-001	1	FEB 84
#RSX	OBSERVER	OFSERVER V1.1 SFI 13.18.02	1.1	AE-F335C-TC-001	1	HAY 84
RSX	PROFESSIONAL TOOL KIT BASIC-FLUS-2	FRO TOOL KIT BASIC-FLUS-2 V2.2 SPD 30.27.01	2.2	AE-96508-TK-001	1	MAY 84
#RSX	PROFESSIONAL TOOL KIT BASIC-PLUS-2	FRO TOOL AIT BASIC-FLUS-2 V2.2 SFD 30.27.03	2.2	AE-F650D-TK-001	1	JUL 84
*RSX	KHV11-A HDLC FRAMING SOFTWARE	KHV11A-HULC FRAHING SOFTWARE V1.0 SFD 14.22.0	1.0	AE-R298A-TC-001	1	FER 84
RSX	FROFESSIONAL TOOL KIT FOFTRAN-77	FRO TOOL KIT FORTRAN-77 V5.0 SFD 30.38.01	5.0	AE-W587B-Th-001	1	hay 84
*RSX	PROFESSIONAL TOOL KIT FORTRAN-77	FRO TOOL KIT FORTRAN-77 V5.0 SFD 30.38.02	5.0	4E-95870-TK-001	1	JUL 84
*RSX	IEX-RSX DRIVER	IEX-RSX NRIVER V2.0 SPN 12.68.01	2.0	AE-X682E-TC-061	1	JUL 84
*RSX	FORTRAN-77 PERUG, PDF-11	PDF-11 FORTRAN-77 DEBUG V1.0 SFD 30.33.00	1.0	AE-Y3988-TN-001	1	FEB 84
*RSX	PROFESSIONAL TOOL KIT COROL-81	FRO TOOL KIT COBOL-81 V2.1 SFD 40.24.00	2.1	AE-Z754A-TH-001		OCT 84
*RSX	PROFESSIONAL TOOL NIT FORTRAN-77 DR	PRO TOOL KIT FORTRAN-77/DBG V1.0 SPD 40.25.00	1.0	AE-2847A-TH-001	1	JUL 84
#RSX	RSX-11H	RSX-11H MINI REFERENCE	4.1	AV-5570E-TC-001	3	NOV 83
#RSY	RSX-11S	RSX-11M MINI REFERENCE	4.1	AV-5570E-TC-001	3	NOV 83
#RSX	RSX-11H-FLUS	RSX-11M-PLUS MINI REFERENCE	2.1	AV-H435C-TC-00	3	NBN 83
*RSX	COBOL-81/RSX	COBOL-81 FOCKET GUIDE	2.0	AV-H630C-TC-001	2	JAN 84
*RSX	FROFESSIONAL TOOL KIT COROL-81	CCBOL-81 FOCKET GUIDE	2.1	AV-H630C-TC-001	2	HAY 84
*RSX	FHS-11/RSX	FDF11 KEYPAD EDITOR REFERENCE CARD	1.0	AV-H854A-TC-001	1	SEP 82
#R3X	FMS-11/RSX	FMS-11/RSX-11H HINI REFERENCE GUIDE	1.0	AV-H856A-TC-001	1	SEP 82
RSX	RSX-11H	EDT EDITOR REFERENCE CARD	4.1	AV-J756A-TC-001	1	NOV 83
RSX	RSX-11H-PLUS	EDI EDITOR REFERENCE CARD	2.1	AV-J756A-TC-001	1	NOV 83

OPERATING SYSTEH	PRODUCT Name	TITLE OF MANUAL	VERSION	PART NUMBER REV LEVEL	NUMBER OF FICHE	DATE
*RSX	BASIC-PLUS-2 FOR RSX-11M/M-PLUS	BASIC POCKET REFERENCE GUIDE	2.0-2.2	AV-L341A-TK-001	2	APR 83
#RSX	PROFESSIONAL TOOL KIT BASIC-PLUS-2	BASIC POCKET REFERENCE GUIDE	2.0-2.2	AV-L341A-TK-001	2	APR 83
*RSX	DPM	DPM/DPM PLUS REFERENCE GUIDE	4.1	AV-N195A-TC-001	1	SEP 82
*RSX	HICROPOWER/PASCAL-RSX	MP/F REFERENCE CARD	1.5	AV-M395A-TC-001	1	JUL 84
#RSX	RSX 11 PSI/M	RSX-11 PSI REFERENCE CARD	2.0	AV-H749A-TC-001	1	5EP 82
‡RSX	RSX MIJE/T11	MDE/T11 REFERENCE CARD	1.0	AV-M846B-TK-001	1	FER 84
RSX	CHR11/CHV11 SOFTWARE DRIVER	CMR11/CMV11 SOFTWARE DRIVER RELEASE NOTES	1.0	AV-N058A-TC-001	1	APR 83
#RSX	CHR11/CHV11 SOFTWARE DRIVER	CRM11/CHV11 SOFTWARE DRIVER RELEASE NOTES	3.0	AV-N058R-TC-001	1	FER 84
*RSX	BCF	BCP V1.0 RELEASE NOTES	1.0	AV-N2708-TE-001	1	APR 83
#RSX	RSX 11M 3271 PROTOCOL EMULATOR	3270 TERMINAL EMULATOR KEYBOARD LAYOUT	3.0	AV-P075A-TE-001	1	AFR 83
*RSX	RSX MDE/T11	MDE/T-11 V1.0 INSTL GDE/REL NTS	1.0	AV-P511A-TC-001	1	APR 83
*RSX	DRMS-11	BEFORE YOU INSTALL DRMS-11 V2.1	2.1	AV-F666A-TC-001	1	APR 83
RSX 11 PLU	RSX 11M PLUS DECTYPE	DECTYPE KEYBOARD LAYOUT	3.0	AV-R127A-TK-001	1	JUL 84
RSX 11 PLU	RSX 11M PLUS DECTYPE	DETYPE QUICK REFERENCE GUIDE	3.0	AV-R128B-TK-001	1	JUL 84
*RSX	PROFESSIONAL TOOL KIT DIRDL	DIBOL-83 LANGUAGE REFERENCE CARD	1.5	AV-U067A-TK-001	1	JUL 84
RSX 11 PLU	RSX 11M FLUS DIROL	DIBOL-83 LANGUAGE REFERENCE CARD	1.0	AV-U067A-TK-001	1	JUL 84
*RSX	RSX 11M F ENHANC PKG FOR MINC	RGL/11 PROGRAMMERS REFERENCE MANUAL ERRATA	1.2	AV-V185A-TC-001	1	JAN 84
#RSX	RSX 11M F ENHANC PKG FOR MINC	REAL-11 PROGRAMMERS REFERENCE MANUAL ERRATA	1.2	AV-0187A-TE-001	1	JUL 84
#RSX	RSX 11H F ENHANC FKG FOR MINC	SSP REFERENCE MANUAL ERRATA SHEET	1.2	AV-V139A-TC-001	i	JAN 84
*RSX	RSX 11H F ENHANC PKG FOR HINC	LSP REFERENCE MANUAL ERRATA SHEET	1.2	AV-V190A-TE-001	1	JAN 84
*RSX	RSX 11M F ENHANC PKG FOR MINC	INTRO TO FEP & FRP ERRATA SHEET	1.2	AU-U191A-TC-001	1	JAN 84
*RSX	IEC-11M	IEC-11M RELEASE NOTES	3.0	AV-9507A-TC-001	1	FEB 84
*RSX	DATATRIEVE-11	DTR-11 COVER LETTER/BEFORE YOU INSTALL	3.0	AV-X024A-TC-001	1	JUL 84
*RSX	OBSERVER	OBSERVER REFERENCE CARD	1.1	AU-X073A-TC-001	1	FER 84
*RSX	DECNET-11h	DECNET-RSX VOL I SPNST GENERAL INFORMATION	4.0	AV-Y552A-TC-001		OCT 84
#RSX	DECNET-11H	DECNET-RSX VOLUME II USER'S INFORMATION	4.0	AV-Y553A-TC-001		OCT 84

OPERATING SYSTEM	FRODUCT NAME	TITLE OF HANUAL	VERSION	PART NUMBER REV LEVEL	NUMBER OF FICHE	DATE
*RSX	DECNET-11M	DECNET-RSX VOL II SFNST GENERAL INFORMATION	4.0	AV-Y554A-TC-001		OCT 84
*RSX	DECNET-11M	DECNET-RSX VOL IV SPNST GENERAL INFORMATION	4.0	AV-Y555A-TC-001		OCT 84
*RSX	PROFESSIONAL HOST TOOL KIT	PRO/TOOL NIT V2.0 SPD 40.19.01	2.0	BH-Y991B-TH-CO1		OCT 84
*RSX	RSX 11M F ENHANC PKG FOR MINC	MICROCOMPUTERS AND MEMORIES HANDBOOK	1.1-1.2	ER-20912-20-001	8	APR 83
*RSX	RSX 11M F ENHANC PKG FOR MINC	PDP-11 HICROCOMPUTER INTERFACES HANDBOOK	1-1-1-2	EB-23144-18-601	7	APR 83
*RSX	RSX-11M	FDF-11 FROGRAMMING CARD	4.1	EH-S1046-78-001	1	NOV 83
#RSX	RSX-11M-PLUS	PDF-11 PROGRAMMING CARD	2.1	EH-S1046-78-001	1	NOV 83
*RSX	RSX-11S	PDF-11 PROGRAMMING CARD	4.1	EH-S1046-78-001	1	NOV S3
*RSX	HICROPOWER/PASCAL-RSX	FDF-11 PROGRAMMING CARD	1.5	EH-S1046-78-001	1	JUL 84
*RSX	RSX 11M F ENHANC FKG FOR HINC	DECLAB-11/MINC USER'S GUIDE	1.1-1.2	EK-MNC11-UG-001	2	APR 83
*RSX	RSX 11M F ENHANC PKG FOR MINC	MINC THERMOCOUPLE PREAMPLIFIER USER'S GUIDE	1.1-1.2	EK-HNCTF-UG-001	1	APR 83

Page 1

OPERATING SYSTEM	FRODUCT NAME	TITLE OF MANUAL	VERSION	PART NUMBER REV LEVEL	NUMBER OF FICHE	DATE
*RSX	RSX-11H	RSX-11M/RSX-11S RELEASE NOTES	4.1	AA-2573H-TC-001	2	NOV 83
*RSX	RSX-11H	RSX-11H/11S INFORMATION DIRECTORY/INDEX	4.1	AA-2593G-TC-001	4	NUV 83
*RSX	RSX-11H	RSX-11M GUIDE TO WRITING AN I/O DRIVER	4.1	AA-2600E-TC-001	3	NOV 83
#RSX	RSX-11H	IAS/RSX-11 SYSTEM LIB ROUTINE REF MANUAL	4.1	AA-5580B-TC-001	2	NOV 83
*RSX	RSX-11h	RSX-11 SYS GENERATION AND INSTALLATION GUE	4.1	AA-H625C-TC-001	5	HOV 83
RSX	RSX-11M	EDT EDITOR MANUAL	4.1	AA-J726A-TC-001	3	NOV 83
*RSX	RSX-11M	RHS-11 FROGRAMMERS HANUAL	4.1	AA-L668A-TC-001	5	HOV 83
*RSX	RSX-11H	RMS-11 USER'S GUILLE	4,1	AA-L669A-TC-001	2	HOV 83
*RSX	RSX-11H	RMS-11 UTILITIES MANUAL	4.1	AA-L-570A-TC-001	3	NOV 83
#RSX	RSX-11M	RSX-11M/M-FLUS BATCH AND QUEUE OPERATIONS MAN	4.1	AA-L671A-TC-001	2	NOV 83
*RSX	RSX-11h	RSX-11H/H-PLUS COMMAND LANGUAGE MANUAL	4.1	AA-L672B-TC-001	ó	NOV 83
*R'SX	RSX-11M	RSX-11H/H+ CRASH DUMP ANZ REF HANUAL	4.1	AA-L673E-TC-001	3	NOV 83
*RSX	RSX-11H	RSX-11M/M-FLUS ERROR LOGGING MANUAL	4.1	AA-16749-TC-001	3	HOV 83
#RSX	RSX-11H	RSX-11H/M-FLUS EXECUTIVE REFERENCE MANUAL	4.1	AA-L675A-TC-001	4	NOV 83
*RSX	RSX-11H	RSX-11H/M-PLUS GUIDE TO PROGRAM DEVELOPMENT	4.1	AA-L676A-TC-001	2	NOV 83
*RSX	RSX-11H	RSX-11H/H+ I/O DRIVERS REF HAN (UPD#1)	4.1	AA-L677A-TC-001	6	NOV 83
*RSX	RSX-11M	RSX-11H/H+ HCR OPERATIONS HANUAL (UFD#1)	4.1	AA-L678A-TC-001	5	NOV 83
*RSX	RSX-11M	RSX-11H/H+ SYSTEM MANAGEMENT GIVE (UFD41)	4.1	AA-L679B-TC-001	6	E8 VON
#RSX	RSX-11n	RSX-11H/H-PLUS TASK BLDR HANUAL (UPD#1)	4.1	AA-L690B-TC-001	5	NOV 83
*RSX	R5X-11H	RSX-11H/H-FLUS UTILITIES MANUAL (UFD#1)	4.1	AA-L681A-TC-001	6	NOV 83
*RSX	RSX-11h	RMS-11: AN INTRODUCTION	4.1	AA-L682A-TC-001	1	NOV 83
*RSX	RSX-11H	INTRODUCTION TO RSX-11M AND RSX-11M-PLUS	4.1	AA-L753A-TC-001	2	NOV 83
*RSX	RSX-11H	IAS/RSX-11 I/O OPERATIONS REFERENCE MANUĀL	4.1	AA-M176A-FC-001	3	E8 VON
*RSX	RSX-11M	EDT EDITOR MANUAL	4.1	AA-M476A-TK-001	8	FER 84
*RSX	RSX-11M	ED: QUICK REFERENCE MANUAL	4.1	AA-h477A-TK-001	1	FEB S4

OPERATING SYSTEM	FRODUCT NAME	TITLE OF MANUAL	VERSION	FART NUMPER REV LEVEL	NUMBER OF FICHE	DATE
*RSX	RSX-11H	IAS/RSX-11 ODI REFERENCE MANUAL	4.1	AA-M507A-TC-901		NOV 83
#RSX	RSX-11H	FDF-11 MACRO-11 LANGUAGE REF MANUAL	4.1	AA-V027A-TC-001		NOV S3
RSX	RSX-11M	RSX-11H V4.1 SPD 14.35.20	4.1	AE-3407U-TC-001		FEB 84
*RSX	RSX-11M	RSX-11H V4.1 SPD 14.32.21	4.1	AE-3407V-TC-001	1	HAY 84
*RSX	RSX-11H	RSX-11H CROSS REFERENCE TABLE	4.1	AE-h778F-TC-001		CCT 84
#RSX	RSX-11H	RSX-11M MINI REFERENCE	4.1	AV-5570E-TC-001		NOV 83
RSX	RSX-11M	EDT EDITOR REFERENCE CARD	4.1	AV-J756A-TC-001		NOV 83
4RSX	RSX-11M	PDF-11 PROGRAMMING CARD	4.1	EH-S1046-78-001		NOV 83
*RSX	RSX-11M-PLUS	IAS/RSX-11 SYSTEM LIB ROUTINE REF MANUAL	2.1	AA-5580B-TC-001	2	NOV 83
*RSX	RSX-11M-FLUS	RSX-11M-PLUS GUIDE TO WRITING I/O DRIVER	2.1	AA-H267B-TC-001	4	NOV 83
*RSX	RSX-11M-FLUS	RSX-11H-PLUS INFORMATION DIRECTORY AND INDEX	2.1	AA-H426C-TC-001	4	NOV 83
*RSX	RSX-11M-FLUS	RSX-11M-FLUS V2.1 RELEASE NOTES	2.1	AA-H427C-TC-001	1	NOV 83
*RSX	RSX-11M-PLUS	RSX-11M-PLUS SYSTEM GEN/INSTALLATION GUIDE	2.1	AA-H431C-TC-001	3	NOV 83
RSX	RSX-11M-PLUS	EDT EDITOR MANUAL	2.1	AA-J7264-TC-001	3	NOV 33
#RSX	RSX-11M-PLUS	RMS-11 PROGRAMMERS MANUAL	2.1	AA-L669A-TC-001	5	NOV 83
#RSX	RSX-11M-FLUS	RMS-11 USER'S GUIDE	2.1	AA-L669A-TC-001	2	NOV 83
*RSX	RSX-11M-PLUS	RHS-11 UTILITIES	2.1	AA-L670A-TC-001	3	NOV 83
#RSX	RSX-11M-PLUS	RSX-11H/H+ BATCH AND QUEUE OPER MANUAL	2.1	AA-L671A-TC-001	2	NOV 83
#RSX	RSX-11M-FLUS	RSX-11M/M+ COMMAND LANGUAGE MANUAL	2.1	AA-L6728-TC-001	5	NOV 83
*RSX	RSX-11M-PLUS	RSX-11H/H+ CRASH DUMP ANZ REF HANUAL	2.1	AA-L673R-TC-001	3	NOV 83
#RSX	RSX-11M-PLUS	RSX-11M/M-PLUS ERROR LOGGING MANUAL	2.1	AA-L674B-TC-001	3	NOV 83
*RSX	RSX-11M-FLUS	RSX-11M/M-PLUS EXECUTIVE REFERENCE MANUAL	2.1	AA-L675A-TC-001	4	NOV 83
*RSX	RSX-11M-PLUS	RSX-11M/M+ GUIDE TO PROGRAM DEVELOPMENT	2.1	AA-L675A-TC-001	2	NOV 83
≭ RSX	RSX-11M-FLUS	RSX-11M-M-PLUS I/O DRIVERS REF MAN (UFD#1)	2.1	AA-L677A-TC-001	6	NOV 83
*RSX	RSX-11M-PLUS	RSX-11M-M-PLUS HCR OF MANUAL (UFD#1)	2.1	AA-L678A-IC-001	5	NOV 83
*RSX	RSX-11H-PLUS	RSX-11M-M-PLUS SYSTEM MANAGEMENT GDE (UPD#1)	2.1	AA-L679B-TC-001	6	E8 VON

Pase 3

OPERATING SYSTEM	PRODUCT Name	TITLE OF MANUAL	VERSION	PART NUMBER REV LEVEL	NUMBER OF FICHE	DATE
*RSX	RSX-11M-PLUS	RSX-11M-H-PLUS TASK BUILDER HANUAL	2.1	AA-L680B-TC-001	5	NOV 83
≭ RSX	RSX-11M-FLUS	RSX-11H/H-PLUS UTILITIES HANUAL (UPI#1)	2.1	AA-L681A-TC-001	6	NOV 83
*RSX	RSX-11M-PLUS	RMS-11: AN INTRODUCTION	2.1	AA-L682A-TC-001	1	ES VON
*RSX	RSX-11H-PLUS	INTRODUCTION TO RSX-11H AND RSX-11H+	2.1	AA-L763A-TC-001	2	HOV 83
*RSX	RSX-11H-PLUS	TAS/RSX-11 I/O OPERATIONS REFERENCE MANUAL	2.1	AA-H176A-TC-001	3	NOV 83
*RSX	RSX-11M-PLUS	ELT EDITOR MANUAL	2.1	AA-N476A-TK-001	8	FEB 84
*RSX	RSX-11M-PLUS	EDT QUICK REFERENCE MANUAL	2.1	AA-H477A-TK-001	1	FEB 84
≭ RSX	RSX-11M-FLUS	IAS/RSX-11 OUT REFERENCE MANUAL	2.1	AA-M507A-TC-001	!	NOV 83
*RSX	RSX-11M-PLUS	PDF-11 MACRO-11 LANGUAGE REFERENCE MANUAL	2.1	AA-V027A-TC-001	3	E8 VDM
RSX	RSX-11M-FLUS	RSX-11M-FLUS V2.1 SFD 14.70.08	2.1	AE-H662I-TC-001	1	FEB 84
*RSX	RSX-11M-PLUS	RSX-11M-PLUS V2.1 SPD 14.70.09	2.1	AE-H862J-TC-001	1	JUL 84
*RSX	RSX-11M-FLUS	RSX-11M-PLUS V2.1 CROSS REFERENCE SPIN	2.1	AE-H779I-TC-001	1	HAY 84
#RSX	RSX-11M-FLUS	RSX-11M-PLUS MINI REFERENCE	2.1	AV-H435C-TC-001	3	NOV 83
RSX	RSX-11H-PLUS	EDT EDITOR REFERENCE CARD	2.1	AV-J756A-TC-001	1	NOV 83
*RSX	RSX-11M-PLUS	PDP-11 PROGRAMMING CARD	2.1	EH-S1046-78-001	i	NOV 83
*RSX	RSX-11S	RSX-11M/RSX-11S RELEASE NOTES	4.1	AA-2573H-TC-001	2	NOV 83
*RSX	RSX-11S	RSX-11M/RSX-11S INFORMATION DIRECTORY & INDEX	4.1	AA-2593G-TC-001	4	NOV 83
¥RSX	RSX-11S	RSX-11M GUIDE TO WRITING I/O DRIVER	4.1	AA-2600E-TC-001	3	NOV 63
*RSX	RSX-11S	RSX-11S SYS GEN/INSTL GDE (INCLUDES UPD#1)	4.1	A^-2874E-TC-001	2	NOV 83
≭ ƘSX	RSX-11S	IAS/RSX-11 SYS LIB ROUTINE REF MANUAL	4.1	AA-5580B-TC-001	2	E3 VON
*RSX	RSX-11S	RSX-11H SYSTEM GENERATION/INSTALLATION GUIDE	4.1	AA-H625C-TC-001	5	NOV 83
*RSX	FSX-11S	RSX-11H/H+ CRASH DUMP ANZ REF MANUAL	4.1	AA-L673B-TC-001	3	NOV 83
*RSX	RSX-11S	RSX-11H/h-PLUS EXECUTIVE REFERENCE MANUAL	4.1	AA-L675A-TC-001	4	NOV 83
‡ RSX	RSX-11S	RSX-11H/H-PLUS GUIDE TO PROGRAM DEVELOPMENT	4.1	AA-L676A-TC-001	2	K8 V0N
*RSX	RSX-11S	RSX-11M/N+ I/O DIRVERS REF MANUAL (UPD#1)	4.1	AA-L677A-TC-001	6	NOV 83
*RSX	RSX-11S	RSX-11H/H-FLUS MCR OPERATIONS MANUAL (UPD#1)	4.1	AA-L678A-TC-001	5	NOV 83

OPERATING	PRODUCT	TITLE OF		PART NUMBER REV	NUMBER OF	
SYSTEM	NAME	HANUAL .	VERSION	LEVEL	FICHE	DATE
*RSX	RSX-11S	RSX-11H/H+ SYSTEM MANAGEMENT GUIDE (UFD#1)	4.1	AA-L679B-TC-001	6	NOV 83
*RSX	RSX-11S	RSX-11H/H-PLUS TASK BUILDER MANUAL	4.1	AA-L680B-TC-001	5	NOV 83
*RSX	RSX-11S	IAS/RSX-11 I/O OPERATIONS REFERENCE MANUAL	4.1	AA-H176A-TC-001	3	NOV 83
*RSX	RSX-11S	IAS/RSX-11 ODT REFERENCE MANUAL	4.1	AA-M507A-FC-001	1	NOV 83
*RSX	RSX-11S	PDP-11 MACRO-11 LANGUAGE REFERENCE MANUAL	4.1	AA-V027A-TC-001	3	NOV 83
RSX	RSX-11S	RSX-11M/11S V4.1 UPDATE & INFORMATION	4.1	AA-W259B-TC-001	1	FEB 84
*RSX	RSX-11S	RSX-11H/11S V4.1 UPDATE C INFORMATION	4.1	AA-W259C-TC-001	i	HAY 84
RSX	RSX-11S	RSX-115 V4.1 SPD 9.21.13	4.1	AE-3427N-TC-001	1	FEB 84
*RSX	RSX-11S	RSX-11S V4.1 SFE 09.21.14	4.1	4E-34270-TC-001	1	MAY 84
*RSX	RSX-11S	RSX-11H MINI REFERENCE	4.1	AV-5570E-TC-001	3	NOV 83
*RSX	RSX-11S	PDP-11 PROGRAHHING CARD	4.1	EN-S1046-78-001	i	NOV 83
RSX	BASIC-PLUS-2 FOR RSX-11M/M-PLUS	BASIC+2 RSX-11M/M-FLUS INSTL GDE/REL NOTES	2.1	AA-0158E-TC-001	1	JAN 84
*RSX	BASIC-PLUS-2 FOR RSX-11M/M-PLUS	BASIC+2 RSX-11H/H-PLUS INSTL GDE/REL NOTES	2.2	AA-0158F-TC-001	1	MAY 84
RSX	BASIC-PLUS-2 FOR RSX-11M/M-PLUS	BASIC REFERENCE MANUAL	2.0-2.1	AA-L334A-TK-001	6	APR 83
*RSX	BASIC-PLUS-2 FOR RSX-11M/H-PLUS	BASIC REFERENCE MANUAL (UPD#1)	2.2	AA-L334A-TK-002	6	MAY 84
RSX	BASIC-PLUS-2 FOR RSX-11M/H-PLUS	BASIC USER'S GUIDE	2.0-2.1	AA-L 135A-TK-001	3	APR 83
*RSX	BASIC-PLUS-2 FOR KSX-11H/H-PLUS	BASIC USER'S GUIDE (UPD#1)	2.2	AA-L335A-TK-002	3	MAY 84
RSX	RASIC-PLUS-2 FOR RSX-11M/M-PLUS	BASIC ON RSX-11H/M-PLUS SYSTEMS (UPD#1)	2.1	AA-L338A-TC-001	3	JAN 84
*RSX	BASIC-PLUS-2 FOR RSX-11M/M-PLUS	BASIC ON RSX-11M/M-PLUS SYSTEMS (UPD#1 % #2)	2.2	AA-L338A-TC-002	3	MAY 84
RSX	BASIC-PLUS-2 FOR RSX-11H/H-PLUS	BASIC-PLUS-2 V2.1 SPD 14.11.8	2+1	AE-J197I-TC-001	1	FEB 84
RSX	BASIC-PLUS-2 FOR RSX-11M/M-PLUS	BASIC-PLUS-2 V2.2 SPD 14.11.10	2.2	AE-J197K-TC-001	1	MAY 84
*RSX	BASIC-PLUS-2 FOR RSX-11M/M-PLUS	BASIC-PLUS-2 V2.2 SPD 14.11.11	2.2	AE-J197L-TC-001	i	JUL 84
*RSX	BASIC-PLUS-2 FOR RSX-11M/M-PLUS	BASIC POCKET REFERENCE GUIDE	2.0-2.2	AV-L341A-TK-001	2	AFR 83
RSX	BCF	RSX-11M BCP USER'S GUIDE	1.0	AA-N259A-TC-001	2	3EP 82
#RSX	BCF	BCF USER'S GUIDE	1.0	AA-N269B-TK-001	2	FER 84
*RSX	BCP	BCF V1.0 SPD 14.72.0	1.0	AE-N202A-TC-001	1	FEB 84

OPERATING SYSTEM	PRODUCT Name	TITLE OF MANUAL	VERSION	PART NUMBER REV LEVEL	NUMBER OF FICHE	IIATE
*RSX	BCP	BCP V1.0 RELEASE NOTES	1.0	AV-N2708-TC-001	1	AFR 83
RSX	CHR11/CHV11 SOFTWARE DRIVER	CHR11/CHV11 SOFTWARE DRIVER USERS GUIDE	1.0	AA-N060A-TC-001	1	AFR 83
*RSX	CHR11/CHV11 SOFTWARE DRIVER	CHR11/CHV11 SOFTWARE DRIVER USER'S GUIDE	3.0	AA-N060B-TC-001	1	FEB 84
RSX	CHR11/CHV11 SOFTWARE DRIVER	CHR11/CHV11 SOFTWARE DRIVER REFERENCE MANUAL	1.0	AA-N061A-TC-001	1	APR 83
*RSX	CHR11/CHV11 SOFTWARE DRIVER	CHR11/CHV11 SOFTWARE DRIVER REFERENCE MANUAL	3.0	AA-N061B-TC-001	1	FEB 84
*RSX	CHR11/CHV11 SOFTWARE DRIVER	CMR11/CMV11 V3.0 SPD 14.76.01	3.0	AE-N059B-TC-001	1	MAY 84
RSX	CHk11/CHV11 SOFTWARE DRIVER	CMR11/CHV11 SOFTWARE DRIVER RELEASE NOTES	1.0	AV-N058A-TC-001	1	APR 83
*RSX	CHR11/CHV11 SOFTWARE DRIVER	CRM11/CMV11 SOFTWARE DRIVER RELEASE NOTES	3.0	AV-N058F-TC-001	1	FER 84
*RSX	COBOL-81/RSX	COBOL-81 LANGUAGE REFERENCE MANUAL	2.0	AA-J434B-TC-001	4	JAN 84
*RSX	COBOL-81/RSX	RSX-11M/M-PLUS USER'S GUIDE	2.0	AA-N179B-TC-001	5	JAN 84
*RSX	COBOL-81/RSX	RSX-11H/M-PLUS INSTALLATION/RELEASE NOTES	2.0	AA-M181C-TC-001	1	JAN 84
#RSX	COBOL-81/RSX	COBOL-81 RSX V2.0 SPD 14.26.03	2.0	AE-F077E-TC-001	1	FEB 84
#RSX	COBOL-81/RSX	COBOL-81 POCKET GUIDE	2.0	AV-H630C-TC-001	2	JAN 84
#RSX	COMM IOP-DUP	COMM TOP-DUP PROGRAMMER'S MANUAL	1.0	AA-5670A-TC-001	1	SEP 82
*RSX	CONH IOF-DUF	COMM TOP-DUP RELEASE NOTES (INCLUDES UPD#1)	1.0	AA-D367A-TC-001	1	SEP 82
*RSX	COMM TOF-TUF	AUDENDUM TO SPD	1.0	AE-BB27A-TK-001	1	MAY 84
#RSX	CONH IOF-DUF	COMM TOP-BUF V1.0 SFB 10.12.04	1.0	AE-D121E-TC-001	1	JUL 84
*RSX	COMM TOP-DZ	COMM TOP-DZ PROGRAMMER'S MANUAL	1.0	AA-5127A-TC-001	1	SEP 82
*RSX	COHM TOP-DZ	COMM 10P-DZ RELEASE NOTES (INCLUDES UPD#1)	1.0	AA-D368A-TC-001	1	SEP 82
*RSX	COMM 10F-TIZ	ADDENDUM TO SPD	1.0	AE-BB27A-TK-001	1	MAY 64
*RSX	COHH IOP-DZ	COMM IOF-DZ V1.0 SFD 10.11.04	1.0	AE-1/122E-TC-001	1	JUL 84
*RSX	CORAL-66	PDF-11 CORAL-66 V4.0 INSTL GDE/REL NOTES	4.0	AA-1744E-TC-001	1	AFR 83
*RSX	CORAL-66	CORAL-66 LANGUAGE REFERENCE MANUAL	4.0	AA-D111C-TK-001	2	APR 83
#RSX	CORAL-66	RSX/VMS CORAL-66 USER'S GUDE	4.0	AA-8112C-TK-001	4	APR 83
*RSX	CORAL-66	CORAL-66 V4.0 SPD 14.56.10	4.0	AE-34501-TC-001	1	MAY 84
*RSX	DATATRIEVE-11	DATATRIEVE-11 REFERENCE MANUAL	3.0	AA-U049A-TK-001	4	FER 84

OPERATING	FRODUCT	TITLE OF		PART NUMBER REV	NUMBER OF	
SYSTEN	NAME	MANUAL	VERSION	LEVEL	FICHE	DATE
#RSX	DATATRIEVE-11	DATATRIEVE-11 CALL INTERFACE MANUAL	3.0	AA-U050A-TC-001	2	JAN 84
#RSX	DATATRIEVE-11	DATATRIEVE-11 GUIDE TO WRITING REPORTS	3.0	AA-U051A-TK-001	i	FER 84
#RSX	DATATRIEVE-11	DATATRIEVE-11 SUMMARY DESCRIPTION	3.0	AA-U052A-TC-001	1	JAN 84
*RSX	DATATRIEVE-11	DATATRIEVE-11 INSTALLATION GDE/REL NOTES	3.0	AA-X022A-TC-001	i	JAN 84
*RSX	DATATRIEVE-11	DATATRIEVE-11 USER'S GUIDE	3.0	AA-X023A-TX-001	3	FER 84
#RSX	DATATRIEVE-11	INTRODUCTION TO DATATRIEVE-11	3.0	AA-X025A-TK-001	1	FEB 84
*RSX	DATATRIEVE-11	DATATRIEVE-11 POCNET GUIDE	3.0	44-X1034-TK-001	1	FER 84
RSX	DATATRIEVE-11	DATATRIEVE-11 V3.0 SFD 12.48.11	3.0	AE-0777L-T0-001	1	MAY 84
*RSX	DATATRIEVE-11	DATATRIEVE-11 V3.0 SPD 12.48.12	3.0	AE-0777M-TC-001	1	JUL 64
*RSX	DATATRIEVE-11	DTR-11 COVER LETTER/REFORE YOU INSTALL	3.0	AV-X024A-TC-001	1	JUL 84
*RSX	DBM5-11	DBMS-11/M+ DDL/DEVICE MEDIA CON LANG SEF MAN	2.0-2.1	AA-H804B-TC+001	3	SEP 80
#RSX	DBMS-11	DEMS-11 DATA BASE ADMINISTRATOR'S (DBA) GUIDE	2.0-2.1	AA-H805E-TC-001	4	SEF 82
*RSX	D&MS-11	DBMS11 FORTRAN DATA MANIFULATION LANG REF MAN	2.0-2.1	AA-K3838-1C-001	2	SEF 82
*RSX	DBMS-11	DBMS11 COBOL DATA MANIPULATION LANG REF MAN	2.0-2.1	AA-N884B-TC-001	2	SEF 82
*RGX	DEMS-11	DBMS-11 INSTALLATION GUIDE	2.0-2.1	AA-1.885B-TC-001	2 .	SEP 82
#RSX	DBMS-11	DRMS-11 V2.0 RELEASE NOTES	2.0-2.1	AA-K886P-TC-001	i	SEF 82+ -
*RSX	DBm3-11	USING THE DATATRIEVE-11/DBMS-11 INTERFACE	2.0-2.1	AA-N887B-TC-001	1	SEP 82
*RSX	DRMS-11	DBMS-11 V2.1 SFD 12.66.2	2.1	AE-M130I-TC-001	1	FEB 84
*RSX	PBMS-11	BEFORE YOU INSTALL DBMS-11 V2.1	2.1	AV-P666A-TC-001	1	APR 83
RSX	DECNET-11H	RSX DECNET GUIDE TO USER UTILITIES	3.1	AA-H223B-TC-001	2	FEB 84
#RSX	DECNET-11M	RSX DECNET GUIDE TO USER UTILITIES	4.0	4A-H223C-TC-001	2	may 84
RSX	DECNET-11M	RSX DECNET SYSTEM MANAGER'S GUIDE	3.1	AA-H224R-TC-001	5	FER 94
#RSX	DECNET-11M	RSX DECNET SYSTEM MANAGER'S GUIDE	4.0	AA-H224C-TC-001	5	MAY 84
RSX	DECNET-11H	RSX DECNET NETWORK GEN AND INSIL GUIDE	3.1	AA-H2258-TC-001	3	FER 84
*RSX	DECHET-11H	RSX DECNET NETWORK GEN AND INSTALLATION GUIDE	4.0	AA-H225C-TC-001	5	n41 84
RSX	DECNET-11M	INTRODUCTION TO DECNET	3.1	AA-J055[-TN-001	g) be	FEB 84

OPERATION SYSTEM		PRODUCT Name	TITLE OF MANUAL	VERSION	PART NUMBER REV LEVEL	NUMBER OF FICHE)TE
*RSX	DECNET-11M		INTRODUCTION TO DECNET	4.0	AA-J055[I-TN-001	3	hAY	84
RSX	DECNET-11M		RSX DECNET POST-INSTL CHECKOUT PROCEDURES	3.1	AA-J3198-TN-001	2	FEB (84
*RSX	DECNET-11H		RSX DECNET POST-INSTL CHECKOUT PROCEDURES	4.0	AA-J319C-TK-001	1	MAY I	84
RSX	DECNET-11M		RSX DECNET RELEASE NOTES	3.1	AA-J517B-TC-001	1	FER	84
#RSX	DECNET-11H		RSX DECNET RELEASE NOTES	4.0	AA-J517C-TC-001	1	may i	84
RSX	DECNET-11H		OVERVIEW OF RSX DECNET	3.1	AA-M096A-TC-001	2	FEB (84
*RSX	DECNET-11H		OVERVIEW OF RSX DECNET	4.0	AA-M098B-TC-001	2	may (84
RSX	DECNET-11M		RSX-DECNET REFERENCE GUIDE	3.1	AA-H097A-T€-001	1	FEB (81
RSX	DECNET-11H		RSX DECNET PROGRAMMER'S REF MANUAL	3.1	AA-m098A-TC-001	5	FEB (84
*RSX	DECNET-11H		RSX DECNET PROGRAMMER'S REFERENCE MANUAL	4.0	AA-H098B-TC-001	4	HAY 8	84
*RSX	DECNET-11H		OVERVIEW TO DIGITAL NETWORK PROCEDURES	4.0	AA-X105A-TK-001	2	hAY 8	84
*RSX	DECNET-11M		USERS/FROGRAMMERS MINI REFERENCE GUIDE	4.0	AA-X923A-TC-001	1	JUL S	S4
*RSX	DECNET-11H		DECNET RSX SYSTEM MANGER'S MINI REF GUIDE	4.0	AA-X924A-TC-001	1	MAY 8	84
RSX	DECNET-11H		DECNET-11M V4.0 SPD 10.75.10	4.0	AE-3431K-TC-001	1	HAY 8	84
*RSX	DECNET-11H		DECNET-11M V4.0 SFD 10.75.11	4.0	AE-3431L-TC-001	1	JUL 8	84
#RSX	DECNET-11H		DECNET-11S V4.0 SPD 10.74.12	4.0	AE-3432N-TC-001		001 8	84
*RSX	DECNET-11H		DECNET-11M+ V2.0 SPE 10.66.05	4.0	AE-J513F-TC-001		001 8	84
*RSX	DECNET-11M		DECNET-RSX VOL I SPNST GENERAL INFORMATION	4.0	AV-Y552A-TC-001		3 150	84
#RSX	DECNET-11m		DECNET-RSX VOLUME II USER'S INFORMATION	4.0	AV-Y553A-TC-001		OCT 8	34
*RSX	DECNET-11M		DECNET-RSX VOL II SPNST GEMERAL INFORMATION	4.0	AV-Y554A-TC-001		0CT 8	84
*RSX	DECNET-11M		DECNET-RSX VOL IV SPNST GENERAL INFORMATION	4.0	AV-Y555A-TC-001		001 8	84
*RSX	DPK		DEN/DENT DECDATA INTELL SUBS USRS GDE (UPD#1)	4.1	AA-J529B-TC-001	3	SEP 8	82
*RSX	DPM		DPH/DPM+ TERNIANL USER'S GUIDE (UPD#1)	4.1	AA-J5308-TC-001	2	SEP 8	82
¥R'SX	DPH		DPM/IPM+ SYSTEM GENERATION/MANAGEMENT GDE	4.1	AA-J531C-TC-001	2	SEP 8	82
*RSX	LPH		DPH/DPH PLUS RELEASE NOTES	4.1	AA-N150A-TC-001	1	SEF 8	82
*RSX	DFM		DFM V4.1 SPD 15.6.6	4.1	AE-573CH-TC-001	1	FER 8	34

OPERATING SYSIEM		TITLE OF MANUAL	VERSION	PART NUMBER REV LEVEL	NUMBER OF FICHE	DATE
#RSX	DFH	DENIONE DE REFERENCE GUIDE	4.1	AV-M195A-TC-001		SEP 82
*RSX	DRU11-C RSX-11 DRIVER	DRU11-C RSX11H/H+ SOFTWARE MANUAL	4.2	AA-W152A-TC-001		JUL 84
≇RSX	TRU11-C RSX-11 DRIVER	DRU11-C RSX SFD 13.35.00	4.2	AE-BF37A-TC-001	1	JUL 84
*RSX	DT07-11H	DT07-11H V1.1 USER'S GUIDE	1.1	AA-K568A-TC-001	1	SEP B2
#RSX	DT07-11H	DT07-11H V1.1 SPD 14.36.1	1.1	AE-K5348-TC-001	1	FEB 84
#RSX	DX/11M	DX PRODUCTS PROGRAMMER'S REFERENCE MANUAL	3.1	AA-5469C-TC-001	i	AFR 83
*RSX	DX/11h	DX PRODUCTS USER'S GUIDE	3.1	AA-5476D-TC-001	1	AFR 83
*RSX	DX/11M	DX/11M INSTALLATION GUIDE	3.1	AA-1997A-TC-001	1	APR S3
*RSX	DX/11M	DX/11M VERSION 3.1 RELEASE NOTES	3.1	AA-H2888-TC-001	1	APR 83
#RSX	IX/11H	DX/11H V3.1 SPD 10.96.4	3.1	AE-5274F-TC-001	1	FEB 84
*RSX	DX/116	ADDENDUM TO SFD	3.1	AE-BB27A-TK-001	1	MAY 84
*RSX	FMS-11/RSX	FDF11 KEYPAD EDITOR USER'S GDE (UPD#1)	1.0	AA-H853A-TC-001	2	SEP 82
*RSX	FMS-11/RSX	FMS-11/RSX11M SOFTWARE REF MANUAL (UPD#1)	1.0	AA-H855A-TC-001	3	SEP 82
*RSX	FMS-11/RSX	FHS-11/RSX-11M RELEASE NOTES	1.0	AA-H857A-TC-001	ì	SEF 82
*RSX	FMS-11/RSX	FDF11 KEYPAD EDITOR RELEASE NOTES	1.0	AA-J692A-TC-001	1	SEP 82
#RSX	FMS-11/RSX	FMS-11/RSX V1.0 SPD 12.27.5	1.0	AE-J405F-TC-001	1	FEB 84
RSX	FMS-11/RSX	FMS-11/RSX V1.0 SPI 12.27.07	1.0	AE-J405H-TC-001	1	JUL 84
*RSX	FMS-11/RSX	PDP11 KEYPAD EDITOR REFERENCE CARD	1.0	AV-H854A-TC-001	1	SEP 82
*RSX	FMS-11/RSX	FMS-11/RSX-11M MINI REFERENCE GUIDE	1.0	AU-8856A-TC-001	1	SEP 82
*RSX	FORTRAN IV/RSX	PDP-11 FORTRAN LANGUAGE REFERENCE MANUAL	2.6	AA-R953A-TK-001	2	JAN 84
*RSX	FORTRAN IV/KSX	RSX/VMS FORTRAN IV INSTALLATION/REL NTS	2.6	AA-R954A-TK-001	1	JAN 84
*RSX	FORTRAN IV/RSX	RSX/VAX/VHS FORTRAN IV USER'S GUIDE	2.6	AA-R955A-TK-001	2	JAN 84
RSX	FORTRAN IV/85X	FORTRAN IV/RSX V2.6 SPD 14.63.9	2.6	AE-3443J-TC-001	1	FEB 84
*RSX	FORTRAN IV/RSX	FURTRAN IV/RSX V2.6 SPD 14.63.10	2+6	AE-3443K-TC-001	1	HAY 84
#RSX	FORTRAN-77 DEBUG, PDP-11	PDP-11 FORTRAN-77/DEBUG USER'S GUIDE	1.0	AA-V1974-TK-001	2	JAN 84
*RSX	FORTRAN-77 DEBUG, FDP-11	FORTRAN-77/DEBUG INSTAL GUIDE/REL NOTES	1.0	AA-X650A-TK-001	1	JAN 84

Fase 9

OFERATING SYSTEM	FRODUCT NAME	TITLE OF MANUAL	VERSION	FART NUMBER REV LEVEL	NUMBER OF FICHE	DATE
*RSX	FORTRAN-77 DEBUG, PDP-11	PDP-11 FORTRAN-77 DEBUG V1.0 SFD 30.33.00	1.0	AE-Y3988-TK-001	1	FEP 84
*RSX	FORTRAN-77/RSX, PDF-11	FDF-11 FORTRAM-77 LANGUAGE REFERENCE MANUAL	5.0	4A-V193A-TK-001	3	FER 84
*RSX	FORTRAN-77/RSX, FDP-11	PDF-11 FORTRAN-77 USER'S GUIDE	5.0	AA-V194A-TK-001	3 6	FER 84
#RSX	FORTRAN-77/RSX, FBF-11	PDF-11 FORTRAM-77 OTS REFERENCE MANUAL	5.0	AA-V195A-TK-001	2	FEB 84
*RSX	FORTRAN-77/RSX, PDF-11	FDF-11 FORTRAN-77 INSTL GUIDE/REL NOTES	5.0	AA-V196A-TK-001	1	JAN 84
RSX	FORTRAN-77/RSX, PDP-11	FDF-11 FORTRAN-77/RSX V5.0 SFD 14.31.06	5.0	AE-J139G-TC-001	1	FER 84
*RSX	FORTRAN-77/RSX, PDF-11	PDP-11 FORTRAN-77/RSX V5.0 SPD 14.31.07	5.0	AE-J139H-TC-001	1	MAY 84
*RSX	IEC-11H	IEC-11H RSX SOFTWARE MANUAL	3.0	AA-M275A-TC-001	1	SEP 82
*RSX	IEC-11H	IEC-11M V3.0 SPD 14.64.0	3.0	AE-N029A-TC-101	1	FEB 84
*RSX	IEC-1.M	IEC-11M RELEASE NOTES	3.0	AV-V507A-TC-001	1	FER 84
#RSX	IEX-RSX DRIVER	IEX-RSX USERS & INSTALLATION GUIDE	2.0	AA-R472A-TC-001		OCT 84
¥ RSX	IEX-RSX DRIVER	IEX-RSX DRIVER V2.0 SFD 12.68.01	2.0	AE-X682F-TC-001	1	JUL 84
#RSX	KMC-11 TOOLS	KHC11 PROGRAMMER'S MANUAL	1.0	AA-5244E-TC-001	2	SEP 82
≇RSX	KMC-11 TOOLS	KMC-11 TOOLS V1.0 SPD 12.49.04	1.0	AE-C776E-TC-001	1	HAY 84
#RSX	KMV11-A HDLC FRAMING SOFTWARE	KHV11-A HDLC FRANING SETWARE FOR RSX REF MAN	1.0	AA-N565A-TC-001	i	APR 83
*RSX	KMV11-A HDLC FRAMING SOFTWARE	KMV11A-HDLC FRAMING SOFTWARE V1.0 SFD 14.22.0	1.0	AE-R298A-TC-001	1	FEB 84
#RSX	LABORATORY SUBROUTINE PACKAGE	LABORATORY SUB PROGRAMMER'S REF MAN (UFD#1)	1.2	AA-C984C-TC-001	1	SEP 82
*RSX	LABORATORY SUBROUTINE PACKAGE	ADDENDUM TO SPD	1.2	AE-BB27A-TK-001	1	MAY 84
RSX	LABORATORY SUBROUTINE PACKAGE	LSP V1.2 SPD 15.44.5	1.2	AE-1607F-TC-001	1	FEB 84
#RSX	LABORATORY SUBROUTINE PACKAGE	LSF V1.2 SPT 15.44.06	1.2	AE-D607G-TC-001	1	MAY 84
*RSX	HICROPOWER/PASCAL-RSX	MP/F RSX-11M/M+ INSTALLATION GUIDE	1.5	4A-AK10A-TC-001	1	JUL 84
*RSX	MICROPOWER/PASCAL-RSX	HF/F RSX-11M/H+ RELEASE NOTES	1.5	AA-AK11A-TC-001	1	JUL 84
*RSX	HICROPOWER/FASCAL-RSX	MP/P-RSX/VMS SYSTEM USER'S GUIDE	1.5	AA-AN13A-TK-001	3	JUL 84
#RSX	MICROPOWER/FASCAL-RSX	MP/F-RSX/VMS MESSAGES MANUAL	1,5	AA-AK14A-TN-001	1	JUL 84
*RSX	MICROPOWER/PASCAL-RSX	INTRODUCTION TO MICROPOWER/FASCAL	1.5	AA-M388A-TC-001	1	JUL 84
*RSX	MICROFOWER/PASCAL-RSX	MF/F LANGUAGE GUIDE (UFD #1)	1.5	AA-H389C-TC-001	5	JUL 84

OPERATING SYSTEM	PRODUCT NAME	TITLE OF Hanual	VERSION	PART NUMBER REV LEVEL	NUMBER OF FICHE	DATE
*RSX	MICROPOWER/PASCAL-RSX	HP/P-RT RUNTINE SERVICE HANUAL (UPD #1)	1.5	AA-h3/18-TC-001	6	JUL 84
#RSX	HICROPOWER/PASCAL-RSX	HP/P DEBUGGER USER'S GUIDE (UPD#1)	1.5	AA-M393R-TC-001	·2	JUL 84
*RSX-	MICROPOWER/PASCAL-RSX	PDF-11 MACRO-11 LANGUAGE REFERENCE MANUAL	1.5	AA-V027A-TC-001	3	JUL 84
#RSX	HICROPOWER/PASCAL-RSX	KXT11-C SOFTWARE USER'S GUIDE	1.5	AA-Y615A-TK-001	2	JUL 84
*RSX	MICROPOWER/PASCAL-RSX	MP/F RSX SPD 14.83.00	1.5	AE-BK29A-TC-001	. i	JUL 84
4RSX	HICROPOWER/PASCAL-RSX	HP/F REFERENCE CARD	1.5	AV-H395A-TC-001	1	JUL 84
*RSX	MICROPOWER/PASCAL-RSX	PDP-11 PROGRAMMING CORD	1.5	EH-S1046-78-001	1	JUL 84
*RSX	MUX200/RSX-IAS	MUX200/RSX-IAS V2.1 RELEASE NOTES	2.1	AA-1343C-TC-001	1	JAN 84
#RSX	MUX200/RSX-IAS	MUX200/RSX-IAS SYSTEM MANAGER GUIDE	2.1	AA-1344C-TC-001	2	JAN 84
#RSX	MUX200/RSX-IAS	HUX200/RSX-IAS USER'S GUIDE	2.1	AA-1346C-TC-001	1	JAN 84
*RSX	MUX200/RSX-IAS	HUX200/RSX-IAS V2.1 SFD 10.77.07	2.1	AE-3453I-TC-001	1	FER 84
RSX	OBSERVER	OBSERVER INSTL GUIDE AND GEN GUIDE	1.0	AA-N959A-TC-001	1	APR 83
*RSX	OBSERVER	OBSERVER INSTL GUIDE AND GEN GUIDE	1.1	AA-N959B-TL-001	. 1	FEB 84
RSX	ORSERVER	OBSERVER USER'S GUIDE	1.0	AA-N960A-TC-001	3	AFR 83
*RSX	OBSERVER	OBSERVER USER'S GUIDE	1.1	AA-N960B-TC-001	. 3	FEB 84
RSX	OBSERVER	OBSERVER RELEASE NOTES	1.0	AA-N962A-TC-001	1	APR 83
*RSX	OBSERVER	OBSERVER RELEASE NOTES	1.1	AA-N962B-TC-001	1	FEB 84
#RSX	OBSERVER	OBSERVER EVENT MESSAGE REFERENCE MANUAL	1.1	AA-X074A-TC-001	2	JUL 84
*RSX	OBSERVER	OBSERVER V1.1 SPD 13.18.02	1.1	AE-P335C-TC-001	. 1	HAY 84
#RSX	OBSERVER	OBSERVER REFERENCE CARD	1.1	AV-X073A-TC-001	1	FEB 84
RSX	PASCAL/RSX, PDP-11	PDP-11 PASCAL LANGUAGE REFERENCE HANUAL	1.0	AA-M875A-TC-001	2	JAN 84
*RSX	PASCAL/RSX, PDP-11	PDP-11 PASCAL LANGUAGE REF MANUAL (UPD#1)	1.1	AA-M875A-TC-002	2	FEB 84
RSX	PASCAL/RSX, PDF-11	PDF-11 PASCAL USER'S GUIDE	1.0	AA-M876A-TC-001	2	JAN 84
#RSX	FASCAL/RSX, PDF-11	PDP-11 PASCAL USER'S GUIDE (UPD#1)	1.1	AA-MB76A-TC-002	2	FEB 84
RSX	PASCAL/RSX, FDF-11	PDP-11 PASCAL INSTALLATION GDE/REL NOTES	1.0	AA-h877A-TC-001	1	JAN 84
#RSX	PASCAL/RSX, FDF-11	PDF-11 FASCAL INSTALLATION GDE/REL NOTES	1.1	AA-MS77R-TC-001	1	MAY 84

OPERATING	PRODUCT	TITLE OF		PART NUMBER REV	NUMBER OF	
SYSTEM	NAME	MANUAL	VERSION	LEVEL	FICHE	DATE
RSX	PASCAL/RSX; PDF-11	PDP-11 PASCAL/RSX V1.1 SPD 14.18.02	1.1	AE-M217C-TC-001	1	FEB 84
*RSX	PASCAL/RSX, PDF-11	PDP-11 PASCAL/RSX V1.1 SPD 14.18.03	1+1	AE-N917B-TC-001	1	MAY 84
*RSX	PDP-11 COBOL	PDP-11 COBOL INSTALLTION GUIDE	4.4	AA-1745F-TC-001	1	SEP 82
#RSX	FDF-11 COBOL	PIP11 COBOL LANG REF MANUAL (UPIP1 & #2)	4.4	AA-1749E-TC-001	3	SEP 82
*RSX	PDP-11 COBOL	PDP-11 COBOL USER'S GUIDE (INCLUDES UPD#1)	4.4	AA-1757E-TC-001	6	SEP 82
*RSX	PDF-11 COROL	PDF-11 COBOL V4.4 SPD 12.40.18	4.4	AE-3417S-TC-001	1	FER 84
RSX	PLXY-11H	PLXY-11 V1.1 USER'S GUIDE	1.1	AA-J535A-TK-001	1	SEP 82
#RSX	PLXY-11H	FLXY-11 USER'S GUIDE	1.3	AA-J535B-TK-001	1	HAY 84
*RSX	PLXY-11K	PLXY-11 V1.3 SPD 14.39.01	1.3	AE-K797B-TC-001	1	MAY 84
RSX	PROFESSIONAL HOST COMMUNICATIONS	PROFESSIONAL HOST COMM INSTL PROCEDURES	1.5	AA-P412B-TK-001	1	JAN 84
*RSX	PROFESSIONAL HOST COMMUNICATIONS	PROFESSIONAL HOST COMM INSTL PROCEDURES	1.7	AA-P412C-TK-001	1	MAY 84
≭ RSX	PROFESSIONAL HOST TOOL KIT	THS FROGRAMMER'S MANUAL	2.0	AA-AI/34A-TH-001		OCT 84
*RSX	PROFESSIONAL HOST TOOL KIT	PRO/DECNET TK PROGRAMMER'S REFERENCE MANUAL	2.0	AA-AV69A-TK-001	3	JUL 84
*RSX	PROFESSIONAL HOST TOOL KIT	PRO/DECNET TOOL KIT INSTALLATION GUIDE	2.0	AA-AV70A-TK-001	1	JUL 84
#RSX	PROFESSIONAL HOST TOOL KIT	GUIDE TO WRITING P/OS 1/0 DRIVER	2.0	AA-BT73A-TH-001		OCT 84
*RSX	PROFESSIONAL HOST TOOL KIT	PRO TOOL KIT REFERENCE MANUAL	2.0	AA-BT74A-TH-001		OCT 84
*RSX	PROFESSIONAL HOST TOOL KIT	FMS-11/RSX SOFTWARE REFERENCE MANUAL	1.0-2.0	AA-H855A-TC-001	3	APR 83
*RSX	FROFESSIONAL HOST TOOL KIT	FMS-11/RSX RELEASE HOTES	1.0-2.0	AA-H857A-TC-001	1	APR 83
*RSX	PROFESSIONAL HOST TOOL KIT	INTRO TO DECNET PHASE IV	2.0	AA-J055D-TK-001		OCT 84
*RSX	PROFESSIONAL HOST TOOL KIT	RSX/RMS USER'S GUIDE	1.0-2.0	AA-L669A-TC-001	2	MAY 84
*RSX	PROFESSIONAL HOST TOOL KIT	RSX-11M/M-PLUS RMS-11 UTILITIES MANUAL	1.0-2.0	AA-L670A-TC-001	3	MAY 84
*RSX	PROFESSIONAL HOST TOOL KIT	RSX-11H/M-PLUS TASK BUILDER HANUAL	1.0-2.0	AA-L680B-TC-001	ว	JAN 84
*RSX	PROFESSIONAL HOST TOOL KIT	IAS/RSX-11 OUT REFERENCE MANUAL	1.0-2.0	AA-H507A-TC-001	1	APR 83
RSX	PROFESSIONAL HOST TOOL KIT	TOOL KIT DOCUMENTATION DIRECTURY	1.0	AA-N615B-TK-001	1	JAN 84
RSX	PROFESSIONAL HOST TOOL KIT	TOOL KIT DOCUMENATION DIRECTORY	1.0	AA-N615C-TK-001	1	MAY 84
RSX	PROFESSIONAL HOST TOOL KIT	PRO TOOL K'T INSTE GDE/REE NTS	1.0	AA-N616B-TK-001	1	JAN 84

SYSTEM NAME HANDEL PROFESSIONAL HOST TOOL KIT TOOL KIT USER'S GUIDE CAM-8617C-1K-001 2.0 AB-8617C-1K-001 3.0 ABY 88 RSX PROFESSIONAL HOST TOOL KIT CORE GRAPHICS LIBRARY MANUAL 1.0 AB-4619B-TK-001 2.0 AB-7619B-TK-001 2.0 AB-7618B-TK-001 2.0 AB-7619B-TK-001 2.0 AB-7618B-TK-001	OPERATING	PROI	DUCT	TITLE OF		PART NUMBER REV	NUMBER OF	
RSX PROFESSIONAL HOST TOOL KIT CORE GRAPHICS LIBRARY MANUAL 1.0 AA-M619A-TK-001 2 APR 83 RSX PROFESSIONAL HOST TOOL KIT CORE GRAPHICS LIBRARY MANUAL 1.0 AA-M619B-TK-001 2 MAY C4 RSX PROFESSIONAL HOST TOOL KIT P/OS SYSTEM REFERENCE MANUAL 1.0-2.0 AA-M620A-TK-002 4 JUL 84 RRSX PROFESSIONAL HOST TOOL KIT DOCUMENTATION SUIDE LINES 1.0-2.0 AA-M621A-TK-001 1 AFR 83 18SX PROFESSIONAL HOST TOOL KIT TERMINAL SUBSYSTEM MANUAL 1.0-2.0 AA-M621A-TK-001 2 JAM 84 8RSX PROFESSIONAL HOST TOOL KIT PROFIT HACRO-II LANGUAGE REFERENCE MANUAL 1.0-2.0 AA-V927A-TC-001 3 JAN 84 ARSX <	SYSTEM	NAM	iE .	HANUAL	VERSION	LEVEL	FICHE	DATE
RSX PROFESSIONAL HOST TOOL KIT CORE GRAPHICS LIBRARY NAMUAL 1.0 AA-M619B-TK-601 2 MAY CA RSX PROFESSIONAL HOST TOOL KIT F/OS SYSTEM REFERENCE NAMUAL 1.0 AA-M620A-TK-602 4 APR 83 MRSX PROFESSIONAL HOST TOOL KIT P/US SYSTEM REFERENCE NAMUAL (UPIN2) 1.0-2.0 AA-M620A-TK-602 4 JUL 84 MRSX PROFESSIONAL HOST TOOL KIT DOUMENTATION GUIDE LINES 1.0-2.0 AA-M621A-TK-601 1 AFR 83 MRSX PROFESSIONAL HOST TOOL KIT PERMINAL SUBSYSTEM MANUAL 1.0-2.0 AA-P628A-TK-601 2 JAR 88 MRSX PROFESSIONAL HOST TOOL KIT PRO/FRS-11 MICROPORTION 1.0-2.0 AA-P679A-TK-601 5 AFR 83 MRSX PROFESSIONAL HOST TOOL KIT PRO/FRS-11 MICROPORTION SUPPLEMENT 1.0-2.0 AA-P103B-TK-601 1 AFR 83 MRSX PROFESSIONAL HOST TOOL KIT PRO/FRS-11 MICROPORTION SUPPLEMENT 1.0-2.0 AA-P103B-TK-601 1 JAR 84 MRSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT DECLEMENT SUPPLEMENT 1.0-2.0 AA-P103B-TK-601	RSX	PROFESSIONAL HOST	TOOL KIT	TOOL KIT USER'S GUIDE	1.0	AA-N617C-TK-001	3	MAY 84
RSX PROFESSIONAL HOST TOOL KIT F/OS SYSTEM REFERENCE MANUAL 1.0 AA-M620A-TK-001 4 AF 83 #RSX PROFESSIONAL HOST TOOL KIT F/OS SYSTEM REFERENCE MANUAL (UPD42) 1.0-2.0 AA-M620A-TK-002 4 JUL 84 #RSX PROFESSIONAL HOST TOOL KIT DOCUMENTATION GUIDE LINES 1.0-2.0 AA-M620A-TK-001 1 AF 83 #RSX PROFESSIONAL HOST TOOL KIT PERMINAL SUBSYSTEM HANUAL 1.0-2.0 AA-M620A-TK-001 2 JAH 84 #RSX PROFESSIONAL HOST TOOL KIT PROFRHS-11 MAIRD PROGRAMMER'S GUIDE 1.0-2.0 AA-P079A-TA-001 5 AFR 83 #RSX PROFESSIONAL HOST TOOL KIT PROFRHS-11 MAIRD PROGRAMMER'S GUIDE 1.0-2.0 AA-P038-TK-001 1 JAH 84 #RSX PROFESSIONAL HOST TOOL KIT PROFRHS-11 DOCUMENATION SUPPLEMENT 1.0-2.0 AA-P103F-TK-001 1 JAH 84 #RSX PROFESSIONAL HOST TOOL KIT PROFIT HACKO-11 LANGUAGE REFERENCE MANUAL 1.0-2.0 AA-P103F-TK-001 1 JAH 84 #RSX PROFESSIONAL HOST TOOL KIT PROFIT HACKO-11 LANGUAGE REFERENCE MANUAL 1.0-2.0	RSX	PROFESSIONAL HOST	TOOL KIT	CORE GRAPHICS LIBRARY MANUAL	1.0	AA-N619A-TK-001	2	APR 83
#RSX PROFESSIONAL HOST TOOL KIT DOCUMENTATION GUIDE LINES 1.0-2.0 AA-M620A-TK-002 4 JUL 84 #RSX PROFESSIONAL HOST TOOL KIT DOCUMENTATION GUIDE LINES 1.0-2.0 AA-M620A-TK-001 1 APR 83 #RSX PROFESSIONAL HOST TOOL KIT TERMINAL SUBSYSTEM MANUAL 1.0-2.0 AA-M621A-TK-001 1 APR 83 #RSX PROFESSIONAL HOST TOOL KIT FRO/RNS-11: AN INTRODUCTION 1.0-2.0 AA-P697A-TK-001 1 APR 83 #RSX PROFESSIONAL HOST TOOL KIT FRO/RNS-11: AN INTRODUCTION 1.0-2.0 AA-P697A-TK-001 1 APR 83 #RSX PROFESSIONAL HOST TOOL KIT FRO/RNS-11 DOCUMENTATION SUPFLEMENT 1.0-2.0 AA-P103B-TK-001 1 JAN 84 #RSX PROFESSIONAL HOST TOOL KIT FRO/FNS-11 DOCUMENTATION SUPFLEMENT 1.0-2.0 AA-P103B-TK-001 1 JAN 84 #RSX PROFESSIONAL HOST TOOL KIT FRO/FNS-11 DOCUMENTATION SUPFLEMENT 1.0-2.0 AA-P103B-TK-001 1 JAN 84 #RSX PROFESSIONAL HOST TOOL KIT PDP-11 MACRO-11 LANGUAGE REFERENCE MANUAL 1.0-2.0 AA-P103B-TK-001 1 JAN 84 #RSX PROFESSIONAL HOST TOOL KIT POP-11 MACRO-11 LANGUAGE REFERENCE MANUAL 1.0-2.0 AA-V027A-TC-001 3 JAN 84 #RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT INSTALLATION GUIDE/RELEASE NOTES 1.0 AA-X910A-TH-001 1 MAY 94 #RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT INSTALLATION GUIDE/RELEASE NOTES 2.0 AA-X911A-TH-001 1 MAY 94 #RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT INSTALLATION GUIDE/RELEASE NOTES 2.0 AA-X911A-TH-001 1 MAY 94 #RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT COMMAND LANG/UTILITIES MANUAL 1.0-2.0 AA-X912A-TH-001 5 MAY 94 #RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT COMMAND LANG/UTILITIES MANUAL 1.0-2.0 AA-X912A-TH-001 5 MAY 94 #RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT COMMAND LANG/UTILITIES MANUAL 1.0-2.0 AA-X912A-TH-001 5 MAY 94 #RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT OWN AND LANG/UTILITIES MANUAL 1.0-2.0 AA-X912A-TH-001 5 MAY 94 #RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT OWN AND LANG/UTILITIES MANUAL 1.0-2.0 AA-X912A-TH-001 5 MAY 94 #RSX PROFESSIONAL REAL TIME INTERFACE LI PRITL RELEASE NOTES 1 MAY 94 #RSX PROFESSIONAL REAL TIME INTERFACE LI PRITL RELEASE NOTES 1 MAY 94 #RSX PROFESSIONAL REAL TIME INTERFACE LI PRITL PRO/TOOL KIT SPI 4-0.3	RSX	PROFESSIONAL HOST	TOOL KIT	CORE GRAPHICS LIBRARY MANUAL	1.0	AA-N619B-TK-001	2	MAY C4
#RSX	RSX	PROFESSIONAL HOST	TOOL KIT	F/OS SYSTEM REFERENCE MANUAL	1.0	AA-N620A-TK-001	4	APR 83
## RSX PROFESSIONAL HOST TOOL KIT TERMINAL SUBSYSTEM MANUAL 1.0-2.0 AA-M6238-TX-001 2 JAN 84 ## RSX PROFESSIONAL HOST TOOL KIT PRO/RMS-11; AN INTRODUCTION 1.0-2.0 AA-M6238-TX-001 1 AFR 83 ## RSX PROFESSIONAL HOST TOOL KIT PRO/RMS-11 MACRO PROGRAMMER'S GUIDE 1.0-2.0 AA-P097A-TX-001 5 AFR 83 ## RSX PROFESSIONAL HOST TOOL KIT PRO/RMS-11 DOCUMENTATION SUPPLEMENT 1.0-2.0 AA-P193R-TX-001 1 JAN 84 ## RSX PROFESSIONAL HOST TOOL KIT FRO/FAS-11 DOCUMENTATION SUPPLEMENT 1.0-2.0 AA-P193R-TX-001 1 JAN 84 ## RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT DOCUMENTATION DIRECTORY 1.0 AA-W027A-TC-001 3 JAN 84 ## RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT INSTALLATION GDE/RELEASE NOTES 1.0 AA-X910A-TH-001 1 MAY 84 ## RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT INSTALLATION GDE/RELEASE NOTES 2.0 AA-X911A-TH-001 1 JUL 84 ## RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT INSTALLATION GUIDE/RELEASE NOTES 2.0 AA-X912A-TH-001 5 MAY 84 ## RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT INSTALLATION GUIDE/RELEASE NOTES 2.0 AA-X912A-TH-001 5 MAY 84 ## RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT INSTALLATION GUIDE/RELEASE NOTES 2.0 AA-W660A-TH-001 0 0 0 ## RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT INSTALLATION GUIDE/RELEASE NOTES 2.0 AA-W660A-TH-001 0 0 0 ## RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT INSTALLATION GUIDE/RELEASE NOTES 2.0 AA-W660A-TH-001 0 0 0 ## RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT OLANANI LAAG/UILLITES NANUAL 1.0-2.0 AA-W660A-TH-001 0 0 0 0 ## RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT V2.0 SFB 40.19.01 2.0 0 0 0 0 0 0 0 0 ## RSX PROFESSIONAL REAL TIME INTERFACE LI PRIIL PROMS REFERENCE MANUAL 1.1 0 0 0 0 0 0 0 ## RSX PROFESSIONAL REAL TIME INTERFACE LI PRIIL PROMS REFERENCE MANUAL 2.0-2.1 0 0 0 0 0 0 0 0 ## RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC REFERENCE MANUAL (UPD \$1) 2.0	*RSX	FROFESSIONAL HOST	TOOL KIT	F/OS SYSTEM REFERENCE MANUAL (UFD#2)	1.0-2.0	AA-N620A-TK-002	4	JUL 84
#RSX PROFESSIONAL HOST TOOL KIT PRO/RMS-11: AN INTRODUCTION 1.0-2.0 AA-PO9PA-TK-001 1 APR 83 #RSX PROFESSIONAL HOST TOOL KIT PRO/RMS-11 HACRO PROGRAMMER'S GUIDE 1.0-2.0 AA-PO9PA-TK-001 1 JAN 84 #RSX PROFESSIONAL HOST TOOL KIT PRO/FMS-11 DOCUMENTATION SUPPLEMENT 1.0-2.0 AA-P193B-TK-001 1 JAN 84 #RSX PROFESSIONAL HOST TOOL KIT 1AS/RSX ODT REFERENCE MANUAL SUPPLEMENT 1.0-2.0 AA-P193B-TK-001 1 JAN 84 #RSX PROFESSIONAL HOST TOOL KIT PDP-11 NACRO-11 LANGUAGE REFERENCE MANUAL 1.0-2.0 AA-P193B-TK-001 1 MAY 84 #RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT DOCUMENATION DIRECTORY 1.0 AA-X910A-TH-001 1 MAY 84 #RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT INSTALLATION GUIDE/RELEASE NOTES 2.0 AA-X911A-TH-001 1 MAY 84 #RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT INSTALLATION GUIDE/RELEASE NOTES 2.0 AA-X911A-TH-001 1 JAN 84 #RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT COMMAND LANG/UTLITIES NANUAL 1.0-2.0 AA-X912A-TH-001 5 MAY 84 #RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT COMMAND LANG/UTLITIES NANUAL 1.0-2.0 AA-X912A-TH-001 5 MAY 84 #RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT COMMAND LANG/UTLITIES NANUAL 1.0-2.0 AA-X912A-TH-001 5 MAY 84 #RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT U2.0 SPB 40.19.01 2.0 BH-Y991B-TH-001 5 OCT 84 #RSX PROFESSIONAL REAL TIME INTERFACE LI PRITL PROMS REFERENCE NANUAL 1.1 AA-AL40C-TH-001 5 OCT 84 #RSX PROFESSIONAL REAL TIME INTERFACE LI PRITL PROMS REFERENCE NANUAL 1.1 AA-P41A-TK-001 1 JUL 84 #RSX PROFESSIONAL REAL TIME INTERFACE LI PRITL PROMS REFERENCE NANUAL 2.0-2.1 AA-L334A-TK-001 6 APR 83 #RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC REFERENCE NANUAL (UPD \$1) 2.2 AA-L334A-TK-002 6 APR 83 #RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC REFERENCE MANUAL (UPD \$1) 2.0-2.1 AA-L335A-TK-001 6 APR 83 #RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC REFERENCE MANUAL (UPD \$1) 2.0-2.1 AA-L335A-TK-001 6 APR 83 #RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC REFERENCE MANUAL (UPD \$1) 2.0-2.1 AA-L335A-TK-001 6 APR 83 #RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC REFERENCE MANUAL (UPD \$1) 2.0-2.1 AA-L335A-TK-001 6 A	*RSX	PROFESSIONAL HOST	TOOL KIT	DOCUMENTATION GUIDE LINES	1.0-2.0	AA-N621A-TK-001	1	APR 83
#RSX PROFESSIONAL HOST TOOL KIT PRO/FMS-11 MACRO PROGRAMMER'S GUIDE 1.0-2.0 AA-F079A-TN-001 5 AFR 83 #RSX PROFESSIONAL HOST TOOL KIT PRO/FMS-11 DOCUMENTATION SUPPLEMENT 1.0-2.0 AA-F103B-TK-001 1 JAN 84 #RSX PROFESSIONAL HOST TOOL KIT IAS/RSX ODT REFERENCE MANUAL SUPPLEMENT 1.0-2.0 AA-P173B-TK-001 1 JAN 84 #RSX PROFESSIONAL HOST TOOL KIT PDP-11 MACRO-11 LANGUAGE REFERENCE MANUAL 1.0-2.0 AA-V027A-TC-001 3 JAN 84 #RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT DOCUMENATION DIRECTORY 1.0 AA-X910A-TH-001 1 MAY 84 #RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT INSTALLATION GDE/RELEASE NOTES 2.0 AA-X911B-TH-001 1 MAY 84 #RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT INSTALLATION GUIDE/RELEASE NOTES 2.0 AA-X912A-TH-001 5 MAY 84 #RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT COMMAND LANG/UTILITIES MANUAL 1.0-2.0 AA-X912A-TH-001 5 MAY 84 #RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT COMMAND LANG/UTILITIES MANUAL 1.0-2.0 AA-X912A-TH-001 5 MAY 84 #RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT V2.0 SFD 40.19.01 2.0 BH-Y991B-TH-001 0 0CT 84 #RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT V2.0 SFD 40.19.01 2.0 BH-Y991B-TH-001 0 0CT 84 #RSX PROFESSIONAL REAL TIME INTERFACE LI PRILL RELEASE NOTES 1.1 AA-A140C-TH-001 0 0CT 84 #RSX PROFESSIONAL REAL TIME INTERFACE LI PRILL REGRES NOTES 1.1 AA-B140C-TH-001 0 0CT 84 #RSX PROFESSIONAL REAL TIME INTERFACE LI PRO/TO FRILL PROMPS REFERENCE MANUAL 1.1 AE-B27A-TK-001 1 JUL 84 #RSX PROFESSIONAL REAL TIME INTERFACE LI PRO/TO FRILL V1.1 SPD 40.35.01 1.1 AE-B27A-TK-001 1 0CT 84 #RSX PROFESSIONAL REAL TIME INTERFACE LI PRO/TO FRILL V1.1 SPD 40.35.01 1.1 AE-B27A-TK-001 6 APR 83 #RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC REFERENCE MANUAL (UPD \$1) 2.0 AA-L334A-TK-002 6 MAY 84 #RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC REFERENCE MANUAL (UPD \$1) 2.0 AA-L334A-TK-002 6 MAY 84 #RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC REFERENCE MANUAL (UPD \$1) 2.0 AA-L334A-TK-002 6 MAY 84 #RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC REFERENCE MANUAL (UPD \$1) 2.0 AA-L334A-TK-002 6 MAR 83	*RSX	PROFESSIONAL HOST	TOOL KIT	TERMINAL SUBSYSTEM MANUAL	1.0-2.0	AA-N623B-TK-001	2	JAN 84
#RSX PROFESSIONAL HOST TOOL KIT 14S/RSX ODT REFERENCE MANUAL SUPPLEMENT 1.0-2.0 AA-P103R-TK-001 1 JAN 84 #RSX PROFESSIONAL HOST TOOL KIT 14S/RSX ODT REFERENCE MANUAL SUPPLEMENT 1.0-2.0 AA-P103R-TK-001 1 JAN 84 #RSX PROFESSIONAL HOST TOOL KIT 15D-11 MACRO-11 LANGUAGE REFERENCE MANUAL 1.0-2.0 AA-V027A-TC-001 3 JAN 84 RSX PROFESSIONAL HOST TOOL KIT 15D-11 MACRO-11 LANGUAGE REFERENCE MANUAL 1.0-2.0 AA-X910A-TH-001 1 MAY 84 RSX PROFESSIONAL HOST TOOL KIT 15D-11 MACRO-11 LANGUAGE REFERENCE MANUAL 1.0-2.0 AA-X910A-TH-001 1 MAY 84 #RSX PROFESSIONAL HOST TOOL KIT 15D-10 KIT INSTALLATION GDIE/RELEASE NOTES 1.0 AA-X911A-TH-001 1 MAY 84 #RSX PROFESSIONAL HOST TOOL KIT 15D-10 KIT INSTALLATION GUIDE/RELEASE NOTES 2.0 AA-X911A-TH-001 1 JUL 84 #RSX PROFESSIONAL HOST TOOL KIT 15D-10 KIT	*RSX	PROFESSIONAL HOST	TOOL KIT	FRO/RMS-11: AN INTRODUCTION	1.0-2.0	AA-P098A-TK-001	1	APR 83
#RSX PROFESSIONAL HOST TOOL KIT 1AS/RSX ODT REFERENCE MANUAL SUPPLEMENT 1.0-2.0 6A-P193B-TK-001 1 JAN 84 #RSX PROFESSIONAL HOST TOOL KIT PDP-11 MACRO-11 LANGUAGE REFERENCE MANUAL 1.0-2.0 6A-V027A-TC-001 3 JAN 84 RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT DOCUMENATION DIRECTORY 1.0 6A-X910A-TH-001 1 MAY 84 #RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT INSTALLATION GDE/RELEASE NOTES 1.0 6A-X911A-TH-001 1 MAY 84 #RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT INSTALLATION GUIDE/RELEASE NOTES 2.0 6A-X911A-TH-001 1 JUL 84 #RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT COMMAND LANG/UTILITIES MANUAL 1.0-2.0 6A-X912A-TH-001 5 MAY 84 #RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT COMMAND LANG/UTILITIES MANUAL 1.0-2.0 6A-X912A-TH-001 5 MAY 84 #RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT V2.0 SPD 40.19.01 2.0 6H-Y991B-TH-001 0CT 84 #RSX PROFESSIONAL REAL TIME INTERFACE LI PRIIL RELEASE NOTES 1.1 6A-6140C-TH-001 0CT 84 #RSX PROFESSIONAL REAL TIME INTERFACE LI PRIIL RELEASE NOTES 1.1 6A-8140C-TH-001 1 JUL 84 #RSX PROFESSIONAL REAL TIME INTERFACE LI PRO/TOOL KIT V2.0 SPD 40.35.01 1.1 6A-8140C-TH-001 1 JUL 84 #RSX PROFESSIONAL REAL TIME INTERFACE LI PRO/TOOL KIT SPD 40.35.01 1.1 6A-8827A-TK-001 1 JUL 84 #RSX PROFESSIONAL REAL TIME INTERFACE LI PRO/TOOL TO SPD 1.1 6A-8827A-TK-001 1 JUL 84 #RSX PROFESSIONAL REAL TIME INTERFACE LI PRO/TOOL TO SPD 1.1 6A-8827A-TK-001 1 JUL 84 #RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC REFERENCE MANUAL 2.0-2.1 6A-L334A-TK-002 6 MAY 84 #RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC REFERENCE MANUAL (UPD \$1) 2.2 6A-L334A-TK-002 6 MAY 84 #RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC REFERENCE MANUAL (UPD \$1) 2.2 6A-L334A-TK-002 6 MAY 84 #RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC REFERENCE MANUAL (UPD \$1) 2.0 6A-C335A-TK-001 3 AFR 83	*RSX	PROFESSIONAL HOST	TOOL KIT	PRO/RMS-11 MACRO PROGRAMMER'S GUIDE	1.0-2.0	AA-P079A-TK-001	5	APR 83
#RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT DOCUMENATION DIRECTORY 1.0 AA-V927A-TC-001 3 JAN 84 RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT INSTALLATION DIRECTORY 1.0 AA-X910A-TH-001 1 MAY 84 RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT INSTALLATION GDE/RELEASE NOTES 1.0 AA-X911A-TH-001 1 MAY 84 #RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT INSTALLATION GUIDE/RELEASE NOTES 2.0 AA-X911B-TH-001 1 JUL 84 #RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT COMMAND LANG/UTILITIES NANUAL 1.0-2.0 AA-X912A-TH-001 5 MAY 84 #RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT COMMAND LANG/UTILITIES NANUAL 1.0-2.0 AA-X912A-TH-001 5 MAY 84 #RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT V2.0 SPD 40.19.01 2.0 BH-Y991B-TH-001 0CT 84 #RSX PROFESSIONAL REAL TIME INTERFACE LI PRILL RELEASE NOTES 1.1 AA-A140C-TH-001 0CT 84 #RSX PROFESSIONAL REAL TIME INTERFACE LI PRILL PROMRS REFERENCE MANUAL 1.1 AA-P411A-TK-001 3 JUL 84 #RSX PROFESSIONAL REAL TIME INTERFACE LI PRO/TOOL KIT V2.0 SPD 40.35.01 1.1 AE-BL52B-TH-001 0CT 84 #RSX PROFESSIONAL REAL TIME INTERFACE LI PRO/TK FRIIL V1.1 SPD 40.35.01 1.1 AE-BL52B-TH-001 0CT 84 #RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC REFERENCE MANUAL (UPD \$1) 2.2 AA-L334A-TK-002 6 MAY 84 RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC REFERENCE MANUAL (UPD \$1) 2.2 AA-L334A-TK-002 6 MAY 84 RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC REFERENCE MANUAL (UPD \$1) 2.0-2.1 AA-L335A-TK-002 6 MAY 84 RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC REFERENCE MANUAL (UPD \$1) 2.0-2.1 AA-L335A-TK-002 6 MAY 84	*RSX	PROFESSIONAL HOST	TOOL KIT	PRO/FMS-11 DOCUMENTATION SUPPLEMENT	1.0-2.0	AA-F103B-TK-001	1	JAN 84
RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT DOCUMENATION DIRECTORY 1.0 AA-X910A-TH-001 1 MAY 84 RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT INSTALLATION GDE/RELEASE NOTES 1.0 AA-X911A-TH-001 1 MAY 84 #RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT INSTALLATION GUIDE/RELEASE NOTES 2.0 AA-X911A-TH-001 5 MAY 84 #RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT COHMAND LANG/UTILITIES MANUAL 1.0-2.0 AA-X912A-TH-001 5 MAY 84 #RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT V2.0 SPD 40.19.01 2.0 AA-Y660A-TH-001 0CT 84 #RSX PROFESSIONAL REAL TIME INTERFACE LI PRO/TOOL KIT V2.0 SPD 40.19.01 2.0 BH-Y991B-TH-001 0CT 84 #RSX PROFESSIONAL REAL TIME INTERFACE LI PRO/TO KIT V2.0 SPD 40.19.01 1.1 AA-F411A-TK-001 3 JUL 84 #RSX PROFESSIONAL REAL TIME INTERFACE LI PRO/TK FRILL V1.1 SPD 40.3S.01 1.1 AB-B27A-TK-001 1 JUL 84 #RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC REFERENCE MANUAL 2.0-2.1 AA-L334A-TK-001 6 APR 83 <td>*RSX</td> <td>PROFESSIONAL HOST</td> <td>TOOL KIT</td> <td>IAS/RSX ODT REFERENCE MANUAL SUPPLEMENT</td> <td>1.0-2.0</td> <td>-AA-P193B-TK-001</td> <td>1</td> <td>JAN 84</td>	*RSX	PROFESSIONAL HOST	TOOL KIT	IAS/RSX ODT REFERENCE MANUAL SUPPLEMENT	1.0-2.0	-AA-P193B-TK-001	1	JAN 84
RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT INSTALLATION GDE/RELEASE NOTES 1.0 AA-X911A-TH-001 1 MAY 84 #RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT INSTALLATION GUIDE/RELEASE NOTES 2.0 AA-X911A-TH-001 1 JUL 84 #RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT COMMAND LANG/UTILITIES NAMUAL 1.0-2.0 AA-X912A-TH-001 5 MAY 84 #RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT V2.0 SPD 40.19.01 2.0 AA-Y991B-TH-001 0CT 84 #RSX PROFESSIONAL REAL TIME INTERFACE LI PRO/TOOL KIT V2.0 SPD 40.19.01 2.0 RH-Y991B-TH-001 0CT 84 #RSX PROFESSIONAL REAL TIME INTERFACE LI PRO/TOOL KIT V2.0 SPD 40.19.01 1.1 AA-AI40C-TH-001 0CT 84 #RSX PROFESSIONAL REAL TIME INTERFACE LI PRO/TO SPD 1.1 AE-BP27A-TK-001 1 JUL 84 #RSX PROFESSIONAL REAL TIME INTERFACE LI PRO/TK FRTIL V1.1 SPD 40.35.01 1.1 AE-BP27A-TK-001 1 JUL 84 #RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC REFERENCE MANUAL (UPD \$1) 2.0 AA-L334A-TK-001 6 APR 83 #RSX	*RSX	PROFESSIONAL HOST	TOOL KIT	FUF-11 MACRO-11 LANGUAGE REFERENCE MANUAL	1.0-2.0	AA-V027A-TC-001	3	JAN 84
#RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT INSTALLATION GUIDE/RELEASE NOTES 2.0 AA-X911B-TH-001 1 JUL 84 #RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT COMMAND LANG/UTILITIES MANUAL 1.0-2.0 AA-X912A-TH-001 5 MAY 84 #RSX PROFESSIONAL HOST TOOL KIT PRO GIDIS MANUAL (UFD#1) 2.0 AA-Y660A-TH-001 0CT 84 #RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT V2.0 SFD 40.19.01 2.0 BH-Y991B-TH-001 0CT 84 #RSX PROFESSIONAL REAL TIME INTERFACE LI PRTIL RELEASE NOTES 1.1 AA-A140C-TH-001 0CT 84 #RSX PROFESSIONAL REAL TIME INTERFACE LI PRTIL PROMRS REFERENCE MANUAL 1.1 AA-P411A-TK-001 3 JUL 84 #RSX PROFESSIONAL REAL TIME INTERFACE LI PRO/TK FRTIL V1.1 SPD 40.35.01 1.1 AE-BL52B-TH-001 0CT 84 #RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC REFERENCE MANUAL 2.0-2.1 AA-L334A-TK-001 6 APR 83 #RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC REFERENCE MANUAL (UPD #1) 2.2 AA-L334A-TK-002 6 MAY 84 #RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC REFERENCE MANUAL (UPD #1) 2.0-2.1 AA-L335A-TK-001 3 AFR 83	RSX	PROFESSIONAL HOST	TOOL KIT	PRO/TOOL KIT DOCUMENATION DIRECTORY	1.0	AA-X910A-TH-001	1	MAY 84
#RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT COMMAND LANG/UTILITIES MANUAL 1.0-2.0 AA-X912A-TH-001 5 MAY 84 #RSX PROFESSIONAL HOST TOOL KIT PRO GIDIS MANUAL (UFD#1) 2.0 AA-Y660A-TH-001 0CT 84 #RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT V2.0 SPD 40.19.01 2.0 BH-Y991B-TH-001 0CT 84 #RSX PROFESSIONAL REAL TIME INTERFACE LI PRIIL RELEASE NOTES 1.1 AA-AI-40C-TH-001 0CT 84 #RSX PROFESSIONAL REAL TIME INTERFACE LI PRIIL PROMRS REFERENCE MANUAL 1.1 AA-P411A-TK-001 3 JUL 84 #RSX PROFESSIONAL REAL TIME INTERFACE LI ADDENDUM TO SPD 1.1 AE-BF27A-TK-001 1 JUL 84 #RSX PROFESSIONAL REAL TIME INTERFACE LI PRO/TK FRIIL V1.1 SPD 40.35.01 1.1 AE-BL52B-TH-001 0CT 84 RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC REFERENCE MANUAL 2.0-2.1 AA-L334A-TK-001 6 APR 83 #RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC REFERENCE MANUAL (UPD #1) 2.2 AA-L334A-TK-002 6 MAY 84 RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC USER'S GUIDE 2.0-2.1 AA-L335A-TK-001 3 AFR 83	RSX	PROFESSIONAL HOST	TOOL KIT	PRO/TOOL KIT INSTALLATION GDE/RELEASE NOTES	1.0	AA-X911A-TH-001	1	MAY 34
ARSX PROFESSIONAL HOST TOOL KIT PRO GIDIS MANUAL (UFD#1) 2.0 AA-Y660A-TH-001 OCT 84 #RSX PROFESSIONAL HOST TOOL KIT PRO/TOOL KIT V2.0 SPD 40.19.01 2.0 BH-Y991B-TH-001 OCT 84 #RSX PROFESSIONAL REAL TIME INTERFACE LI FRTIL RELEASE NOTES 1.1 AA-AI40C-TH-001 OCT 84 #RSX PROFESSIONAL REAL TIME INTERFACE LI FRTIL PROHRS REFERENCE MANUAL 1.1 AA-P411A-TK-001 3 JUL 84 #RSX PROFESSIONAL REAL TIME INTERFACE LI ADDENDUM TO SPD 1.1 AE-B152B-TH-001 OCT 84 RSX PROFESSIONAL REAL TIME INTERFACE LI PRO/TK FRTIL V1.1 SPD 40.35.01 1.1 AE-B152B-TH-001 OCT 84 RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC REFERENCE MANUAL 2.0-2.1 AA-L334A-TK-001 6 APR 83 #RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC USER'S GUIDE 2.0-2.1 AA-L335A-TK-001 3 AFR 83	*RSX	PROFESSIONAL HOST	TOOL KIT	PRO/TOOL KIT INSTALLATION GUIDE/RELEASE NOTES	2.0	AA-X9118-TH-001	1	JUL 84
#RSX PROFESSIONAL REAL TIME INTERFACE LI PRTIL RELEASE NOTES #RSX PROFESSIONAL REAL TIME INTERFACE LI PRTIL PRGHRS REFERENCE MANUAL #RSX PROFESSIONAL REAL TIME INTERFACE LI PRTIL PRGHRS REFERENCE MANUAL #RSX PROFESSIONAL REAL TIME INTERFACE LI ADDENDUM TO SPD #RSX PROFESSIONAL REAL TIME INTERFACE LI PRO/TK FRTIL V1.1 SPD 40.35.01 #RSX PROFESSIONAL REAL TIME INTERFACE LI PRO/TK FRTIL V1.1 SPD 40.35.01 #RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC REFERENCE MANUAL #RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC REFERENCE MANUAL (UPD \$1) #RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC REFERENCE MANUAL (UPD \$1) #RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC REFERENCE MANUAL (UPD \$1) #RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC USER'S GUIDE	*RSX	PROFESSIONAL HOST	TOOL KIT	PRO/TOOL KIT COMMAND LANG/UTILITIES MANUAL	1.0-2.0	AA-X912A-TH-001	5	HAY 84
*RSX PROFESSIONAL REAL TIME INTERFACE LI PRTIL RELEASE NOTES 1.1 AA-AI40C-TH-001 OCT 84 *RSX PROFESSIONAL REAL TIME INTERFACE LI PRTIL PRGMRS REFERENCE MANUAL 1.1 AA-F411A-TK-001 3 JUL 84 *RSX PROFESSIONAL REAL TIME INTERFACE LI ADDENDUM TO SPD 1.1 AE-BB27A-TK-001 1 JUL 84 *RSX PROFESSIONAL REAL TIME INTERFACE LI PRO/TK PRTIL V1.1 SPD 40.35.01 1.1 AE-BL52B-TH-001 OCT 84 RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC REFERENCE MANUAL *RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC REFERENCE MANUAL (UPD \$1) 2.2 AA-L334A-TK-002 6 MAY 84 RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC USER'S GUIDE 2.0-2.1 AA-L335A-TK-001 3 AFR 83	#RSX	PROFESSIONAL HOST	TOOL KIT	PRO GIDIS MANUAL (UFI#1)	2.0	AA-Y660A-TH-001		OCT 84
#RSX PROFESSIONAL REAL TIME INTERFACE LI FRTIL FRGMRS REFERENCE MANUAL #RSX PROFESSIONAL REAL TIME INTERFACE LI ADDENDUM TO SPD #RSX PROFESSIONAL REAL TIME INTERFACE LI FRO/TK FRTIL V1.1 SFD 40.35.01 #RSX PROFESSIONAL REAL TIME INTERFACE LI FRO/TK FRTIL V1.1 SFD 40.35.01 #RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC REFERENCE MANUAL #RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC REFERENCE MANUAL (UPD \$1) #RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC REFERENCE MANUAL (UPD \$1) #RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC USER'S GUIDE	*RSX	FROFESSIONAL HOST	TOOL KIT	FRO/TOOL KIT V2.0 SPD 40.19.01	2.0	BH-Y991B-TH-001		OCT 84
*RSX PROFESSIONAL REAL TIME INTERFACE LI ADDENDUM TO SPD 1.1 AE-BB27A-TK-001 1 JUL 84 RSX PROFESSIONAL REAL TIME INTERFACE LI PRO/TK PRTIL V1.1 SPD 40.35.01 1.1 AE-BL52B-TH-001 0CT 84 RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC REFERENCE MANUAL 2.0-2.1 AA-L334A-TK-001 6 APR 83 *RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC REFERENCE MANUAL (UPD \$1) 2.2 AA-L334A-TK-002 6 MAY 84 RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC USER'S GUIDE 2.0-2.1 AA-L335A-TK-001 3 AFR 83	*RSX	PROFESSIONAL REAL	TIME INTERFACE LI	PRTIL RELEASE NOTES	1.1	AA-AI400-TH-001		001 84
#RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC REFERENCE MANUAL 2.0-2.1 AA-L334A-TK-001 6 APR 83 #RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC REFERENCE MANUAL (UPD \$1) 2.2 AA-L334A-TK-002 6 MAY 84 RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC USER'S GUIDE 2.0-2.1 AA-L335A-TK-001 3 AFR 83	*RSX	PROFESSIONAL REAL	TIME INTERFACE LI	FRTIL FROMRS REFERENCE MANUAL	1.1	AA-F411A-TK-001	3	JUL 84
RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC REFERENCE MANUAL 2.0-2.1 AA-L334A-TK-001 6 APR 83 **RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC REFERENCE MANUAL (UPD \$1) 2.2 AA-L334A-TK-002 6 MAY 84 RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC USER'S GUIDE 2.0-2.1 AA-L335A-TK-001 3 AFR 83	*RSX	PROFESSIONAL REAL	TIME INTERFACE LI	ADDENDUM TO SPD	1.1	AE-BB27A-TK-001	1	JUL 84
*RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC REFERENCE MANUAL (UPD \$1) 2.2 AA-L334A-TK-002 6 MAY 84 RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC USER'S GUIDE 2.0-2.1 AA-L335A-TN-001 3 AFR 83	#RSX	PROFESSIONAL REAL	TIME INTERFACE LI	PRO/TK FRTIL V1.1 SPI 40.35.01	1.1	AE-BL52B-TH-001		OCT 84
RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC USER'S GUIDE 2.0-2.1 AA-L335A-TN-001 3 AFR 83	RSX	FROFESSIONAL TOOL	KIT BASIC-PLUS-2	BASIC REFERENCE MANUAL	2.0-2.1	AA-L334A-TK-001	6	APR 83
	*RSX	PROFESSIONAL TOOL	KIT BASIC-PLUS-2	BASIC REFERENCE MANUAL (UPD \$1)	2.2	AA-L334A-TK-002	6	HAY 84
*RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC USER'S GUILLE (UPIN\$1) 2.2 AA-L335A-TK-002 3 MAY 84	RSX	FROFESSIONAL TOOL	KIT BASIC-PLUS-2	BASIC USER'S GUIDE	2.0-2.1	AA-L335A-TN-001	3	AFR 83
	*RSX	PROFESSIONAL TOOL	KIT BASIC-PLUS-2	BASIC USER'S GUIDE (UPD#1)	2.2	AA-L335A-TK-002	3	MAY 84

PART NUMBER TITLE NUMBER **OPERATING** PRODUCT 0F REV OF SYSTEH NAME MANUAL VERSION LEVEL FICHE DATE JAN 84 RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC ON RSX-11H/H-PLUS SYSTEMS (UPD#1) 2.1 AA-L338A-TC-001 1 *RSX FROFESSIONAL TOOL KIT BASIC-FLUS-2 BASIC ON RSX-11H/H-PLUS SYSTEMS (UPD#1 & #2) 2.2 AA-L338A-TC-002 HAY 84 RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 BASIC-PLUS-2 DOCUMENTATION SUPPLEMENT 2.1 AA-P102B-TK-001 1 JAN 84 *RSX PROFESSIONAL TOOL KIT BASIC-FLUS-2 BASIC-FLUS-2 DOCUMENTATION SUPPLEMENT 2.2 AA-F102C-TK-001 1 HAY 84 RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 PRO TOOL KIT BASIC + 2 INSTL GUE/REL NTS 2.1 JAN 84 AA-F104B-TK-001 1 RSX PROFESSIONAL TOOL KIT BASIC-PLUS-2 FRO TOOL KIT BASIC-FLUS-2 V2.2 SPD 30.27.01 2.2 AE-P650B-TK-001 1 MAY 84 **#RSX** PROFESSIONAL TOOL KIT BASIC-PLUS-2 PRO TOOL KIT BASIC-PLUS-2 V2.2 SPD 30.27.03 2.2 AE-P650D-TK-001 1 JUL 34 *RSX PROFESSIONAL TOOL NIT BASIC-PLUS-2 BASIC FOCKET REFERENCE GUIDE APR 83 2.0-2.2 AV-L341A-TK-001 ***RSX** PROFESSIONAL TOOL KIT COBOL-81 COBOL-81 LANGUAGE REFERENCE MANUAL 2.1 AA-J4348-TE-001 4 MAY 84 #RSX 2.1 PROFESSIONAL TOOL KIT COROL-81 RSX-11H/H-FLUS USER'S GUIDE AA-H179B-TC-001 5 MAY 84 ¥RSX PROFESSIONAL TOOL KIT COBOL-81 FRO TOOL KIT COROL-81 INSTL GDE/DOC SUPL 2.1 AA-Y285A-TH-001 1 JUL 84 *RSX PROFESSIONAL TOOL KIT COROL-81 FRO TOOL KIT COROL-81 V2.1 SFD 40.24.00 2.1 AE-2764A-TH-001 **UCT 84** *RSX FROFESSIONAL TOOL KIT COBOL-81 COFOL-81 POCKET GUIDE 2.1 AU-H630E-TC-001 2 MAY 84 **#RSX** PROFESSIONAL TOOL KIT DIBOL DIBOL FOR BEGINNERS JUL 84 1.5 AA-BI77A-TK-001 1 RSX PROFESSIONAL TOOL NIT DIEDL INTRODUCTION TO DIBOL 1.0-1.6 AA-P042A-TK-001 1 APR 83 #RSX PROFESSIONAL TOOL KIT DIBOL INTRODUCTION TO DIBOL 1.6 AA-P042E-TK-001 1 JUL 84 RSX PROFESSIONAL TOOL KIT DIBOL USER'S GUIDE AA-P043A-TK-001 2 AFR 83 PROFESSIONAL TOOL KIT DIROL 1.0 #R'SX PROFESSIONAL TOOL KIT DIROL PROFESSIONAL TOOL KIT DIBOL USER'S GUIDE AA-F043E-TK-001 2 MAY 84 1.6 RGX PROFESSIONAL TOOL KIT DIPOL PROFESSIONAL TOOL WIT DIBOL LANG REP MANUAL 64-5,44A-TK-001 3 APR 83 1.0 RSX PROFESSIONAL TOOL KIT DIROL PROFESSIONAL TOOL KIT DIBOL REL NIS/INSTL GDE 1.0 AH-F045A-IK-001 1 AFR 83 #RSX PROFESSIONAL TOO', KIT DIBOL PROFESSIONAL TOOL KIT BIBOL REL NIS/INSIL GDE 1.6 AA-F045C-TK-001 nay 84 **#RSX** PROFESSIONAL TOOL KIT DIBOL DIFOL-83 LANGUAGE REFERENCE MANUAL (UFD#1) 1.6 AA-U066A-IK-001 FEB 84 RSX PROFESSIONAL TOOL KIT DIEDL DIBOL LANGUAGE REFERENCE CARD 1.6 AA-U067A-Th-001 MAY 84 **#RSX** PROFESSIONAL TOOL KIT DIBOL DIROL-83 COMPATIFILITY MANUAL 1,6 AA-V810R-TK-001 1 MAY 84 #RSX FEB 84 PROFESSIONAL TOOL KIT DIBOL FRO TOOL NIT MESSAGE MANUAL 1.5 AA-Z515A-TK-001 1 ***RSX** PROFESSIONAL TOOL KIT DIBOL DIROL-83 LANGUAGE REFERÊNCE CARIJ 1.5 AU-U067A-TK-001 1 JUL 84

OPERATING SYSTEM	FRODUCT NAME	TITLE OF MANUAL	VERSION	PART NUMBER REV LEVEL	NUMBER OF FICHE	DATE
*RSX	PROFESSIONAL TOOL KIT FORTRAN-77	FRO HOST TK F-77 IG/DOC SUPL	5.0	AA-R387B-TK-001		JAN 84
*RSX	FROFESSIONAL TOOL KIT FORTRAN-77	PDF-11 F-77 LANGUAGE REFERENCE MANUAL	5.0	AA-U193A-TK-001		FEB 84
*RSX	PROFESSIONAL TOOL KIT FORTRAN-77	FDP-11 FORTRAN-77 USER'S GUIDE	5.0	AA-V194A-TK-001		FEB 84
*RSX	PROFESSIONAL TOOL KIT FORTRAN-77	PDF-11 FORTRAN-77 OTS REFERENCE MANUAL	5.0	AA-V195A-TK-001		FEB 04
RSX	PROFESSIONAL TOOL KIT FORTRAN-77	FRO TOOL KIT FORTKAN-77 V5.0 SPD 30.38.01	5.0	AE-W5878-TK-001	1	MAY 84
*RSX	rROFESSIONAL TOOL KI; FORTRAN-77	PRO TOOL KIT FORTRAN-77 V5.0 SPD 30.38.02	5.0	AE-W58/C-TK-001		JUL 84
*RSX		PRO TOOL KIT FORTRAN-77/DBG IG/DOC SUFL	1.0	AA-Z384A-TK-001		MAY S4
*RSX		PRO TOOL KIT FORTWAN-77/DBG V1.0 SPD 40.25.00		AE-Z847A-TH-001	1	JUL 84
RSX	PROFESSIONAL TOOL KIT PASCAL	PRO TOOL KIY PASCAL INSTL/REL NOTES	1.1	4A-R7598-TK-001		MAY 84
*RSX	PROFESSIONAL TOOL KIT FASCAL		1.2	AA-R759C-TK-001		JUL 84
*RSX	PROFESSIONAL TOOL KIT PASCAL		1.1-1.2			JAN 84
*RSX	PROFESSIONAL TOOL NIT PASCAL	FRO TOOL KIT FASCAL LANGUAGE REFERENCE MANUAL				JAN 84
*RSX	RGL-11	RGL-11 PROGRAMMER'S REFERENCE HANUAL	1.1	AA-M837A-TC-001		APR 83
*RSX	RGL-11	RGL-11 INSTALLATION GUIDE	1.1	AA-M838A-TC-001	1	AFR 83
RSX	RGL-11	RELEAGE NOTES FOR RGL-11	1.1	AA-M839A-TC-001		APR 83
*RSX	RGL-11	RELEASE NOTES FOR RGL-11	1.1	AA-M839R-TC-001		FER 84
RSX	RGL-11	RGL-11 V1.1 SFD 14.62.3	1.1	AE-H801D-TC-001		FEB 84
*RSX	RGL-11	RGL-11 V1.1 SPD 14.62.04	1.1	AE-H802E-TC-001		HAY 84
*RSX	RSN 11 2780/3780 EMULATOR	RSX-11 2780/3780 EMULATOR USER'S GUIDE	4.1	AA-3581A-TC-001		SEP 82
RSX	RSX 11 2780/3780 EMULATOR	RSX11 2780/3780 EMUL V4.1 SFD 10.01.01	4.1	AE-K997B-TC-001		HAY 84
*RSX	RSX 11 2780/3780 EMULATOR	RSX11 2780/3780 EMUL 94.1 SFD 10.01.02	4.1	AE-K997C-TC-001		OCT 84
*RSX	RSX 11 PSI/M	INTRODUCTION TO RSX-11 .'S1	2.0	AA-#369A-TC-001		SEF 82
*RSX	RSX 11 PSI/H	RSX-11 FSI SYSTEM MANAGER'S GUIDE	2.0	AA-H370A-TC-001		SEP 82
*RSX	RSX 11 FSI/M	RSX-11 PSI USER'S GUIDE				SEP 82
*RSX	RSX 11 PSI/H	RSX-11 PSI GENERATION GUIDE	2.0	AA-M371A-TC-001 AA-M372A-TC-001		SEP 82
*RSX	RSX 11 PSI/M	RSX-11 PSI NETWORN SPECIFIC INFORMATION	2.0	AA-A373A-TC-001		SEP 82
THUN	NVA 11 1 V1/11	NOW IT IST HELMONN SLEETLIE THE GRUNNITOR	2+0	NH 113/3H-10-001	1	SET OZ

OPERATING SYSTEM	PRODUCT NAMF:	TITLE OF HANUAL	VERSION	PART NUMBER REV LEVEL	NUMBER OF FICHE	DATE
#RSX	RSX 11 PSI/M	RSX-11 PSI RELEASE NOTES	2.0	AA-N374A-TE-001	1	SEP 82
#RSX	RSX 11 FSI/M	RSX-11 F5J/M V2.0 SFD 10.42.0	2.0	AE-N141B-TC-001	1	FEB 84
#RSX	RSX 11 PSI/H	RSX-11 PSI REFERENCE CARD	2.0	AV-H749A-TE-001	1	SEP 82
#RSX	RSX 11/FROVUE	PROVUE SYSTEM MANAGER'S GUIDE	2.0	AA-H021B-TK-001	1	JAN 84
*RSX	RSX 11/FROVUE	PROVUE SYSTEM BUILD MANUAL	2.0	AA-H022B-TK-001	1	JAN 84
#RSX	RSX 11/PKOVUE	PROVUE TERMINAL USER'S GUIDE	2.0	AA-M0238-TK-001	1	JAN 84
#RSX	RSX 11/PROVUE	PROVUE OFFLINE FICTURE SYSTEM MANUAL	2.0	AA-M024R-TK-001	1	JAN 84
#RSX	RSX 11/FROVUE	PROVUE ONLINE FICTURE SYSTEM MANUAL	2.0	AA-M025B-TK-001	1	JAN 84
#RSX	RSX 11/FROVUE	PROVUE PROGRAMMING GUIDE	2.0	AA-M026B-TK-001	1	JAN 84
#RSX	RSX 11/FROVUE	PROVUE UTILITY GUIDE	2.0	AA-H027B-TK-001	1	JAN 84
*RSX	RSX 11/FROVUE	PROVUE V2.0 RELEASE NOTES	2.0	AA-M089B-TK-001	1	JAN 84
*RSX	RSX 11/PROVUE	PROVUE V2.0 SPE 14.33.1	2.0	AE-N2718-TC-001	1	FEB 84
#RSX	RSX 11H 3271 FROTOCOL EMULATOR	RSX-11/3271 PE PROGRAMMER'S GUIDE	3.0	AA-C739B-TC-001	2	APR 83
*RSX	RSX 11H 3271 FROTOCOL EMULATOR	RSX-11/3271 FE SYSTEM MANAGER'S GUIDE	3.0	AA-C739C-TC-001	3	APR 83
#RSX	RSX 11M 3271 PROTOCOL EMULATOR	RSX-11/3271 FE RELEASE NOTES V3.0	3.0	AA-H0320-T0-001	1	AFR 83
*RSX	RSX 11H 3271 PROTOCOL EMULATOR	3270 TERMINAL EMULATOR KEYBOARD LAYOUT	3.0	AV-P075A-TE-001	1	APR 83
*RSX	RSX 11H F ENHANC PKG FGR HINC	SCIENTIFIC SUBROUTINES PROG REF MAN (UFD#1)	1,1-1,2	AA-1101D-TC-001	2	APR 83
#RSY	RSX 11H F ENHANC PKG FOR HINC	LAB SUBROUTINES PROG REF MAN (UPD#1)	1.1-1.2	AA-C984C-TC-001	3	APR 83
*RSX	RSX 11H F ENHANC PKG FOR MINC	REALIIM/MNC FORTTRAN PROG REF MAN (UPD#1,2)	1.1-1.2	AA-D631C-TC-001	4	APR 83
#RSX	RSY 11M F ENHANC PKG FOR HINC	INTRODUCTION TO FEF AND FRP	1.1-1.2	AA-J302E-TC-001	1	AFR 83
#RSX	RSX 11H F ENHANC PKG FOR HINC	RSX-11M FEP AND FRP INSTALLATION/USRS GDE	1.2	AA-J303E-TC-001	2	JAN 84
#RSX	RSX 11M F ENHANC PKG FOR HINC	RELEASE NOTES FOR RSX-11M/FEP AND FRP	1.2	AA-M055II-TC-001	1	JAN 84
*RSX	RSX 11H F ENHANC PKG FOR MINC	RGL/11 PROGRAMMER'S REFERENCE MANUAL	1.1-1.2	AA-M837A-TE-001	3	APR 83
#RSX	RSX 11H F ENHANC FKG FOR HINC	RSX-11H/FEP V1.2 SPD 14.44.4	1.2	AE-L762E-TC-001	1	FEB 84
#RSX	RSX 11M F ENHANC FKG FOR MINC	RGL/11 PROGRAMMERS REFERENCE MANUAL ERRA.A	1.2	AV-V185A-TC-001	1	JAN 84
≢RSX	RSX 11H F ENHANC PKG FOR MINC	REAL-11 PROGRAMMERS REFERENCE MANUAL ERRATA	1.2	AV-V187A-TC-001	i	JUL 84

OPERATING SYSTEM	FRODUCT NAME	TITLE OF MANUAL	VERSION	PART NUMBER REV LEVEL	NUMBER OF FICHE	DATE
*RSX	RSX 11H F ENHANC PKG FOR HINC	SSP REFERENCE MANUAL ERRATA SHEET	1.2	AV-V189A-TC-001	1	JAN 84
*RSX	RSX 11H F ENHANC PKG FOR MINC	LSP REFERENCE MANUAL ERRATA SHEET	1.2	AV-V190A-TC-001	1	JAN 84
#RSX	RSX 11H F ENHANC PKG FOR MINC	INTRO TO FEP & FRP ERRATA SHEET	1.2	AV-V171A-TC-001	1	JAN 84
*RSX	RSX 11H F EMHANC PXG FOR HINC	MICROCOMPUTERS AND MEMORIES HANDBOOK	1.1-1.2	EB-20912-20-001	8	APR 83
*RSX	RSX 11M F ENHANC PKG FOR MINC	PDP-11 MICROCOMPUTER INTERFACES HANDBOOK	1.1-1.2	EB-23144-18-001	7	APR 83
*RSX	RSX 11H F ENHANC PKG FOR HINC	NECLAR-11/MINC USER'S GUIDE	1.1-1.2	EK-HNC11-UG-001	2	AFR 83
*RSX	RSX 11M F ENHANC PKG FOR HINC	HINC THERMOCOUPLE PREAMPLIFIER USER'S GUIDE	1.1-1.2	EK-HNCTP-UG-001	1	APR 83
RSX	RSX 11M IAS RJE/HASP	RJE/HASP WORKSTATION INSTALLATION GUIDE	1.1	AA-5426C-TC-001	1	SEP 82
*RSX	RSX 11M IAS RJE/HASP	RJE/HASP WORKSTATION INSTALLATION GUIDE	1.1	AA-5426D-TC-001	1	JUL 84
RSX	RSX 11M IAS RJE/HASP	RJE/HASP WORKSTATION OPERATOR'S GUIDE	1.1	AA-5427C-TC-001	1	SEP 82
*RSX	RSX 11M IAS RJE/HASF	RJE/HASP WORKSTATION OPERATOR'S GUIDE	1.1	AA-5427D-TC-001	1	JUL 84
*RSX	RSX 11M IAS RJE/HASP	RSX11M IAS RJE/HASP V1.1 SPD 10.51.6	1.1	AE-5248G-TC-001	1	FEB 84
*RSX	RSX 11M PLUS DECTYPE	DECTYPE REFERENCE MANUAL	3.0	AA-R124B-TK-G01	2	JUL 84
RSX 11 PLU	RSX 11M PLUS DECTYPE	USING DECTYPE	3.0	AA-R125B-TK-001	3	JUL 84
RSX 11 PLU	J RSX 11H PLUS DECTYPE	INSTALLING AND MANAGING DECTYPE	3.0	AA-Z960A-TC-001	1	JUL 84
RSX 11 PLU	RSX 11M PLUS DECTYPE	DECTYPE V3.0 SPD 14.82.00	3.0	AE-BG31A-TC-001	1	JUL 84
RSX 11 PLU	J RSX 11H PLUS DECTYPE	DECTYPE KEYBOARD LAYOUT	3.0	AV-R127A-TK-001	1	JUL 84
RSX 11 PLU	RSX 11H PLUS DECTYPE	DETYPE QUICK REFERENCE GUIDE	3.0	AV-R128B-TK-001	1	JUL 84
RSX 11 PLU	J RSX 11M PLUS DIBOL	DIBOL FOR BEGINNERS	1.0	AA-B177A-TK-001	1	JUL 84
RSX 11 PLU	RSX 11M PLUS BIBOL	FRO TOOL KIT INTRODUCTION TO DIBOL-83	1.0	AA-F042B-TK-001	1	JUL 84
RSX 11 PLL	RSX 11M PLUS DIBOL	DIBOL-83 LANGUAGE REFERENCE MANUAL (GPD#1)	1.0	AA-U066A-TK-001	2	JUL 84
RSX 11 FLU	RSX 11M PLUS DIBOL	DIBOL-83 COMPATIBILITY GUIDE	1.0	AA-V810B-TK-001	1	JUL 84
RSX 11 PLU	RSX 11M PLUS DIBOL	M4/MICRO RSX DIBOL USER'S GUIDE	1.0	AA-Z885A-TC-001	2	JUL 84
RSX 11 PLU	RSX 11M PLUS DIROL	HH/MICRO RSX DIBOL RELEASE NOTES/INSTL GDE	1.0	AA-Z886A-TC-001	1	JUL 84
RSX 11 PLU	RSX 11M PLUS DIBOL	H+/HICRO RSX DB HESSAGE HANUAL	1.0	AA-Z887A-TC-001	1	JUL 84
RSX 11 PLL	RSX 11H PLUS DIROL	DIBOL-83 LANGUAGE REFERENCE CARD	1.0	AV-U067A-TK-001	1	JUL 84

OPERATING		TITLE OF	HEDGION	PART NUMBER REV	NUMBER OF	
SYSTEH	NAME	MANUAL	VERSION		FICHE	DATE
*RSX	RSX 11M SNA PE	RSX11H/SNA PE CONCEPTS AND FACILITIES (UPD#1)	1.1	AA-5501A-TC-001	2	SEP 82
*RSX	RSX 11M SNA PE	RSX11H/SNA FE SYSTEM MANAGER'S GUIDE (UFD#1)	1.1	AA-5502A-TC-001	2	SEP 82
*RSX	RSX 11M SNA PE	RSX11M/SNA PE APPLICATIONS PROGRAMMER'S GUIDE	1.1	AA-5503B-TC-001	2	SEP 82
*RSX	RSX 11M SNA PE	RSX11H/SNA PE RELEASE NOTES (UPD#1)	1.1	AA-J549A-TC-001	1	SEP 82
*RSX	RSX 11M SNA PE	RSX 11H SNA PE VI.1 SPI 14.04.1	1.1	AE-J512C-TC-001	1	FEB 84
*RSX	RSX DLX-11	RSX DLX-11 USER'S GUIDE	1.0	AA-K142A-TC-001	2	SEP 82
≭ RSX	RSX DLX-11	RSX DLX-11 RELEASE NOTES	1.0	AA-K143A-TC-001	1	SEP 82
*RSX	RSX DLX-11	RSX DLX-11 V1.0 SPD 10.6.0	1.0	AE-K4348-TC-001	1	FEB 84
#RSX	RSX MDE/T11	HDE/T-11 USER'S GDE/REF MANUAL	1.0	AA-M8458-TK-001	3	APR 83
*RSX	RSX MDE/T11	RSX11M/M+ MDE/T11 SFTW INSTL GDE/REL NTS	1.0	AA-N998A-TC-001	i	APR 83
≭ RSX	RSX MDE/T11	RSX HDE/T-11 V1.0 SPD 14.23.0	1.0	AE-P081B-TC-001	1	FEB 84
*RSX	RSX MDE/T11	MDE/T11 REFERENCE CARD	1.0	AV-M846B-TK-001	1	FEB 84
*RSX	RSX MDE/T11	MDE/T-11 V1.0 INSTL GDE/REL NTS	1.0	AV-P511A-TC-001	1	APR 83
RSX	RTEH-11	RTEM-11 USER'S MANUAL	1.1	AA-N435B-TK-001	2	JAN 84
*RSX	RTEH-11	RTEM-11 USER'S GUIDE	2.0	AA-N435C-TK-001	2	MAY 84
RSX	RTEM-11	RTEM-11 INSTL GUIDE/RELEASE NOTES (UFD#1)	1.1	AA-N436A-TK-001	2	JAN 84
*RSX	RTEM-11	RTEM-11 INSTALLATION GUIDE	2.0	AA-N4368-TK-001	1	MAY 84
*RSX	RTEH-11	RTEM-11 RELEASE NOTES	2.0	AA-W325A-TK-001	1	HAY 84
*RSX	RTEM-11	RTEM-11 V2.0 SFD 30.21.04	2.0	4E-N571E-TK-001	1	HAY 84
RSX	SORT-11	PDP11 SORT REFERENCE MANUAL (UPDATE \$1)	2.0	AA-3341C-TC-001	2	SEP 82
*RSX	SORT-11	PDP-11 SORT/MERGE USER'S GUIDE	3.0	AA-CI67A-TC-001	2	JUL 84
RSX	SCRT-11	SORT-11 V2.0 SPD 12.7.5	2.0	AE-5429G-TC-001	1	FEB 84
*RSX	SORT-11	SORT-11 V3.0 SPD 12.07.07	3.0	AE-5429H-TE-001	1	JUL 84
≭RSX	SSP-11	SCIENTIFIC SUB PROGRAMMER'S REF HAN (UPD#1)	1.3	AA-1101D-TC-001	2	SEP 82
RSX	SSP-11	SSF-11 V1.3 SFD 15.45.9	1.3	AE-3413H-TC-001	1	FED 84
*RSX	SSF-11	SSP-11 V1.3 SPD 15.45.10	1.3	AE-3413I-TC-U01	1	MAY 84

GFERATING SYSTEM	PRODUCT NAME	TITLE OF MANUAL	VERSION	FART NUMBER REV LEVEL	NUMBER OF FICHE	DATE
*RSX	SSP-11	ADDENDUM TO SPD	1.3	AE-8827A-TK-001	1	HAY 84
*RSX	UN1004	UN1004/RSX RELEASE NOTES	2.0	AA-1341C-TC-001	1	SEP 82
*RSX	UN1004	UN1004/RSX USRS GDE/SYS GEN GDE (UPD#1)	2.0	AA-1342B-TC-001	1	SEP 82
*RSX	UN1004	UM1004 V2.0 SPD 10.79.06	2.0	AE-3454G-TC-001	1	FEB 84
RSX	VSV11-H DRIVER	VSV11-M SOFTWARE DRIVER GUIDE	2.0	AA-J287B-TK-001	1	SEP 82
*RSX	VSV11-H DRIVER	VSV11-M SOFTWARE DRIVER GUIDE	2.2	AA-J287E-TK-001	1	JUL 84
RSX	VSV11-M DRIVER	VSV11-M V2.0 RELEASE NOTES	2.0	AA-M615A-TC-001	. 1	JAN 84
*RSX	VSV11-M DRIVER	VSV11-H V2.2 SPD 14.53.04	2.2	AE-K851A-TC-001	1	JUL 84
RSX	VSV11-H DRIVER	VSV11-H V2.1 SPD 14.53.03	2.1	AE-K851D-TC-001	. 1	FEB 84
*RSX	VTV31-K RSX11M DRIVE/SUB PKG	VTV31-K/RSX DEVICE DRV AND SUBROUTINE LIBRARY	1.0	AA-M809A-TC-001	. 1	APR 83
*RSX	VTV31-K RSX11% DRIVE/SUB PKG	VTV31-K/RSX V1.0 SFD 14.73.0	1.0	AE-P079A-TC-001	1	FEB 84

Fase 1

TITLE	PART NUMBER				HUMBER	
OF MANUAL	REV LEVEL	VERSION	FRODUCT NAME	OPERATING SYSTEM	OF FICHE	DATE
3270 TERMINAL EMULATOR KEYROARD LAYOUT	AV-P075A-TE-001	3.0	RSX 11M 3271 PROTOCOL EMULATOR	#RSX	1	AFR 83
ADDENDUM TO SFD	AE-BB27A-TK-001	1.0	COMM 100-DOE	#RSX	1	MAY 84
ADDENDUM TO SPD	AE-BB27A-TK-001	1.0	COMM IOP-DZ	#RSX	1	MAY 84
ADDENDUM TO SPD	AE-BB27A-TK-001	3.1	BX/11M	#RSX	1	HAY 84
ADDENDUM TO SPD	AE-BB27A-TK-001	1.2	LABORATORY SUBROUTINE FACAAGE	#RSX	1	HAY 84
ADDENDUM TO SFD	AE-8827A-TK-001	1.1	FROFESSIONAL REAL TIME INTERFACE LI	₹RSX	1	JUI. 84
ADDENDUM TO SPD	AE-BB27A-TK-001	1.3	SSP-11	#RSX	1	MAY 84
BASIC ON RSX-11H/H-FLUS SYSTEMS (UFD#1 1 #2)	A4-L338A-TC-002	2.2	BASIC-PLUS-2 FOR RSX-11H/H-PLUS	#RSX	3	HAY 84
BASIC ON RSX-11M/H-PLUS SYSTEMS (UPD#1 # #2)	AA-L338A-TC-002	2.2	PROFESSIONAL TOOL KIT BASIC-PLUS-2	#RSX		MAY 84
BASIC ON RSX-11H/H-PLUS SYSTEMS (UFD#1)	AA-L338A-TC-001	2.1	BASIC-FLUS-2 FOR RSX-11H/N-PLUS	RSX	ż	JAN 84
BASIC ON RSX-11H/H-FLUS SYSTEMS (UPD#1)	AA-L338A-TC-001	2.1	PROFESSIONAL TOOL KIT BASIC-PLUS-2	RSX	1	JAN 84
BASIC FOCKET REFERENCE GUIDE	AV-L341A-TK-001	2.0-2.2	BASIC-PLUS-2 FOR RSX-11M/M-PLUS	#RSX	2	APR 83
BASIC POCKET REFERENCE GUIDE	AV-L341A-TK-001	2.0-2.2	PROFESSIONAL TOOL KIT BASIC-PLUS-2	#RSX	2	APR 83
BASIC REFERENCE MANUAL	AA-L334A-TK-001	2.0-2.1	BASIC-FLUS-2 FOR RSX-11M/M-FLUS	RSX	6	APR 83
BASIC REFERENCE MANUAL	AA-L334A-TK-001	2.0-2.1	PROFESSIONAL TOOL KIT BASIC-PLUS-2	RSX	ò	APR 83
BASIC REFERENCE MANUAL (UFD \$1)	AA-L334A-TK-002	2.2	FROFESSIONAL TOOL KIT BASIC-PLUS-2	*RSX	6	MAY 84
BASIC REFERENCE MANUAL (UFD#1)	AA-L334A-TK-002	2.2	BASIC-PLUS-2 FOR RSX-11H/H-PLUS	#RSX	6	nay 84
BASIC USER'S GUIDE	AA-L335A-TK-001	2.0-2.1	BASIC-FLUS-2 FOR RSX-11h/M-FLUS	RSX	3	AFR 83
BASIC USER'S GUIDE	4A-L335A-TK-001	2.0-2.1	FROFESSIONAL TOOL NIT BASIC-FLUS-2	RSX	3	APR 83
RASIC USER'S GUIDE (UFD\$1)	AA-L335A-TK-002	2.2	BASIC-PLUS-2 FOR RSX-11H/H-FLUS	*RSX	3	M4Y 84
BASIC USER'S GUIDE (UPD#1)	AA-L335A-TK-002	2.2	PROFESSIONAL TOOL KIT BASIC-PLUS-2	#RSX	3	MAY 84
BASIC+2 RSX-11H/H-FLUS INSTL GDE/REL MOTES	AA-0158E-TC-001	2.1	BASIC-PLUS-2 FOR RSX-11M/M-PLUS	RSX	1	JAN 84
BASIC+2 RSX-11M/M-FLUS INSTL GDE/REL NOTES	AA-0158F-TC-001	2.2	BASIC-PLUS-2 FOR RSX-11N/M-PLUS	*RSX	1	HAY 84
BASIC-PLUS-2 DOCUMENTATION SUPPLEMENT	AA-P1028-TK-001	2.1	FROFESSIONAL TOOL NIT BASIC-FLUS-2	RSX	t	JAN 84
BASIC-PLUS-2 DOCUMENTATION SUPFLEHENT	AA-P102C-TK-001	2.2	PROFESSIONAL TOOL KIT BASIC-PLUS-2	KRSX	1	hay 34

BASIC-PLUS-2 V2.1 SFD 14.11.8 AE-J1971-TC-001 2.1 BASIC-PLUS-2 FOR RSX-11M/H-PLUS RSX 1 FEB 84 RASIC-PLUS-2 V2.2 SPD 14.11.10 AE-J197K-TC-001 2.2 BASIC-PLUS-2 FOR RSX-11M/H-PLUS RSX 1 MAY 84 BASIC-PLUS-2 V2.2 SPD 14.11.11 AE-J197L-TC-001 2.2 BASIC-PLUS-2 FOR RSX-11M/H-PLUS RSX 1 JMAY 84 BCP USER'S GUIDE AA-N269B-TK-001 1.0 BCP 18SX 2 FEB 84 RCP V1.0 RELEASE NOTES AV-N270B-TC-001 1.0 BCP 18SX 1 APR 83 BCP V1.0 SPD 14.72.0 AE-N202A-TC-001 1.0 BCP 18SX 1 APR 83 BEFORE YOU INSTALL DBMS-11 V2.1 AV-P666A-TC-001 2.1 DBMS-11 4RSX 1 APR 83 CHR11/CHV11 SOFTWARE DRIVER REFERENCE HANUAL AA-N061B-TC-001 1.0 CMR11/CHV11 SOFTWARE DRIVER REFERENCE HANUAL AA-N061B-TC-001 3.0 CMR11/CHV11 SOFTWARE DRIVER RESERVE GUIDE AA-N060B-TC-001 3.0 CMR11/CHV11 SOFTWARE DRIVER RESERVE HANUAL AA-N060B-TC-001 3.0
BASIC-PLUS-2 V2.2 SPD 14.11.11 AE-J197L-TC-001 2.2 BASIC-PLUS-2 FOR MSX-11H/H-PLUS #RSX 1 JUL 84 BCP USER'S GUINE AA-N269B-TK-001 1.0 BCP #RSX 2 FEB 84 BCP V1.0 RELEASE NOTES AV-N270B-TC-001 1.0 BCP #RSX 1 APR 83 BCP V1.0 SPD 14.72.0 AE-N202A-TC-001 1.0 BCP #RSX 1 APR 83 BEFORE YOU INSTALL DBMS-11 V2.1 AV-P666A-TC-001 2.1 DBMS-11 #RSX 1 APR 83 CHR11/CHV11 SOFTWARE DRIVER REFERENCE HANUAL AA-N061B-TC-001 1.0 CHR11/CHV11 SOFTWARE DRIVER RELEASE NOTES AV-N058A-TC-001 1.0 CHR11/CHV11 SOFTWARE DRIVER #RSX 1 APR 83 CHR11/CHV11 SOFTWARE DRIVER USER'S GUIDE AA-N060A-TC-001 1.0 CHR11/CHV11 SOFTWARE DRIVER #RSX 1 APR 83 CHR11/CHV11 SOFTWARE DRIVER USER'S GUIDE AA-N060A-TC-001 1.0 CHR11/CHV11 SOFTWARE DRIVER #RSX 1 APR 83 CHR11/CHV11 SOFTWARE DRIVER USER'S GUIDE AA-N060A-TC-001 1.0 CHR11/CHV11 SOFTWARE DRIVER #RSX 1 APR 83 CHR11/CHV11 SOFTWARE DRIVER USER'S GUIDE AA-N060A-TC-001 1.0 <t< td=""></t<>
BCP USER'S GUIDE AA-N269B-TK-001 1.0 BCP \$RSX 2 FEB 84 BCP V1.0 RELEASE NOTES AV-N270B-TC-001 1.0 BCP \$RSX 1 APR 83 BCP V1.0 SPD 14.72.0 AE-N202A-TC-001 1.0 BCP \$RSX 1 FEB 84 BEFORE YOU INSTALL DBHS-11 V2.1 AV-P666A-TC-001 2.1 DBHS-11 \$RSX 1 APR 83 CMR11/CHV11 SOFTWARE DRIVER REFERENCE HANUAL AA-N061B-TC-001 1.0 CMR11/CHV11 SOFTWARE DRIVER RSX 1 APR 83 CMR11/CHV11 SOFTWARE DRIVER RELEASE NOTES AV-N058A-TC-001 1.0 CMR11/CHV11 SOFTWARE DRIVER RSX 1 APR 83 CMR11/CHV11 SOFTWARE DRIVER USER'S GUIDE AA-N060B-TC-001 3.0 CMR11/CHV11 SOFTWARE DRIVER RSX 1 APR 83 CMR11/CHV11 SOFTWARE DRIVER USER'S GUIDE AA-N060B-TC-001 3.0 CMR11/CHV11 SOFTWARE DRIVER RSX 1 APR 83 CMR11/CHV11 V3.0 SPD 14.76.01 AE-N059B-TC-001 3.0 CMR11/CHV11 SOFTWARE DRIVER RSX 1 APR 83 COBOL-81 LANGUAGE REFERENCE HANUAL AA-J434B-TC-001 2.0 COROL-81/RSX \$RSX 4 JAN 84
BCP V1.0 RELEASE NOTES AV-N270B-TC-001 1.0 BCP \$R\$X 1 APR 83 BCP V1.0 SPD 14.72.0 AE-N202A-TC-001 1.0 BCP \$R\$X 1 FEB 84 BEFORE YOU INSTALL DBMS-11 V2.1 AV-P666A-TC-001 2.1 DBMS-11 \$R\$X 1 APR 83 CMR11/CHV11 SOFTWARE DRIVER REFERENCE HANUAL AA-N061A-TC-001 1.0 CMR11/CHV11 SOFTWARE DRIVER REFERENCE HANUAL AA-N061B-TC-001 3.0 CMR11/CHV11 SOFTWARE DRIVER RELEASE NOTES AV-N058A-TC-001 1.0 CMR11/CHV11 SOFTWARE DRIVER ASX 1 APR 83 CMR11/CHV11 SOFTWARE DRIVER USER'S GUIDE AA-N060B-TC-001 3.0 CMR11/CHV11 SOFTWARE DRIVER ARX 1 APR 83 CMR11/CHV11 SOFTWARE DRIVER USER'S GUIDE AA-N060B-TC-001 3.0 CMR11/CHV11 SOFTWARE DRIVER ARX 1 APR 83 CMR11/CHV11 SOFTWARE DRIVER USER'S GUIDE AA-N060B-TC-001 3.0 CMR11/CHV11 SOFTWARE DRIVER ARX 1 APR 83 CMR11/CHV11 V3.0 SPD 14.76.01 AE-N059B-TC-001 3.0 CMR11/CHV11 SOFTWARE DRIVER ARX 1 APR 83 CWBOL-81 LANGUAGE REFERENCE HANUAL AA-J434B-TC-001 2.0 CGROL-81/RSX 4 JAN 84
BEFORE YOU INSTALL DBMS-11 V2.1 AV-F666A-TC-001 2.1 DBMS-11 \$RSX 1 APR 83 CMR11/CMV11 SOFTWARE DRIVER REFERENCE MANUAL AA-N061A-TC-001 3.0 CMR11/CMV11 SOFTWARE DRIVER REFERENCE MANUAL AA-N061B-TC-001 3.0 CMR11/CMV11 SOFTWARE DRIVER RESX 1 APR 83 CMR11/CMV11 SOFTWARE DRIVER RELEASE NOTES AV-N058A-TC-001 1.0 CMR11/CMV11 SOFTWARE DRIVER RESX 1 APR 83 CMR11/CMV11 SOFTWARE DRIVER CMRSX 1 APR 83 CMR11/CMV11 SOFTWARE DRIVER CMRSX 1 APR 83 CMR11/CMV11 SOFTWARE DRIVER RESX 1 APR 83 CMR11/CMV11 SOFTWARE DRIVER CMRSX 1 APR 83 CMR11/CMV11 V3.0 SPD 14.76.01 AE-N059B-TC-001 3.0 CMR11/CMV11 SOFTWARE DRIVER CMRSX 1 APR 83 CMR11/CMV11 V3.0 SPD 14.76.01 AE-N059B-TC-001 3.0 CMR11/CMV11 SOFTWARE DRIVER CMRSX 1 APR 83 CMR11/CMV11 V3.0 SPD 14.76.01 AE-N059B-TC-001 3.0 CMR11/CMV11 SOFTWARE DRIVER CMRSX 1 APR 83 CMR11/CMV11 V3.0 SPD 14.76.01 AE-N059B-TC-001 3.0 CMR11/CMV11 SOFTWARE DRIVER CMRSX 1 APR 84 CMR11/CMV11 V3.0 SPD 14.76.01 AE-N059B-TC-001 3.0 CMR11/CMV11 SOFTWARE DRIVER CMRSX 1 APR 84 CMR11/CMV11 V3.0 SPD 14.76.01 AE-N059B-TC-001 3.0 CMR11/CMV11 SOFTWARE DRIVER CMRSX 1 APR 84 CMR11/CMV11 V3.0 SPD 14.76.01 AE-N059B-TC-001 3.0 CMR11/CMV11 SOFTWARE DRIVER CMRSX 1 APR 85 CMR11/CMV11 V3.0 SPD 14.76.01 AE-N059B-TC-001 3.0 CMR11/CMV11 SOFTWARE DRIVER CMRSX 1 APR 85 CMR11/CMV11 V3.0 SPD 14.76.01 AE-N059B-TC-001 3.0 CMR11/CMV11 SOFTWARE DRIVER CMRSX 1 APR 85 CMR11/CMV11 V3.0 SPD 14.76.01 AE-N059B-TC-001 3.0 CMR11/CMV11 SOFTWARE DRIVER CMRSX 1 APR 85 CMR11/CMV11 V3.0 SPD 14.76.01 AE-N059B-TC-001 3.0 CMR11/CMV11 SOFTWARE DRIVER CMRSX 1 APR 85 CM
BEFORE YOU INSTALL DBMS-11 V2.1 AV-P666A-TC-001 2.1 DBMS-11 \$RSX 1 APR 83 CMR11/CMV11 SOFTWARE DRIVER REFERENCE MANUAL AA-N061A-TC-001 1.0 CMR11/CMV11 SOFTWARE DRIVER RESX 1 APR 83 CMR11/CMV11 SOFTWARE DRIVER REFERENCE MANUAL AA-N061B-TC-001 3.0 CMR11/CMV11 SOFTWARE DRIVER RESX 1 FEB 84 CMR11/CMV11 SOFTWARE DRIVER RELEASE NOTES AV-N058A-TC-001 1.0 CMR11/CMV11 SOFTWARE DRIVER RSX 1 APR 83 CMR11/CMV11 SOFTWARE DRIVER USER'S GUIDE AA-N060B-TC-001 3.0 CMR11/CMV11 SOFTWARE DRIVER RSX 1 FEB 84 CMR11/CMV11 SOFTWARE DRIVER USER'S GUIDE AA-N060A-TC-001 1.0 CMR11/CMV11 SOFTWARE DRIVER RSX 1 APR 83 CMR11/CMV11 SOFTWARE DRIVER RSX 1 APR 83 CMR11/CMV11 SOFTWARE DRIVER RSX 1 APR 83 CMR11/CMV11 V3.0 SPD 14.76.01 AE-N059B-TC-001 3.0 CMR11/CMV11 SOFTWARE DRIVER RSX 1 MAY 84 CMB0L-81 LANGUAGE REFERENCE MANUAL AA-J434B-TC-001 2.0 COROL-81/RSX \$RSX 4 JAN 84 CMB0L-81 LANGUAGE REFERENCE MANUAL AA-J434B-TC-001 2.0 COROL-81/RSX \$RSX 4 JAN 84 CMB0L-81 LANGUAGE REFERENCE MANUAL AA-J434B-TC-001 2.0 COROL-81/RSX \$RSX 4 JAN 84 CMB0L-81 LANGUAGE REFERENCE MANUAL AA-J434B-TC-001 2.0 COROL-81/RSX \$RSX 4 JAN 84 CMB0L-81 LANGUAGE REFERENCE MANUAL AA-J434B-TC-001 2.0 COROL-81/RSX \$RSX 4 JAN 84 CMB0L-81 LANGUAGE REFERENCE MANUAL AA-J434B-TC-001 2.0 COROL-81/RSX
CHR11/CHV11 SOFTWARE DRIVER REFERENCE MANUAL AA-NO61A-TC-001 1.0 CHR11/CHV11 SOFTWARE DRIVER RSX 1 AFR 83 CHR11/CHV11 SOFTWARE DRIVER REFERENCE MANUAL AA-NO61B-TC-001 3.0 CHR11/CHV11 SOFTWARE DRIVER RELEASE NOTES AV-NO58A-TC-001 1.0 CHR11/CHV11 SOFTWARE DRIVER RSX 1 APR 83 CHR11/CHV11 SOFTWARE DRIVER L'SER'S GUIDE AA-NO60B-TC-001 3.0 CHR11/CHV11 SOFTWARE DRIVER L'SER'S GUIDE AA-NO60B-TC-001 1.0 CHR11/CHV11 SOFTWARE DRIVER RSX 1 AFR 83 CHR11/CHV11 SOFTWARE DRIVER WSX 1 APR 83 CHR11/CHV11 SOFTWARE DRIVER WSX 1 APR 83 CHR11/CHV11 SOFTWARE DRIVER RSX 1 APR 83 CHR11/CHV11 V3.0 SPD 14.76.01 AE-NO59B-TC-001 3.0 CHR11/CHV11 SOFTWARE DRIVER RSX 1 MAY 84 CUBOL-81 LANGUAGE REFERENCE MANUAL AA-J434B-TC-001 2.0 CGR0L-81/RSX \$\$ \$\$ \$\$ \$\$ \$\$ \$\$ \$\$ \$\$ \$\$ \$\$ \$\$ \$\$ \$\$
CHR11/CHV11 SOFTWARE DRIVER REFERENCE MANUAL AA-NO61B-TC-001 3.0 CHR11/CHV11 SOFTWARE DRIVER RSX 1 FEB 84 CHR11/CHV11 SOFTWARE DRIVER RELEASE NOTES AV-NO58A-TC-001 1.0 CHR11/CHV11 SOFTWARE DRIVER RSX 1 APR 83 CHR11/CHV11 SOFTWARE DRIVER USER'S GUIDE AA-NO60B-TC-001 3.0 CHR11/CHV11 SOFTWARE DRIVER RSX 1 FEB 84 CHR11/CHV11 SOFTWARE DRIVER USERS GUIDE AA-NO60A-TC-001 1.0 CHR11/CHV11 SOFTWARE DRIVER RSX 1 APR 83 CHR11/CHV11 V3.0 SPD 14.76.01 AE-NO59B-TC-001 3.0 CHR11/CHV11 SOFTWARE DRIVER RSX 1 HAY 84 CUBOL-81 LANGUAGE REFERENCE MANUAL AA-J434B-TC-001 2.0 CGBOL-81/RSX #RSX 4 JAN 84
CHR11/CHV11 SOFTWARE DRIVER RELEASE NOTES AV-NOS8A-TC-001 1.0 CHR11/CHV11 SOFTWARE DRIVER RSX 1 APR 83 CHR11/CHV11 SOFTWARE DRIVER USER'S GUIDE AA-NO60A-TC-001 1.0 CHR11/CHV11 SOFTWARE DRIVER RSX 1 APR 83 CHR11/CHV11 SOFTWARE DRIVER USERS GUIDE AA-NO60A-TC-001 1.0 CHR11/CHV11 SOFTWARE DRIVER RSX 1 APR 83 CHR11/CHV11 V3.0 SPD 14.76.01 AE-NO59R-TC-001 3.0 CHR11/CHV11 SOFTWARE DRIVER RSX 1 MAY 84 CUBOL-81 LANGUAGE REFERENCE MANUAL AA-J434R-TC-001 2.0 CGROL-81/RSX #RSX 4 JAN 84
CHR11/CHV11 SOFTWARE DRIVER USER'S GUIDE AA-NO60B-TC-001 3.0 CHR11/CHV11 SOFTWARE DRIVER USERS GUIDE AA-NO60A-TC-001 1.0 CHR11/CHV11 SOFTWARE DRIVER RSX 1 FEB 84 CHR11/CHV11 SOFTWARE DRIVER RSX 1 AFR 83 CHR11/CHV11 V3.0 SPD 14.76.01 AE-NO59B-TC-001 3.0 CHR11/CHV11 SOFTWARE DRIVER RSX 1 HAY 84 CUBOL-81 LANGUAGE REFERENCE MANUAL AA-J434B-TC-001 2.0 CGR0L-81/RSX 4RSX 4 JAN 84
CHR11/CHV11 SOFTWARE DRIVER USERS GUIDE AA-N060A-TC-001 1.0 CHR11/CHV11 SOFTWARE DRIVER RSX 1 AFR 83 CHR11/CHV11 V3.0 SPD 14.76.01 AE-N059B-TC-001 3.0 CHR11/CHV11 SOFTWARE DRIVER *RSX 1 HAY 84 CUBOL-81 LANGUAGE REFERENCE MANUAL AA-J434B-TC-001 2.0 COROL-81/RSX *RSX 4 JAN 84
CHR11/CMV11 V3.0 SPD 14.76.01 AE-N059R-TC-001 3.0 CHR11/CMV11 SOFTWARE DRIVER *RSX 1 HAY 84 CUBOL-81 LANGUAGE REFERENCE MANUAL AA-J434R-TC-001 2.0 CGROL-81/RSX #RSX 4 JAN 84
CUBOL-81 LANGUAGE REFERENCE MANUAL AA-J4349-TC-001 2.0 CGROL-81/RSX #RSX 4 JAN 84
CORDI -91 LANGUAGE REFERENCE MANUAL AA-1474R-TC-001 2.1 PROFESSIONAL TOOL VIT CORDI -91 #RSY 4 HAY 94
COUNT OF EMILION INTOINE THE COUNTY TO THE COUNTY THE C
COBOL-81 POCKET GUIDE AV-H630C-TC-001 2.0 COBOL-81/RSX #RSX 2 JAN 84
CL30L-81 POCKET GUIDE AV-H630C-TC-001 2.1 PROFESSIONAL TOOL KIT COBOL-81 #RSX 2 hay 84
COBOL-81 RSX V2.0 SPD 14.26.03 AE-P077E-TC-001 2.0 COBOL-81/RSX #RSX 1 FER 84
CONN TOP-DUP FROGRAMMER'S MANUAL AA-5670A-TC-001 1.0 COMM TOP-DUP #RSX 1 SEP 82
CONH IOP-DUP RELEASE NOTES (INCLUDES UPD#1) AA-D367A-TC-001 1.0 CONH IOP-DUF #RSX 1 SEP 82
COMM TOP-DUP V1.0 SPD 10.12.04 AE-D121E-TC-001 1.0 COMM TOP-DUP \$RSX 1 JUL 84
CONH IOP-DZ PROGRAMMER'S MANUAL AA-5127A-TC-001 1.0 CONH IOP-DZ #RSX 1 SEP 82
COMM IOF-DZ RELEASE NOTES (INCLUDES UPD#1) AA-D368A-TC-001 1.0 COMM IOF-DZ #RSX 1 SEP 32
COMM IOP-DZ V1.0 SFD i0.11.04 AE-D122E-TC-001 1.0 COMM IOP-DZ #RSX 1 JUL 84
CORAL-66 LANGUAGE REFERENCE MANUAL AA-D111C-TK-001 4.0 CORAL-66 **RSX 2 APR 83
CDRAL-66 V4.0 SPD 14.56.10 AE-3450I-TC-001 4.0 CORAL-66 #RSX 1 MAY 84

TITLE OF	PART NUMBER REV			PRODUCT	OFERATING		t
MANUAL	LEVEL	VERSION		NAME	SYSTEM	FICHE	DATE
CORE GRAPHICS LIBRAN! MANUAL	AA-N619A-TK-001	1.0	PROFESSIONAL	HOST TOOL KIT	RSX	2	APR 83
CORE GRAPHICS LIBRARY MANUAL	AA-N619B-TK-001	1.0	PROFESSIONAL	HOST TOOL KIT	RSX	2	MAY 84
CRM11/CHV11 SOFTWARE DRIVER RELEASE NOTES	AV-N0581-TC-001	3.0	CMR11/CHV11	SOFTWARE DRIVER	*RSX	1	FEB 84
DATATRIEVE-11 CALL INTERFACE MANUAL	AA-U050A-TC-001	3.0	DATATRIEVE-1	1	#RSX	2	JAN 84
DATATRIEVE-11 GUIDE TO WRITING REPORTS	AA-U051A-TK-001	3.0	DATATRIEVE-1	1	*RSX	1	FER 84
DATATRIEVE-11 INSTALLATION GDE/REL NOTES	AA-X022A-TC-001	3.0	DATATRIEVE-1	i	*RSX	1	JAN 84
DATATRIEVE-11 POCKET GUIDE	AA-X103A-TK-001	3.0	DATATRIEVE-1	1	*RSX	1	FEB F.
DATATRIEVE-11 REFERENCE MANUAL	AA-U049A-TK-001	3.0	DATATRIEVE-1	i	*RSX	4	FE2 84
DATATRIEVE-11 SUMMARY DESCRIPTION	AA-U052A-TC-001	3.0	DATATRIEVE-1	1	#RSX	i	JAN 84
DATATRIEVE-11 L3ER'S GUIDE	AA-X023A-TK-001	3.0	DATATRIEVE-1	i	¥RSX	3	FEB 84
DATATRIEVE-11 V3.G SPD 12.48.11	AE-C777L-TC-001	3.0	DATATRIEVE-1	1	RSX	1	MAY 84
DATATRIEVE-11 V3.0 SFD 12.48.12	AE-C777N-10-001	3.0	DATATRIEVE-1	1	*RSX	1	JUL 84
DBMS-11 DATA BASE ADMINISTRATOR'S (DBA) GUIDE	AA-H805B-TC-001	2.0-2.1	DBMS-11		*RSX	4	SEF 82
DBMS-11 INSTALLATION GUIDE	AA-K885B-TE-001	2.0-2.1	DBMS-11		*RSX	2	SEF 82
DBMS-11 V2.0 RELEASE NOTES	AA-K886B-TC-001	2.0-2.1	DBMS-11		*RSX	1	SEP 82
IJBMS-11 V2.1 SPIJ 12.66,2	AE-M130D-TC-001	2.1	DRMS-11		*RSX	1	FEB 84
DBMS-11/H+ DDL/DEVICE MEDIA CON LANG REF MAN	AA-H804B-TC-001	2.0-2.1	DBMS-11		*RSX	3	SEP 82
DBHS11 COBOL DATA MANIPULATION LANG REF HAN	AA-KB84B-TC-001	2.0-2.1	DBMS-11		*RSX	2	SEP 82
DBMS11 FORTRAN DATA MANIPULATION LANG REF MAN	AA-K883B-TC-001	2.0-2.1	DBMS-11		*RSX	2	SEP 82
DECLAB-11/MINC USER'S GUIDE	EK-MNC11-UG-001	1.1-1.2	RSX 11H F EN	HANC PKG FOR HIN	C #RSX	2	APR 83
DECNET RSX SYSTEM MANGER'S HINI REF GUIDE	AA-X924A-TC-001	4.0	DECNET-11H		*RSX	1	MAY 84
DECNET-11M V4.0 SPD 10.75.10	AE-3431K-TC-001	4.0	DECNET-11H		RSX	1	HAY 84
DECNET-11M V4.0 SPD 10.75.11	AE-3431L-TC-001	4.0	DECNET-11H		#R5X	1	JUL 84
DECNET-11H+ V2.0 SPD 10.66.05	AE-J513F-TC-001	4.0	DECNET-11N		*RSX		OCT 84
DECNET-115 V4.0 SPD 10.74.12	AE-3432M-TC-001	4.0	DECNET-11H		*RSX		OCT 84
DECNET-RSX VOL I SPNST GENERAL INFORMATION	AV-Y552A-TC-001	4.0	DECNET-11H		*RSX		DCT 84

TITLE OF HANUAL	PART NUMBER REV LEVEL	VERSION		PRODUCT NAME	OPERATING SYSTEM	NUMBER OF FICHE	DATE
DECNET-RSX VOL II SPNST GENERAL INFORMATION	AV-Y554A-TC-001	4.0	DECNET-11H		#RSX		OCT 84
DECNET-RSX VOL IV SPNST GENERAL INFORMATION	AV-Y555A-TC-001	4.0	DECNET-11H		≭RSX		DCT 84
DECNET-RSX VOLUME II USER'S INFORMATION	AV-Y553A-TC-001	4.0	DECNET-11H		*RSX		OCT 84
DECTYPE KEYBOARD LAYOUT	AV-R127A-TK-001	3.0	RSX 11M PLUS	DECTYPE	RSX 11 PLU	1	JUL 84
DECTYPE REFERENCE MANUAL	AA-R124B-TK-001	3.0	RSX 11M PLUS	DECTYPE	#RSX	2	JUL 84
DECTYPE V3.0 SPD 14.82.00	AE-BG31A-TC-001	3.0	RSX 11M PLUS	DECTYPE	RSX 11 FLU	1	JUL 84
DETYPE QUICK REFERENCE GUIDE	AV-R128B-TK-001	3.0	RSX 11H PLUS	DECTYPE	RSX 11 PLU	1	JUL 84
DIBOL FOR BEGINNERS	AA-BI77A-TK-001	1.6	PROFESSIONAL	TOOL KIT DIBOL	KRSX	1	JUL 84
DIBOL FOR BEGINNERS	AA-BI77A-TK-001	1.0	RSX 11M PLUS	DIPOL	RSX 11 PLU	1	JUL 84
DIBOL LANGUAGE REFERENCE CARD	AA-9067A-TK-001	1.6	PROFESSIONAL	TOOL KIT DIROL	RSX	1	MAY 84
DIBOL-83 COMPATIBILITY GUIDE	AA-V810B-TK-001	1.0	RSX 11H FLUS	DIBOL	RSX 11 PLU	1	JUL 84
DIBOL-83 COMPATIBILITY MANUAL	AA-V8108-TK-001	1.6	PROFESSIONAL	TOOL KIT DIBOL	*RSX	1	MAY 84
DIBOL-83 LANGUAGE REFERENCE CARD	AV-U067A-TK-001	1.6	PROFESSIONAL	TOOL KIT DIBOL	*RSX	1	JUL 84
DIBOL-83 LANGUAGE REFERENCE CARD	AV-U067A-TK-001	1.0	RSX 11H PLUS	DIROL	RSX 11 FLU	1	JUL 84
DIBOL-83 LANGUAGE REFERENCE MANUAL (UPD#1)	AA-U066A-TK-001	1.6	PROFESSIONAL	TOOL KIT DIBOL	*RSX	2	FEB 84
DIBOL-83 LANGUAGE REFERENCE MANUAL (UFD#1)	AA-U055A-TK-001	1.0	RSX 11H PLUS	DIROL	RSX 11 FLU	2	JUL 84
DOCUMENTATION GUIDE LINES	AA-N621A-TK-001	1.0-2.0	PROFESSIONAL	HOST TOOL KIT	\$RSX	1	APR 83
DPM V4.1 SPD 15.6.6	AE-5730H-TC-001	4.1	DPH		#RSX	1	FEB 84
DPH/DPH PLUS REFERENCE GUIDE	AV-H195A-TC-001	4.1	DPH		*RSX	i	SEP 82
DPH/DPH PLUS RELEASE NOTES	AA-N150A-TC-001	4.1	DEH		*RSX	1	SEF 82
DPH/DPH1 DECDATA INTELL SUBS USRS GDE (UPD#1)	AA-J529B-TC-001	4.1	DPM		*RSX	3	SEP 82
DPH/DPH+ SYSTEM GENERATION/MANAGEMENT GDE	AA-J531C-TC-001	4.1	DPH		#RSX	2	SEF 82
DPN/DFN+ TERHIANL USER'S GUIDE (UPD#1)	AA-J530B-TC-001	4.1	DPH		*RSX	2	SEP 82
DRU11-C RSX SPD 13.35.00	AE-8F37A-TC-001	4.2	DRU11-C RSX-1	1 DRIVER	#RSX	1	JUL 84
DRU11-C RSX11M/M+ SOFTWARE MANUAL	AA-W152A-TC-001	4.2	DRU11-C RSX-1	11 DRIVER	#RSX	i	JUL 84
DT07-11H V1.1 SFD 14.36.1	AE-K534B-TC-001	1.1	DT07-11H		#RSX	1	FEB 84

TITLE OF Manual	PART NUMBER REV LEVEL	VERSION		PRODUCT NAME	OPERATING SYSTEM	NUMBER OF FICHE	DATE
DT07-11H V1.1 USER'S GUIDE	AA-K568A-TC-001	1.1	DT07-11H		*RSX	1	SEP 82
DTR-11 COVER LETTER/BEFORE YOU INSTALL	AV-X024A-TC-001	3.0	DATATRIEVE-11		*RSX	1	JUL 84
DX PRODUCTS PROGRAMMER'S REFERENCE MANUAL	AA-5469C-TC-001	3.1	DX/11H		*RSX	1	APR 83
DX PRODUCTS USER'S GUIDE	AA-5476D-TC-001	3.1	DX/11H		#RSX	1	APR 83
DX/11M INSTALLATION GUIDE	AA-D997A-TC-001	3.1	DX/11H		*RSX	1	APR 83
DX/11M V3.1 SPD 10.96.4	AE-5274F-TC-001	3.1	DX/11H		#RSX	1	FEB 84
DX/11M VERSION 3.1 RELEASE NOTES	AA-H288B-TC-001	3.1	DX/11H		#RSX	1	APR 83
EDT EDITOR MANUAL	AA-J726A-TC-001	4.1	RSX-11M		RSX	3	NOV 83
EDT EDITOR MANUAL	AA-M476A-TK-001	4.1	RSX-11M		#RSX	8	FEB 84
EDT EDITOR MANUAL	AA-J726A-TC-001	2.1	RSX-11M-FLUS		RSX	3	NOV 83
EDT EDITOR MANUAL	AA-N476A-TK-001	2.1	RSX-11M-PLUS		*RSX	8	FEB 84
EDT EDITOR REFERENCE CARD	AV-J756A-TC-001	4.1	RSX-11M		RSX	1	NDV 83
EDT EDITOR REFERENCE CARD	AV-J756A-TC-001	2.1	RSX-11M-PLUS		RSX	1	NOV 83
EIT QUICK REFERENCE MANUAL	AA-M477A-TK-001	4.1	RSX-11M		*RSX	1	FEB 84
EDT QUICK REFERENCE MANUAL	AA-M477A-TK-001	2.1	RSX-11M-PLUS		‡ RSX	1	FEB 84
FMS-11/RSX RELEASE NOTES	AA-H857A-TC-001	1.0-2.0	PROFESSIONAL H	HOST TOOL KIT	*RSX	1	APR 83
FMS-11/RSX SOFTWARE REFERENCE MANUAL	AA-H855A-TC-001	1.0-2.0	FROFESSIONAL I	HOST TOOL KIT	*RSX	3	APR 83
FMS-11/RSX V1.0 SPD 12.27.07	AE-J405H-TC-001	1.0	FMS-11/RSX		RSX	1	JUL 84
FMS-11/RSX V1.0 SPD 12.27.5	AE-J405F-TC-001	1.0	FMS-11/RSX		#RSX	1	FE8 84
FMS-11/RSX-11M MINI REFERENCE GUIDE	AV-H856A-TC-001	1.0	FMS-11/RSX		#RSX	1	SEP 82
FMS-11/RSX-11M RELEASE NOTES	AA-H857A-TC-001	1.0	FMS-11/RSX		#RSX	1	SEF 82
FMS-11/RSX11M SOFTWARE REF MANUAL (UFD#1)	AA-H855A-TC-001	1.0	FMS-11/RSX		*RSX	3	SEF 82
FORTRAN IV/RSX V2.6 SPD 14.63.10	AE-3443N-TC-001	2.6	FORTRAN IV/RS)	<	*RSX	1	KAY 84
FORTRAN IV/RSX V2.6 SFD 14.63.9	AE-3443J-TC-001	2.6	FORTRAN IV/RS	(RSX	1	FEB 84
FORTRAN-77/DEBUG INSTAL GUIDE/REL NOTES	AA-X650A-TK-001	1.0	FORTRAN-77 DEI	BUG, FDF-11	#RGX	1	JAN 84
GUIDE TO WRITING F/OS I/O DRIVER	AA-BT73A-TH-001	2.0	PROFESSIONAL H	HOST TOOL KIT	#RSX		OCT 84

FART TITLE NUMBER NUMBER OPERATING OF REV PRODUCT OF FICHE HANUAL VERSION NAME SYSTEM DATE LEVEL **JAN 84** IAS/RSX ODT REFERENCE MANUAL SUPPLEMENT AA-P193B-TK-001 1.0-2.0 PROFESSIONAL HOST TOOL KIT #RSX 1 3 **NOV 83** IAS/RSX-11 I/O OPERATIONS REFERENCE MANUAL AA-H176A-TC-001 4.1 RSX-11H **#RSX** #RSX 3 **NOV 83** IAS/RSX-11 I/O OPERATIONS REFERENCE MANUAL AA-M176A-TC-001 2.1 RSX-11H-PLUS IAS/RSX-11 I/O OPERATIONS REFERENCE MANUAL AA-H176A-TC-001 4.1 RSX-11S *RSX 3 **NOV 83** AA-N507A-TC-001 4.1 **NOV 83** IAS/RSX-11 ODT REFERENCE MANUAL RSX-11h #RSX 1 IAS/RSX-11 ODT REFERENCE HANUAL 44-H507A-TC-001 2.1 RSX-11M-FLUS *RSX NOV 83 IAS/RSX-11 OUT REFERENCE MANUAL #RSX **NOV 83** AA-H507A-TC-001 4.1 RSX-11S IAS/RSX-11 OUT REFERENCE HANUAL AA-M507A-TC-001 1.0-2.0 PROFESSIONAL HOST TOOL NIT #RSX 1 APR 83 IAS/RSX-11 SYS LIB ROUTINE REF HANUAL **#RSX NOV 83** AA-5580B-TC-001 4.1 RSX-11S #RSX 2 NOV 83 IAS/RSX-11 SYSTEM LIB ROUTINE REF HANUAL AA-5580B-TC-001 4.1 RSX-11H AA-5580B-TC-001 2.1 RSX-11H-PLUS #RSX 2 **NOV 83** IAS/RSX-11 SYSTEM LIB ROUTINE REF MANUAL TEC-11H RELEASE NOTES AV-V507A-TC-001 3.0 IEC-11M *R'SX 1 FEB 84 IEC-11H RSX SOFTWARE MANUAL IEC-11h \$RSX SEP 82 AA-H275A-TC-001 3.0 IEC-11M V3.0 SPD 14.64.0 AE-N029A-TC-001 3.0 IEC-11H ***RSX** 1 FER 84 IEX-RSX DRIVER V2.0 SPD 12.68.01 IEX-RSX DRIVER #RSX **JUL 84** AE-X682B-TC-001 2.0 IEX-RSX USERS & INSTALLATION GUIDE **DCT 84** AA-R472A-TC-001 2.0 IEX-RSX DRIVER #RSX INSTALLING AND MANAGING DECTYPE AA-Z960A-TC-001 3.0 RSX 11M PLUS DECTYPE RSX 11 PLU **JUL 84** *RSX **OCT 84** INTRO TO DECNET PHASE IV AA-J055I-TK-001 2.0 PROFESSIONAL HOST TOOL KIT INTRO TO FEP & FRF ERRATA SHEET AV-V191A-TC-001 1.2 RSX 11M F ENHANC FKG FOR MINC **#RSX** JAN 84 **FEB 84** INTRODUCTION TO DATATRIEVE-11 AA-X025A-TK-001 3.0 DATATRIEVE-11 #R'SX 1 INTRODUCTION TO DECNET AA-J055C-TK-001 3.1 DECNET-11M RSX FEB 84 INTRODUCTION TO DECNET AA-J055B-TK-001 4.0 DECNET-11H #RSX MAY S4 INTRODUCTION TO DIBOL PROFESSIONAL TOOL KIT DIPOL APR 83 AA-F042A-TK-001 1.0-1.6 RSX INTRODUCTION TO DIBOL AA-F042R-TK-001 1.6 PROFESSIONAL TOOL KIT DIBOL *RSX 1 JUL 84 INTRODUCTION TO FEP AND FRP RSX 11M F ENHANC PKG FOR MINC #RSX AFR 83 AA-J302B-TC-001 1.1-1.2 JUL 84 INTRODUCTION TO HICROPOWER/PASCAL AA-M388A-TC-001 1.5 MICROPOWER/PASCAL-RSX #R'SX

TIT!.E OF HANUAL	PART NUMBER REV LEVEL	VERSION	FRODUCT NAME	OPERATING SYSTEM	NUMBER OF FICHE	DATE
INTRODUCTION TO RSX-11 PSI	AA-M369A-TC-001	2.0	RSX 11 PSI/M	*RSX	1	SEP 82
INTRODUCTION TO RSX-11H AND RSX-11H+	AA-L763A-TC-001	2.1	RSX-11H-PLUS	#RSX	2	NOV 83
INTRODUCTION TO RSX-11H AND RSX-11H-PLUS	AA-L763A-TC-001	4.1	RSX-11M	*RSX	2	NOV 83
KMC-11 TOOLS V1.0 SFD 12.49.04	AE-C776E-TC-001	1.0	KMC-11 TOOLS	*RSX	1	MAY 84
KMC11 PROGRAMMER'S MANUAL	AA-5244B-TC-001	1.0	KMC-11 TOOLS	*RSX	2	SEP 82
KHV11-A HDLC FRAKING SFTWARE FOR REX REF HAN	AA-N565A-TC-001	1.0	KMV11-A HULC FRAMING SOFTWARE	*RSX	1	APR 83
KHV11A-HDLC FRAMING SOFTWARE V1.0 SPD 14.22.0	AE-R298A-TC-001	1.0	KHV11-A HDLC FRAMING SOFTWARE	1RSX	1	FEB 84
KXT11-C SOFTWARE USER'S GUIDE	AA-Y615A-TK-001	1.5	MICROPOWER/PASCAL-RSX	*RSX	2	JUL 84
LAB SUBROUTINES PROG REF MAN (UPD#1)	AA-C984C-TC-001	1.1-1.2	RSX 11H F ENHANC FAG FOR MINC	*RSX	3	AFR 83
LABORATORY SUB PROGRAMMER'S REF HAN (UFD#1)	AA-C984C-TC-001	1.2	LABORATORY SUBROUTINE PACKAGE	#RSX	1	SEP 82
LSP REFERENCE MANUAL ERRATA SHEET	AV-V190A-TC-001	1.2	RSX 11M F ENHANC PKG FOR HINC	\$RSX	1	JAN 84
LSP V1.2 SPD 15.44.06	AE-1607G-TC-001	1.2	LAPORATORY SUBROUTINE PACKAGE	*RSX	1	MAY 84
LSP V1.2 SPD 15.44.5	AE-D607F-TC-001	1.2	LABORATORY SUBROUTINE FACKAGE	RSX	1	FEB 84
H+/HICRO RSX DB MESSAGE HANUAL	AA-Z887A-TC-001	1.0	RSX 11M PLUS DIBOL	RSX 11 PLU	1	JUL P4
H+/HICRO RSX DIBOL RELEASE NOTES/INSTL GDE	AA-Z886A-TC-001	1.0	RSX 11M FLUS DIFOL	RSX 11 PLU	1	JUL 84
H+/MICRO RSX DIBOL USER'S GUIDE	AA-Z885A-TC-001	1.0	RSX 11M PLUS DIBOL	RSX 11 FLU	2	JUL 84
HDE/T-11 USER'S GDE/REF HANUAL	AA-H845B-TK-001	1.0	RSX MDE/T11	*RSX	3	AFR 83
HDE/T-11 V1.0 INSTL GDE/REL NTS	AV-F511A-TC-001	i.0	RSX MDE/T11	#RSX	1	APR 83
HDE/T11 REFERENCE CARD	AV-H8468-TK-001	1.0	RSX MDE/T11	*RSX	1	FEB 84
MICROCOMPUTERS AND MEMORIES HANDBOOK	EB-20912-20-001	1.1-1.2	RSX 11M F ENHANC PKG FOR HINC	Xe3#	3	AFR 83
MINC THERMOCOUPLE PREAMPLIFIER USER'S GUIDE	EK-HNCTP-UG-001	1.1-1.2	RSX 11H F ENHANC PKG FOR MINC	*RSX	1	APR 83
HP/P DEBUGGER USER'S GUIDE (UPD#1)	AA-H393B-TC-001	1.5	HICROPOWER/PASCAL-RSX	4RSX	2	JUL 84
MF/P LANGUAGE GUIDE (UPD \$1)	AA-H389C-TC-001	1.5	MICROPOWER/PASCAL-RSX	*RSX	5	JUL 84
HP/P REFERENCE CARD	AV-H395A-TC-001	1.5	HICROPOWER/PASCAL-RSX	*RSX	1	JUL 81
MP/P RSX SPD 14.83.00	AE-BK29A-TC-001	1.5	HICROPOWER/FASCAL-RSX	#RSX	1	JUL 84
MP/P RSX-11M/H+ INSTALLATION GUIDE	AA-AK10A-TC-001	1.5	HICROPOWER/PASCAL-RSX	FRSX	1	JUL 84

TITLE OF MANUAL	PART HUMBER REV LEVEL	VERSION	PRODUCT NAME	OPERATING System	NUMBER OF FICHE	PATE
MP/P RSX-11M/M+ RELEASE NOTES	A6-AK11A-TC-601		HICROPOWER/PASCAL-RSX	*RSX	1	JUL 84
MF/F-RSX/VMS MESSACES MANUAL	AA-AK14A-TK-Q01		HICROPOWER/PASCAL-RSX	#RSX	1	JUL 84
MP/P-RSX/VMS SYSTEM USER'S GUIDE	AA-AK13A-TK-001		HICROFOWER/PASCAL-RSX	#RSX	3	JUL 84
MP/P-RT RUNTINE SERVICE MANUAL (UPD \$1)	AA-M391R-TC-001		h1CROPONER/FASCAL-RSX	*RSX	6	JUL 84
MUX200/RSX-IAS SYSTEM MANAGER GUIDE	AA-13446-TC-001		HUX200/FSX-IAS	*RSX	2	JAN 84
MUX200/RSX-IAS USER'S GUIDE						JAN 84
	AA-1346C-TC-001		MUX200/RSX-IAS	≇RSX	1	
HUX200/RSX-IAS V2.1 RELEASE HOTES	AA-1343C-7C-001	2.1	MUX200/RSX-IAS	*RSX	1	JAN 84
HUX200/RSX-IAS V2.1 SPI 10.77.07	AE-3453I-10-001	2.1	HUX200/RSX-IAS	#RSX	1	FER 84
OBSERVER EVENT MESSAGE REFERENCE MANUAL	AA-X074A-TC-001	1.1	OBSERVER	*RSX	2	JUL 84
OBSERVER INSTL GUIDE AND GEN GUIDE	aa-N959a-TC-001	1.0	OBSERVER	RSX	1	AFR 83
OBSERVER INSTL GUIDE AND GEN GUIDE	AA-N959B-TC-001	1.1	OBSERVER	#RSX	1	FEB 84
OBSERVER REFERENCE CARD	AU-X073A-TC-001	1.1	OBSERVER	#RSX	1	FER 84
OBSERVER RELEASE NOTES	AA-N962A-TC-001	1.0	OBSERVER	RSX	1	APR 83
OBSERVER RELEASE NOTES	AA-N962B-TC-001	1.1	OBSERVER	#RSX	1	FEB 84
OBSERVER USER'S GUIDE	AA-N960A-TC-001	1.0	OBSERVER	RSX	3	APR 83
OBSERVER USER'S GUIDE	AA-N960B-TC-001	1.1	OBSERVER	*RSX	3	FEB 84
OBSERVER VI.1 SFD 13.18.02	AE-P3350-TC-001	1.1	OBSERVER	*RSX	1	MAY 84
OVERVIEW OF RSX DECNET	AA-H096A-TC-001	3.1	DECNET-11M	RSX	2	FEB 84
OVERVILW OF RSX DECNET	AA-M0968-TC-001	4.0	DECNET-11H	*RSX	2	MAY 84
OVERVIEW TO DIGITAL NETWORK PROCEDURES	AA-X105A-TK-001	4.0	DECNET-11M	≇R'SX	2	MAY 84
P/OS SYSTEM REFERENCE MANUAL	AA-N620A-TK-001	1.0	PROFESSIONAL HOST TOOL KIT	RSY	4	APR 83
P/OS SYSTEM REFERENCE MANUAL (UPD#2)	AA-N620A-TK-002	1.0-2.0	PROFESSIONAL HOST TOOL KIT	*RSX	4	JUL 84
PDP-11 COBOL INSTALLTION GUIDE	AA-1745F-TC-001	4.4	PDF-11 COBOL	*RSX	i	SEP 82
PDP-11 COBOL USER'S GUIDE (INCLUDES UPI#1)	AA-1757E-TC-001	4.4	PDF-11 COFOL	#RSX	6	SEP 82
PDF-11 COBOL V4.4 SPD 12.40.18	AE-3417S-TC-001	4.4	FDF-11 CGBOL	#RSX	1	FER 84
FDP-11 CORAL-66 V4.0 INSTL GDE/REL NOTES	AA-1744E-TC-001	4.0	CORAL-66	*RSX	1	AFR 83

PART TITLE NUMBER NUMBER 0F REV PRODUCT **OPERATING** OF VERSION SYSTEM FICHE DATE HANUAL LEVEL NAME PBP-11 F-77 LANGUAGE REFERENCE HANUAL PROFESSIONAL TOOL KIT FORTRAN-77 3 FE8 84 AA-V193A-TK-001 5.0 *RSX *RSX 2 JAN 84 PDP-11 FORTRAN LANGUAGE REFERENCE NANUAL AA-R953A-TK-001 2.6 FORTRAN IV/RSX **#RSX** FEB 84 PDF-11 FORTRAN-77 DEBUG V1.0 SFD 30.33.00 AC-Y398B-TK-001 1.0 FORTRAN-77 DEBUG, PDF-11 1 PDP-11 FORTRAN-77 INSTL GUIDE/REL NOTES AA-V196A-TK-001 5.0 FORTRAN-77/RSX, PDP-11 *RSX 1 JAN 84 FORTRAN-77/RSX, FDP-11 3 **FER 84** PDP-11 FORTRAN-77 LANGUAGE REFERENCE MANUAL AA-V193A-TK-001 5.0 *RSX PDP-11 FORTRAN-77 OTS REFERENCE MANUAL #RSX 2 **FEB 84** AA-V195A-TK-001 5.0 FORTRAN-77/RSX, FDF-11 FEB 84 PROFESSIONAL TOOL KIT FORTRAN-77 #RSX 2 PDP-11 FORTRAN-77 OTS REFERENCE MANUAL AA-V195A-TK-001 5.0 3 FEB 84 PDP-11 FORTRAN-77 USER'S GUIDE AA-V194A-TK-001 5.0 FORTRAN-77/RSX, PDF-11 #RSX 3 FE8 84 PROFESSIONAL TOOL WIT FORTRAN-77 *RSX PDP-11 FORTRAN-77 USER'S GUIDE AA-V194A-TK-001 5.0 2 FORTRAN-77 DEBUG, PDF-11 #RSX **JAN 81** PDP-11 FORTRAN-77/DEBUG USER'S GUILLE AA-V197A-TK-001 1.0 PDP-11 FORTRAN-77/RSX V5.0 SPD 14.31.06 AE-J139G-TC-001 5.0 FORTRAN-77/RSX, PIP-11 RSX 1 FEB 84 PIP-11 FORTRAN-77/RSX V5.0 SFD 14.31.07 AE-J139H-TC-001 5.0 FORTRAN-77/RSX, FDP-11 #R'SX 1 HAY 84 PDF-11 MACRO-11 LANGUAGE REF MANUAL AA-V027A-TC-001 4.1 RSX-11M **#RSX** 3 **NOV 83** PDP-11 MACRO-11 LANGUAGE REFERENCE MANUAL AA-V027A-TC-001 2.1 RSX-11H-PLUS **IRSX** 3 **NOV 83** PDP-11 MACRO-11 LANGUAGE REFERENCE MANUAL **#RSX** 3 **NOV 83** AA-V027A-TC-001 4.1 RSX-11S PDP-11 MACRO-11 LANGUAGE REFERENCE MANUAL MICROPOWER/PASCAL-RSX **TRISX** 3 **JUL 84** AA-V027A-TC-001 1.5 FDP-11 MACRO-11 LANGUAGE REFERENCE MANUAL 66-V0276-TC-001 1.0-2.0 PROFESSIONAL HOST TOOL KIT *RSX 3 **JAN 94** RSX 11H F ENHANC PKG FOR MINC PDP-11 MICROCOMPUTER INTERFACES HANDBOOK 7 APR 83 EB-23144-18-001 1.1-1.2 *RSX PDP-11 PASCAL INSTALLATION GDE/REL NOTES AA-M877A-TC-001 1.0 PASCAL/RSX, PDP-11 RSX 1 JAN 84 PDF-11 PASCAL INSTALLATION GDE/REL NOTES AA-M877E-TC-001 1.1 PASCAL/RSX, FUP-11 **IRSX** 1 MAY 84 PDP-11 PASCAL LANGUAGE REF MANUAL (UPD#1) 2 AA-M875A-TC-002 1.1 PASCAL/RSX, PDP-11 **IRSX FEB 84** PDP-11 PASCAL LANGUAGE REFERENCE MANUAL AA-H875A-TC-001 1.0 FASCAL/RSX, FUF-11 RSX 2 JAN 84 2 PDP-11 PASCAL USER'S GUIDE AA-M876A-TC-001 1.0 PASCAL/RSX, FUP-11 RSX JAN 84 PDP-11 PASCAL USER'S GUIDE (UPD#1) AA-M876A-TC-002 1.1 FASCAL/RSX, FDP-11 *RSX 2 **FEB 84** FEB 84 PDF-11 PASCAL/RSX V1.1 SPD 14.18.02 AE-N917C-TC-001 1.1 FASCAL/RSX, FDF-11 RSX 1 PDP-11 PASCAL/RSX V1.1 SFD 14.18.03 AE-N917D-TC-001 1.1 PASCAL/RSX, PDF-11 #RSX 1 MAY 84

TITLE OF HANUAL	PART NUMBER REV LEVEL	VERSION		PRODUCT NAME	OFERATING SYSTEM	NUMBER OF FICHE	LIATE
PDP-11 PROGRAMMING CARD	EH-S1046-78-001	4.1	RSX-11M		*RSX	1	NOV 83
PDF-11 PROGRAMMING CARD	EH-S1046-78-001	2.1	RSX-11H-FLUS		‡RSX	1	NOV 83
PDP-11 PROGRAMMING CARD	EH-S1046-78-001	4.1	RSX-11S		*RSX	1	HOV 83
PDP-11 PROGRAMMING CARD	EH-S1046-78-001	1.5	HICROPOWER/PA	SCAL-RSX	*RSX	1	JUL 84
PDF-11 SORT/MERGE USER'S GUIDE	AA-CI67A-TC-001	3.0	SORT-11		*RSX	2	JUL 84
PDP11 COBOL LANG REF MANUAL (UPD#1 % #2)	AA-1747E-TC-001	4.4	PDF-11 COBOL		*RSX	3	SEP 82
PDP11 KEYPAD EDITOR REFERENCE CARD	AV-H854A-TC-001	1.0	FMS-11/RSX		#RSX	1	SEP 82
PDF11 KEYPAD EDITOR RELEASE NOTES	AA-J692A-TC-001	1.0	FHS-11/RSX		*RSX	1	SEP 82
PDF11 KEYFAD EDITOR USER'S GDE (UFD#1)	AA-H853A-TC-001	1.0	FhS-11/RSX		#RSX	2	SEF 82
PDP11 SORT REFERENCE MANUAL (UPDATE #1)	AA-3341C-TC-001	2.0	SORT-11		RSX	2	SEP 82
PLXY-11 USER'S GUIDE	AA-J535B-TK-001	1.3	PLXY-11M		#RSX	1	HAY 84
PLXY-11 V1.1 USER'S GUIDE	AA-J535A-TK-001	1.1	PLXY-11H		RSX	1	SEP 82
FLXY-11 V1.3 SPD 14.39.01	AE-K797B-TC-001	1.3	PLXY-11H		*RSX	1	HAY 84
PRO GIDIS MANUAL (UPD#1)	AA-Y660A-TH-001	2.0	PROFESSIONAL	HOST TOOL KIT	*RSX		OCT 84
FRO HOST TK F-77 IG/DOC SUPL	AA-R387B-TK-001	5.0	PROFESSIONAL	TOOL KIT FORTRAN-77	*RSX	1	JAN 84
PRO TOOL KIT BASIC + 2 INSTL GDE/REL NTS	AA-P104B-TK-001	2.1	PROFESSIONAL	TOOL KIT BASIC-PLUS-2	RSX	1	JAN 84
PRO TOOL KIT BASIC-PLUS-2 V2.2 SPD 30.27.01	AE-P650B-TK-001	2.2	PROFESSIONAL	TOOL KIT BASIC-PLUS-2	RSX	1	HAY 84
PRO TOOL KIT BASIC-PLUS-2 V2.2 SPD 30.27.03	AE-P650D-TK-001	2.2	PROFESSIONAL	TOOL KIT BASIC-PLUS-2	#RSX	1	JUL 84
PRO TOOL KIT COBOL-81 INSTL GDE/DOC SUPL	AA-Y285A-TH-001	2.1	PROFESSIONAL	TOOL KIT COBOL-81	ŧRSX	1	JUL 84
FRO TOOL KIT COBOL-81 V2.1 SFD 46.24.00	AE-Z764A-TH-001	2.1	PROFESSIONAL	TOOL KIT COBOL-81	*RSX		OCT 84
PRO TOOL KIT FORTRAN-77 V5.0 SFD 30.38.01	AE-W5878-TK-001	5.0	PROFESSIONAL	TOOL KIT FORTRAN-77	RSX	1	MAY 84
FRO TOOL KIT FORTRAN-77 V5.0 SFD 30.38.02	AE-W587C-TK-001	5.0	PROFESSIONAL	TOOL KIT FORTRAN-77	#RSX	1	JUL 84
PRO TOOL KIT FORTRAN-77/DBG IG/DOC SUPL	AA-Z384A-TK-001	1.0	PROFESSIONAL	TOOL KIT FORTRAN-77 DB	*RSX	1	MAY 84
PRO TOOL KIT FORTRAN-77/DBG V1.0 SPD 40.25.00) AE-Z847A-TH-001	1.0	PROFESSIONAL	TOOL KIT FORTRAN-77 DB	*RSX	1	JUL 84
PRO TOOL KIT INSTL GDE/REL NTS	AA-N616B-TK-G01	1.0	PROFESSIONAL	HOST TOOL KIT	RSX	1	JAN 84
FRO TOOL KIT INTRODUCTION TO DIBOL-83	AA-F042B-TK-001	1.0	RSX 11h FLUS	DIFOL	RSX 11 PLU	1	JUL 84

PART TITLE NUMBER NUMBER OF REV PRODUCT OPERATING 0F HANUAL LEVEL VERSION NAME SYSTEN FICHE DATE PRO TOOL KIT MESSAGE MANUAL AA-Z515A-TK-001 1.6 PROFESSIONAL TOOL KIT DIPOL **#RSX** FEB 84 1 PRO TOOL KIT PASCAL INSTL GDE/RELEASE NOTES AA-R759C-TK-001 1.2 PROFESSIONAL TOOL KIT FASCAL #RSX 1 JUL 84 AA-R759R-TK-001 1.1 PROFESSIONAL TOOL KIT PASCAL RSX 1 HAY 84 PRO TOOL KIT PASCAL INSTL/REL NOTES PRO TOOL KIT PASCAL LANGUAGE REFERENCE MANUAL AA-U047A-TK-001 1.1-1.2 PROFESSIONAL TOOL KIT PASCAL **#RSX** 2 JAN 84 PRO TOOL KIT PASCAL USER'S GUIDE AA-U046A-TK-001 1.1-1.2 PROFESSIONAL TOOL KIT FASCAL ***RSX** JAN 84 PRO TOOL KIT REFERENCE MANUAL AA-BT74A-TH-001 2.0 PROFESSIONAL HOST TOOL KIT *RSX OCT 84 3 PRO/DECNET TK PROGRAMMER'S REFERENCE MANUAL AA-AV69A-TK-001 2.0 PROFESSIONAL HOST TOOL KIT *RSX JUL 84 PRO/DECNET TOOL KIT INSTALLATION GUIDE AA-AV70A-TK-001 2.0 PROFESSIONAL HOST TOOL KIT **#RSX** 1 JUL 84 **#RS** X 1 PRO/FHS-11 DOCUMENTATION SUPPLEMENT AA-P103B-TK-001 1.0-2.0 PROFESSIONAL HOST TOOL KIT JAN 84 5 AFR 83 #R'SX PRO/RMS-11 MACRO FROGRAMMER'S GUIDE AA-P099A-TK-001 1.0-2.0 PROFESSIONAL HOST TOOL KIT 1 AFR 83 PRO/RMS-11: AN INTRODUCTION AA-P098A-TK-001 1.0-2.0 PROFESSIONAL HOST TOOL KIT *RSX PRO/TK PRTIL V1.1 SPD 40.35.01 AE-BL52B-TH-001 1.1 FROFESSIONAL REAL TIME INTERFACE LI *RSX OCT 84 PRO/TOOL KIT CONHAND LANG/UTILITIES HANUAL AA-X912A-TH-001 1.0-2.0 PROFESSIONAL HOST TOOL KIT #RSX 5 MAY 84 PRO/TOOL KIT DOCUMENATION DIRECTORY AA-X910A-TH-001 1.0 PROFESSIONAL HOST TOOL KIT RSX 1 HAY 84 PRO/TOOL KIT INSTALLATION GDE/RELEASE NOTES AA-X911A-TH-001 1.0 PROFESSIONAL HOST TOOL KIT RSX HAY 84 FRO/TOOL KIT INSTALLATION GUIDE/RELEASE NOTES AA-X911B-TH-001 2.0 PROFESSIONAL HOST TOOL KIT *RSX 1 JUL 84 FRO/TOOL KIT V2.0 SPD 40.19.01 BH-Y991B-TH-001 2.0 PROFESSIONAL HOST TOOL KIT #RSX OCT 84 PROFESSIONAL HOST COMM INSTL PROCEDURES PROFESSIONAL HOST COMMUNICATIONS RSX 1 JAN 84 AA-F4128-TK-001 1.5 PROFESSIONAL HOST COMM INSTL PROCEDURES AA-P412C-TK-001 1.7 PROFESSIONAL HOST COMMUNICATIONS **#RSX** 1 HAY 84 PROFESSIONAL TOOL KIT DIROL LANG REF MANUAL PROFESSIONAL TOOL KIT DIBOL RSX 3 AFE 83 AA-P044A-TK-001 1.0 PROFESSIONAL TOOL KIT DIROL REL NTS/INSTL GDE AA-F045A-TK-001 1.0 PROFESSIONAL TOOL KIT DIPOL RSX 1 APR 83 PROFESSIONAL TOOL KIT DIBOL REL NTS/INSTL GDE AA-F045C-TK-001 1.6 PROFESSIONAL TOOL KIT DIROL **#RSX** 1 HAY 84 2 PROFESSIONAL TOOL KIT DIBOL USER'S GUIDE AA-F043A-TK-001 1.0 PROFESSIONAL TOOL KIT DIROL RSX APR 83 PROFESSIONAL TOOL KIT DIBOL USER'S GUIDE AA-F043C-TK-001 1.6 PROFESSIONAL TOOL KIT DIBOL 2 HAY 84 #F.SX PROVUE OFFLINE FICTURE SYSTEM MANUAL AA-M024B-TK-001 2.0 RSX 11/PROVUE #RSX 1 JAN 84 PROVUE ONLINE FICTURE SYSTEM MANUAL AA-M025B-TK-001 2.0 RSX 11/FROVUE **#RSX** 1 JAN 84

TITLE OF MANUAL	PART NUMBER REV LEVEL	VERSION	PRODUCT NAME	OPERATING SYSTEM	NUMBER OF FICHE	DATE
PROVUE PROGRAMMING GUIDE	AA-N026B-TK-G01	2.0	RSX 11/PROVUE	\$RSX	1	JAN 84
PROVUE SYSTEM BUILD HANUAL	AA-M022B-TK-001	2.0	RSX 11/PROVUE	*RSX	1	JAN 84
PROVUE SYSTEM MANAGER'S GUIDE	AA-M021B-TK-001	2.0	RSX 11/FROVUE	*RSX	1	JAN 84
PROVUE TERMINAL USER'S GUILLE	AA-M023R-1K-001	2.0	RSX 11/PROVUE	‡RSX	1	JAN 84
PROVUE UTILITY GUIDE	AA-M0278-TK-001	2.0	RSX 11/PROVUE	*RSX	1	JAN 84
PROVUE V2.0 RELEASE NOTES	AA-M089E-TK-001	2.0	RSX 11/PROVUE	*RSX	1	JAN 84
PROVUE V2.0 SPD 14.33.1	AE-N271B-TC-001	2.0	RSX 11/FROVUE	*RSX	1	FEB 84
PRTIL FROMES REFERENCE MANUAL	AA-F411A-TK-001	1.1	FROFESSIONAL REAL TIME INTERFACE LI	*RSX	3	JUL 84
PRTIL RELEASE NOTES	AA-AI40C-TH-001	1.1	PROFESSIONAL REAL TIME INTERFACE LI	*RSX		OCT 84
REAL-11 PROGRAMMERS REFERENCE MANUAL ERRATA	AV-V187A-TC-001	1.2	RSX 11H F ENHANC FKG FOR HINC	*RSX	1	JUL 84
REAL11H/HNC FORTTRAN PROG REF MAN (UPD#1,2)	AA-D631C-TC-001	1.1-1.2	RSX 11M F ENHANC FKG FOR MINC	#RSX	4	APR 83
RELEASE NOTES FOR RGL-11	AA-M839A-TC-001	1.1	RGL-11	RSX	1	APR 83
RELEASE NOTES FOR RGL-11	AA-M839B-TC-001	1.1	RGL-11	*RSX	1	FEB 84
RELEASE NOTES FOR RSX-11H/FEP AND FRP	AA-M055D-TC-001	1.2	RSX 11M F ENHANC PKG FOR MINC	*RSX	1	JAN 84
RGL-11 INSTALLATION GUIDE	AA-M838A-TC-001	1.1	RGL-11	*RSX	1	APR 83
RGL-11 PROGRAMMER'S REFERENCE MANUAL	AA-M837A-TC-001	1.1	RGL-11	*RSX	3	APR 83
RGL-11 V1.1 SPD 14.62.04	AE-M802E-TC-001	1.1	RGL-11	*RSX	1	MAY 84
RGL-11 V1.1 SPD 14.62.3	AE-M802D-TC-001	1.1	RGL-11	RSX	1	FER 84
RGL/11 PROGRAMMER'S REFERENCE MANUAL	AA-N837A-TC-001	1.1-1.2	RSX 11M F ENHANC PKG FOR HINC	*RSX	3	APR 83
RGL/11 PROGRAMMERS REFERENCE MANUAL ERRATA	AV-V185A-TC-001	1.2	RSX 11H F ENHANC PKG FOR HINC	*RSX	1	JAN 84
RJE/HASP WORKSTATION INSTALLATION GUIDE	AA-5426C-TC-001	1.1	RSX 11M IAS RJE/HASF	RSX	1	SEP 82
RJE/HASP WORKSTATION INSTALLATION GUIDE	AA-5426D-TC-001	1.1	RSX 11M IAS RJE/HASP	≭ RSX	i	JUL 84
RJE/HASP WORKSTATION OPERATOR'S GUIDE	AA-5427C-TC-001	1.1	RSX 11H IAS RJE/HASP	RSX	1	SEP 82
RJE/HASP WORKSTATION OPERATOR'S GUIDE	AA-5427D-TC-001	1.1	RSX 11H IAS RJE/HASP	*RSX	1	JUL 84
RMS-11 PROGRAMMERS MANUAL	AA-L668A-TC-001	4.1	RSX-11H	*RSX	5	10V 83
RMS-11 PROGRAMMER'S MANUAL	AA-L668A-TC-001	2.1	RSX-11M-PLUS	≭ RSX	5	NOV 83

TITLE	PART NUMBER					NUMBER		
OF Manual	rev Level	VERSION		RODUCT NAME	OPERATING SYSTEM	OF FICHE	DAT	TE
RMS-11 USER'S GUIDE	AA-L669A-TC-001	1.1	RSX-11H		*RSX	2	NOV 8	83
RMS-11 USER'S GUIDE	AA-L669A-TC-001	2.1	RSX-11H-FLUS		*RSX	2	NOV 8	83
RMS-11 UTILITIES	AA-L670A-TC-001	2.1	RSX-11M-FLUS		*RSX	3	NOV 8	33
RMS-11 UTILITIES MANUAL	AA-L670A-TC-001	4.1	RSX-11M		*RSX	3	NOV 8	83
RMS-11: AN INTRODUCTION	AA-L682A-TC-001	4.1	RSX-11M		*RSX	1	NOV 8	83
RMS-11: AN INTRODUCTION	AA-L682A-TC-001	2.1	RSX-11M-FLUS		*RSX	1	NOV 8	83
RSX 11M SNA FE V1.1 SPD 14.04.1	AE-JS12C-TC-001	1.1	RSX 11M SNA FE		#RSX	1	FEB 8	84
RSX DECNET GUIDE TO USER UTILITIES	AA-H223B-TC-001	3.1	DECNET-11M		RSX	2	FEB 8	84
RSX DECNET GUIDE TO USER UTILITIES	AA-H223C-TC-001	4.0	DECNET-11H		*RSX	2	MAY 8	84
RSX DECNET NETWORK GEN AND INSTALLATION GUIDE	AA-H225C-TC-001	4.0	DECNET-11H		#RSX	5	MAY 8	84
RSX DECNET NETWORK GEN AND INSTL GUIDE	AA-H225B-TC-001	3.1	DECNET-11H		RSX	3	FEB 8	84
RSX DECNET POST-INSTL CHECKOUT PROCEDURES	AA-J319B-TK-001	3.1	DECNET-11M		KSX	2	FEB 8	84
RSX DECNET POST-INSTL CHECKOUT PROCEDURES	AA-J319C-TK-001	4.0	DECNET-11M		*RSX	1	HAY 8	84
RSX DECNET PROGRAMMER'S REF MANUAL	AA-M098A-TC-001	3.1	DECNET-11H		RSX	5	FEB 8	84
RSX DECNET PROGRAMMER'S REFERENCE MANUAL	AA-H098R-TC-001	4.0	DECNET-11M		*RSX	4	YAK	84
RSX DECNET RELEASE NOTES	AA-J517B-TC-001	3.1	DECNET-11H		RSX	1	FEB 8	84
RSX DECNET RELEASE NOTES	AA-J517C-TC-001	4.0	DECNET-11H		≭ RSX	1	YAY 8	84
RSX DECNET SYSTEM MANAGER'S GUIDE	AA-H224B-TC-001	3.1	DECNET-11N		RSX	S	FER 8	84
RSX DECNET SYSTEM MANAGER'S GUIDE	AA-H224C-TC-001	4.0	DECNET-11H		*RSX	5	YAY S	84
RSX DLX-11 RELEASE NOTES	AA-K143A-TC-001	1.0	RSX DLX-11		≉ RSX	1	SEP 8	82
RSX DLX-11 USER'S GUIDE	AA-K142A-TC-001	1.0	RSX DLX-11		#RSX	2	SEP 8	82
RSX DLX-11 V1.0 SPD 10.6.0	AE-K434B-TC-001	1.0	RSX DLX-11		*RSX	1	FER 8	81
RSX MDE/T-11 V1.0 SPD 14.23.0	AE-F081B-TC-001	1.0	RSX MDE/T11		ARSX		FEB 8	84
RSX-11 2780/3780 EMULATOR USER'S GUIDE	AA-J581A-TC-001	4.1	RSX 11 2780/378	O EMULATOR	*RSX	1	SEF 8	82
RSX-11 PSI GENERATION GUIDE	AA-H372A-TC-001	2.0	RSX 11 FSI/M		*RSX	2	SEP 8	82
RSX-11 PSI NETWORK SPECIFIC INFORMATION	AA-H373A-TC-001	2.0	RSX 11 FSI/M		₹RSX	1	SEP 8	82

TITLE OF HANUAL	PART NUMBER REV LEVEL	VERSION	PRODUCT NAME	OPERATINO SYSTEM	NUMBER G OF FICHE	DATE
RSX-11 PSI REFERENCE CARD	AV-M749A-TC-001		RSX 11 PSI/M	*RSX	1	SEP 82
RSX-11 PSI RELEASE NOTES	AA-H374A-TC-001		RSX 11 PSI/M	*RSX	1	SEP 82
RSX-11 PSI SYSTEM MANAGER'S GUIDE	AA-N370A-TC-001		RSX 11 PSI/M	*RSX	3	SEP 82
RSX-11 PSI USER'S GUIDE	AA-M371A-TC-001		RSX 11 PSI/M			
RSX-11 FSI/H V2.0 SPD 10.42.0				*RSX	2	SEP 82
	AE-N141B-TC-001		RSX 11 PSI/M	*RSX	1	FEB 84
RSX-11 SYS GENERATION AND INSTALLATION GDE	AA-H625C-TC-001		RSX-11M	≭RSX	5	NOV 83
RSX-11/3271 PE PROGRAMMER'S GUIDE	AA-C739B-TC-001	3.0	RSX 11M 3271 PROTOCOL EMULATOR	*RSX	2	APR 83
RSX-11/3271 PE RELEASE NOTES V3.0	AA-H032C-TC-001	3.0	RSX 11H 3271 PROTOCOL EMULATOR	*RSX	1	APR 83
RSX-11/3271 PE SYSTEM MANAGER'S GUIDE	AA-C739C-TC-001	3.0	RSX 11H 3271 PROTOCOL EMULATOR	*RSX	3	APR 83
RSX-11M BCP USER'S GUIDE	AA-N269A-TC-001	1.0	BCP	RSA	2	SEF 82
RSX-11M CROSS REFERENCE TABLE	AE-M778F-TC-001	4.1	RSX-11M	*RSX		OCT 84
RSX-11M FEF AND FRP INSTALLATION/USRS GDE	AA-J303D-TC-001	1.2	RSX 11M F ENHANC PKG FOR MINC	*RSX	2	JAJ: 84
RSX-11H GUITE TO WRITING AN I/O DRIVEN	AA-2600E-TC-001	4.1	RSX-11M	‡RS X	3	NOV 83
RSX-11M GUIDE TO WRITING I/O DRIVER	AA-2600E-TC-001	4.1	RSX-11S	*RSX	3	NOV 83
RSX-11M MINI REFERENCE	AV-5570E-TC-001	4.1	RSX-11M	#RSX	3	NOV 83
RSX-11M MINI REFERENCE	AV-5570E-TC-001	4.1	RSX-11S	*RSX	3	NOV 83
RSX-11H SYSTEM GENERATION/INSTALLATION GUIDE	AA-H625C-TC-001	4.1	RSX-11S	≭ RSX	5	MOV 83
RSX-11M V4.1 SPI 14.32.21	AE-3407V-TC-001	4.1	RSX-11H	*RSX	1	MAY 84
RSX-11M V4.1 SPD 14.35.20	AE-3407U-TC-001	4.1	RSX-11H	RSX	1	FEB 84
RSX-11M-H-PLUS I/O DRIVERS REF MAN (UPD#1)	AA-L677A-TC-001	2.1	RSX-11M-PLUS	*R3X	6	NOV 83
RSX-11M-M-PLUS MCR OF MANUAL (UPD#1)	AA-L678A-TC-001	2.1	RSX-11M-PLUS	#RSX	5	NOV 83
RSX-11M-M-PLUS SYSTEM MANAGEMENT GDE (UPD#1)	AA-L679R-TC-001	2.1	RSX-11M-FLUS	*RSX	6	HOV 83
RSX-11M-M-PLUS TASK BUILDER MANUAL	AA-L680E-TC-001	2.1	RSX-11H-PLUS	*RSX	5	NOV 83
RSX-11M-PLUS GUIDE TO WRITING I/O DRIVER	AA-H267B-TC-001	2.1	RSX-11M-PLUS	*RSX	4	NOV 83
RSX-11M-PLUS INFORMATION DIRECTORY AND INDEX	AA-H426C-TC-001	2.1	RSX-11M-PLUS	*RSX	4	NOV 83
RSX-11M-FLUS MINI REFERENCE	AV-H435C-TC-001	2.1	RSX-11M-PLUS	¥RSX	3	NOV 83

TITLE	PART NUMBER				NUMBER	₹
OF	REV	UFB0100	FRODUCT	OPERATING		5. A T P
MANUAL	LEVEL	VERSION	NAME	SYSTEM	FICHE	DATE
RSX-11M-FLUS SYSTEM GEN/INSTALLATION GUIDE	AA-H431C-TC-001	2.1	RSX-11H-PLUS	#RSX	3	NOV 83
RSX-11M-PLUS V2.1 CROSS REFERENCE SPD	AE-H779I-TC-001	2.1	RSX-11M-FLUS	*RSX	1	MAY 84
RSX-11M-FLUS V2.1 RELEASE NOTES	AA-H427C-TC-001	2.1	RSX-11M-PLUS	*RSX	1	NOV 83
RSX-11M-PLUS V2.1 SPD 14.70.08	AE-H862I-TC-001	2.1	RSX-11M-FLUS	RSX	1	FER 84
RSX-11M-PLUS V2.1 SFD 14.70.09	AE-H862J-TC-001	2.1	RSX-11M-PLUS	*RSX	1	JUL 84
RSX-11H/11S INFORMATION DIRECTORY/INDEX	AA-2593G-TC-001	4.1	RSX-11H	*RSX	4	HOV 83
RSX-11H/11S V4.1 UFDATE B INFORMATION	AA-W2598-TC-001	4.1	RSX-11S	RSX	1	FEB 84
RSX-11H/11S V4.1 UPDATE C INFORMATION	AA-W259C-TC-001	4.1	RSX-11S	#RSX	1	HAY 84
RSX-11M/FEF V1.2 SPD 14.44.4	AE-L762E-TC-001	1.2	RSX 11H F ENHANC PNG FOR HINC	*RSX	1	FEB 84
RSX-11H/H+ BATCH AND QUEUE OPER MANUAL	AA-L671A-TC-001	2.1	RSX-11M-PLUS	#RSX	2	NOV 83
RSX-11M/M+ COMMAND LANGUAGE MANUAL	AA-L672B-TC-001	2.1	RSX-11M-FLUS	*RSX	6	K8 VON
RSX-11M/M+ CRASH DUMP ANZ REF MANUAL	AA-L673B-TC-001	4.1	RSX-11M	#RSX	3	NOV 83
RSX-11M/M+ CRASH DUMP ANZ REF MANUAL	AA-L673B-TC-001	المثيا	RSX-11M-PLUS	*RSX	3	NOV 83
RSX-11M/M+ CRASH DUMP ANZ REF MANUAL	AA-L673B-TC-001	4.1	RSX-11S	*RSX	3	NOV 83
RSX-11H/H+ GUIDE TO PROGRAM DEVELOPMENT	AA-L676A-TC-001	2.1	RSX-11M-PLUS	#RSX	2	NOV 83
RSX-11H/H+ I/O DIRVERS REF MANUAL (UPD#1)	AA-L677A-TC-001	4.1	RSX-11S	*RSX	6	NOV 83
RSX-11H/H+ I/O DRIVERS REF HAN (UPD#1)	AA-L677A-TC-001	4.1	RSX-11H	*RSX	6	E8 VOH
RSX-11M/H+ NCR OPERATIONS MANUAL (UPD#1)	AA-L678A-TC-001	4.1	RSX-11M	*RSX	5	NOV 83
RSX-11H/N+ SYS(EH HANAGEHENT GDE (UPD#1)	AA-L679B-TC-001	4.1	RSX-11M	*RSX	6	NOV 83
RSX-11H/H+ SYSTEM MANAGEMENT GUIDE (UPD#1)	AA-L679B-TC-001	4.1	RSX-11S	₽RSX	6	NOV 83
RSX-11M/M-PLUS BATCH AND QUEUE OPERATIONS MAN	AA-L671A-TC-001	4.1	RSX-11M	*RSX	2	NOV 83
RSX-11H/H-PLUS COMMAND LANGUAGE MANUAL	AA-L672B-TC-001	4.1	RSX-11H	#RSX	6	HOV 83
RSX-11H/M-PLUS ERROR LOGGING MANUAL	AA-L674B-TC-001	4.1	RSX-11H	#RSX	3	NOV 83
RSX-11M/M-PLUS ERROR LOGGING MANUAL	AA-L674E-TC-001	2.1	RSX-11H-FLUS	*RSX	3	E8 VON
RSX-11H/H-PLUS EXECUTIVE REFERENCE MANUAL	AA-L675A-TC-001	4.1	RSX-11h	*RSX	4	K8 VDM
RSX-11M/M-PLUS EXECUTIVE REFERENCE MANUAL	AA-L675A-TC-001	2.1	RSX-11H-PLUS	#RSX	4	NOV 83

TITLE OF	PART NUMBER REV			RODUCT	OPERATING		
HAUNAL	LEVEL	VERSION		HAHE	SYSTEM	FICHE	DATE
RSX-11H/H-PLUS EXECUTIVE REFERENCE HANUAL	AA-L675A-TC-001	4.1	RSX-11S		\$RSX	1	NOV 83
RSX-11M/M-PLUS GUIDE TO PROGRAM DEVELOPMENT	AA-L676A-TC-001	4.1	RSX-11H		*RSX	2	NOV 83
RSX-11M/M-PLUS GUIDE TO PROGRAM DEVELOPMENT	AA-L676A-TC-001	4.1	RSY-115		*RSX	2	NOV 83
RSX-11M/M-PLUS INSTALLATION/RELEASE NOTES	AA-M181C-TC-001	2.0	COROL-81/RSX		*RSX	1	JAN 84
RSX-11n/H-PLUS MCR OPERATIONS MANUAL (UPD#1)	AA-L678A-TC-001	4.1	RSX-11S		*RSX	5	NOV 83
RSX-11M/H-PLUS RMS-11 UTILITIES MANUAL	AA-L670A-TC-001	1.0-2.0	PROFESSIONAL HO	ST TOOL KIT	*RSX	3	HAY 84
RSX-11M/M-PLUS TASK BLDR MANUAL (UPD#1)	AA-L680B-TC-001	4.1	RSX-11H		TRSX	5	NOV 83
RSX-11H/H-PLUS TASK BUILDER HANUAL	AA-L680R-TC-001	4.1	RSX-11S		#RSX	5	MOV 83
RSX-11M/M-PLUS TASK BUILDER MANUAL	AA-L680R-TC-001	1.0-2.0	PROFESSIONAL HO	OST TOOL KIT	*RSX	5	JAN 84
RSX-11M/H-PLUS USER'S GUIDE	AA-H179B-TC-001	2.0	COFOL-81/RSX		*RSX	5	JAN 84
RSX-11M/M-PLUS USER'S GUIDE	AA-H179R-TC-001	2.1	PROFESSIONAL TO	OOL KIT COBOL-81	#RSX	5	HAY 84
RSX-11H/H-PLUS UTILITIES MANUAL (UPD#1)	AA-L681A-TC-001	4.1	RSX-11H		*RSX	6	NOV 83
RSX-11M/H-PLUS UTILITIES MANUAL (UPD#1)	AA-L681A-TC-001	2:1	RSX-11H-PLUS		*RSX	6	NOV 83
RSX-11M/RSX-11S INFORMATION DIRECTORY & INDEX	AA-2593G-TC-001	4.1	RSX-11S		#RSX	4	NOV 83
RSX-11M/RSX-11S RELEASE NOTES	AA-2573H-TC-001	4.1	RSX-11H		*RSX	2	NOV 83
RSX-11M/RSX-11S RELEASE NOTES	AA-2573H-TC-001	4.1	RSX-11S		#R'SX	2	NOV 83
RSX-11S SYS G A/INSTL GDE (INCLUDES UFD#1)	AA-2874E-TC-001	4.1	RSX-11S		*REX	2	NOV 83
RSX-11S V4.1 SPD 09.21.14	AE-34270-TC-001	4.1	RSX-11S		*RSX	1	HAY 84
RSX-11S V4.1 SFD 9.21.13	AE-3427N-TC-001	4.1	RSX-11S		RSX	1	FER 84
RSX-DECNET REFERENCE GUIDE	AA-H097A-TC-001	3.1	DECNET-11M		RSX	1	FER 84
RSX/RMS USER'S GUIDE	AA-L669A-TC-001	1.0-2.0	PROFESSIONAL HO	OST TOOL KIT	*RSX	2	MAY 84
RSX/VAX/VHS FORTRAN IV USER'S GUIDE	AA-R955A-TK-001	2.6	FORTRAN 1V/RSX		#RSX	2	JAN 84
RSX/VMS CORAL-66 USER'S GUDE	AA-01120-TK-001	4.0	CO9AL-66		#RSX	4	APR 83
RSX/VHS FORTRAN IV INSTALLATION/REL NTS	AA-R954A-TK-001	2.6	FORTRAN IV/RSX		*RSX	1	JAN 84
RSX11 2780/3780 EMUL V4.1 SPD 10.01.01	AE-K997R-TC-001	4.1	RSX 11 2780/378	80 EMULATOR	RSX	1	MAY 84
RSX11 2780/3780 EMUL V4.1 SPD 10.01.02	AE-K997C-TC-001	4.1	RSX 11 2780/37	80 EMULATOR	KRSX		OCT 84

TITLE OF	PART HUMBER REV		FOUDORT	OPERATING	NUMBER OF	t
HANUAL	LEVEL	VERSION		SYSTEM	FICHE	PATE
RSX11M IAS RJE/HASP V1.1 SPD 10.51.6	AE-5248G-TC-001	1.1	RSX 11H IAS RJE/HASP	*RSX	1	FEB 84
RSX11H/H+ HDE/T11 SFTW INSTL GDE/REL NTS	AA-N998A-TC-001	1.0	RSX HDE/111	*RSX	1	APR 83
RSX11M/SNA FE APPLICATIONS PROGRAMMER'S GUIDE	AA-5503B-TC-001	1.1	RSX 11M SNA PE	#RSX	2	SEF 82
RSX11H/SNA PE CONCEPTS AND FACILITIES (UPD#1)	AA-5501A-TC-001	1.1	RSX 11M SNA PE	*RSX	2	SEF 82
RSX11H/SNA FE RELEASE NOTES (UPD#1)	AA-J549A-TC-001	1.1	RSX 11M SNA FE	#RSX	1	SEP 82
RSX11H/SNA PE SYSTEM MANAGER'S GUIDE (UPD#1)	AA-5502A-TC-001	1.1	RSX 11H SNA FE	*RSX	2	SEF 82
RTEH-11 INSTALLATION GUIDE	AA-N436B-TK-001	2.0	RTEH-11	*RSX	1	MAY 84
RTEM-11 INSTL GUIDE/RELEASE NOTES (UFD#1)	AA-N436A-TK-001	1.1	RTEM-11	RSX	2	JAN 84
RTEM-11 RELEASE NOTES	AA-W325A-TK-001	2.0	RTEH-11	*RSX	i	MAY 84
RTEM-11 USER'S GUIDE	AA-N435C-TK-001	2.0	RTEH-11	*RSX	2	HAY 84
RTEM-11 USER'S MANUAL	AA-N435B-TK-001	1.1	RTEH-11	RSX	`2	JAN 84
RTEH-11 V2.0 SPD 30.21.04	AE-N571E-TK-001	2.0	RTEM-11	*RSX	i	HAY 84
SCIENTIFIC SUB PROGRAMMER'S REF MAN (UPD#1)	AA-1101B-TC-001	1.3	SSF-11	#RSX	2	SEP 82
SCIENTIFIC SUBROUTINES PROG REF HAN (UPD#1)	AA-1101D-TC-001	1.1-1.2	RSX 11M F ENHANC FKG FOR MINC	*RSX	2	AFR 83
SORT-11 V2.0 SFD 12.7.5	AE-5429G-TC-001	2.0	SORT-11	RSX	i	FEB 84
SORT-11 V3.0 SPD 12.07.07	AE-5429H-TC-001	3.0	SORT-11	*RSX	1	JUL 84
SSP REFERENCE MANUAL ERRATA SHEET	AV-V189A-TC-001	1.2	RSX 11H F ENHANC PKG FOR HINC	#RSX	i	JAN 84
SSP-11 V1.3 SPD 15.45.10	AE-34131-TC-001	1.3	SSP-11	*RSX	1	MAY 84
SSP-11 V1.3 SFD 15.45.9	AE-3413H-TC-001	1.3	SSP-11	RSX	1	FEB 84
TERHINAL SUBSYSTEM MANUAL	AA-N623B-TK-001	1.0-2.0	PROFESSIONAL HOST TOOL KIT	*RSX	2	JAN 84
THS PROGRAMMER'S MANUAL	AA-AD34A-TH-001	2.0	PROFESSIONAL HOST TOOL KIT	*RSX		OCT 84
IOOL KIT DOCUMENATION DIRECTORY	AA-N615C-TK-001	1.0	PROFESSIONAL HOST TOOL KIT	RSX	1	MAY 84
TOOL KIT DOCUMENTATION DIRECTORY	AA-N615B-TK-001	1.0	FROFESSIONAL HOST TOOL NIT	RSX	1	JAN 84
TOOL KIT USER'S GUIDE	4A-N617C-TK-001	1.0	PROFESSIONAL HOST TOOL KIT	RSX	3	MAY 84
UN1004 V2.0 SFB 10.79.06	AE-3454G-TC-001	2.0	UN1004	*RSX	1	FEB 84
UN1004/RSX RELEASE NOTES	AA-1341C-TC-001	2.0	UN1004	*RSX	1	SEP 82

TITLE OF MANUAL	PART Number Rev Level	VERSION	PRODUCT NAME	OPERATING SYSTEM	NUMBER OF FICHE	DATE
UN1004/RSX USRS GDE/SYS GEN GDE (UPD#1)	AA-1342B-TC-001	2.0	UN1004	*RSX	1	SEP 82
USERS/PROGRAMMERS HINI REFERENCE GUIDE	AA-X923A-TC-001	4.0	DECNET-11H	*RSX	i	JUL 84
USING DECTYPE	AA-R125B-TK-001	3.0	RSX 11M PLUS DECTYPE	RSX 11 PLU	3	JUL 84
USING THE DATATRIEVE-11/DBMS-11 INTERFACE	AA-K887R-TC-001	2.0-2.1	DBMS-11	*RSX	1	SEF 82
VSV11-M SOFTWARE DRIVER GUIDE	AA-J287B-TK-001	2.0	VSV11-M DRIVER	RSX	i	SEP 82
VSV11-M SOFTWARE DRIVER GUIDE	AA-J287E-TK-001	2.2	VSV11-H DRIVER	*RSX	i	JUL 84
VSV11-H V2.0 RELEASE NOTES	AA-M615A-TC-001	2.0	VSV11-M DRIVER	RSX	1	JAN 84
VSV11-M V2.1 SPD 14.53.03	AE-K851I-TC-001	2.1	VSV11-H DRIVER	RSX	1	FEB 84
VSV11-M V2.2 SPD 14.53.04	AE-K851A-TC-001	2.2	VSV11-M DRIVER	#RSX	1	JUL 84
VTV31-K/RSX DEVICE DRV AND SUBROUTINE LIBRARY	AA-M809A-TC-001	1.0	VTV31-K RSX11H DRIVE/SUB PKG	*RSX	1	APR 83
VTV31-K/RSX V1.0 SPD 14.73.0	AE-F079A-TC-001	1.0	VTV31-K RSX11M DRIVE/SUB PNG	*RSX	1	FEB 84